

Sensor X 23



General Check

Item	Status	Comment / Part info
Belts in good condition?		
Look for water inside cabinets. Clean out any water or maintenance items which don't belong.		
Excessive wear or damage anywhere to any components?		
Test Reject mechanism?		
Inspect belt roller bushings or rollers?		
19mm drain plugs on back of machine removed. Sensor compartment drained.		
Test E-stop and safety system		
Change air filters		



Weekly PM Checklist

Technician:

7-20-11 Page 2 of 2

Notes:
