



User Manual

SensorX 502 System

Document Number: 150612ENG-9

Revision:

Language: ENG

Date: 24 September 2020

Machine Code: GR6522, GR6534

Marel Iceland ehf

Austurhraun 9

IS-210 Gardabaer

Iceland

+354 563 8000

www.marel.com

Copyright © 2014-2020 Marel Iceland ehf.

Marel® is a registered trademark. All rights reserved. Published by Marel.

Information in this document is subject to change without further notice, and does not represent a commitment by Marel Iceland ehf.

Marel assumes no responsibility for any faults or shortcomings in this publication. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying or otherwise, without the prior written permission of Marel Iceland ehf. According to Icelandic copyright legislation, it is against the law to reproduce any part of this publication in any form or by any means, without the permission of Marel.

This user manual is the original English language instructions.

Change history

| Version | Release date | Changes |
|---------|--------------------|--|
| 2 | | New version. |
| 2 | 12. June 2015 | Machine code added, revised numbers for the conveyor belt. |
| 2 | 3. December 2015 | New numbers in the parts list. |
| 2 | 22. January 2016 | Added accessories chapter for incline/decline unit for SmartSort. Also new images in the Introduction and the Safety Instruction chapters. |
| 2 | 18. February 2016 | New electrical drawings. |
| 2 | 17. March 2016 | New electrical drawings. |
| 2 | 6. June 2016 | New electrical drawings. |
| 2 | 22. March 2017 | New electrical drawings. |
| 2 | 29. 6. June 2016 | Extensive updates, new images and part numbers. Changes in the text. |
| 2 | 22. March 2017 | New electrical drawings. |
| 2 | 17. May 2019 | New numbers in the parts list. |
| 2 | 8. July 2020 | Parts lists removed. |
| | 24. September 2020 | New electrical drawings. |

For more information about Marel and our products, go to www.marel.com.

STANDARD SAFETY AND WARNING NOTICE FOR ALL MAREL EQUIPMENT

All persons involved in the use and/or installation of this machinery should be aware of the following instructions.

Failure to follow these instructions or other safety instructions in the manual voids all warranties and may result in malfunction of the machinery, property damage, serious personal injury, or death.

WARNING

The installation and use of this product must comply with all applicable national, state, and local codes.

Turn the electrical power off when working on the machinery. Turn the main electrical breaker, located on the electrical cabinet, to the OFF position and lock the breaker with a padlock.

Electrical installations and repairs must be performed by a licensed electrician, in accordance with manufacturer's specifications and national and local electrical codes.

Operating the machinery without the supplied guards or covers installed is a misuse of the machinery and can cause a personal hazard.

Do Not

work on any moving parts of the machinery, such as belts, motors, belt tension adjusters, or rollers, without first disconnecting the electrical power and closing the main air supply valve. Otherwise, a serious personal injury or death may result.

Do Not

work on electrical or air cabinets without first disconnecting the electrical power, or a serious personal injury or death may result.

Do Not

make any changes to the emergency stop buttons.

Additional Safety Information

- Keep long hair tied back and covered.
- Avoid wearing loose clothing, jewelry, or accessories near moving machine parts. This includes ties, shirtsleeves, rings, watches, and other loose fitting items.
- Disengage the machinery to avoid moving parts when cleaning and lubricating bearings.
- Avoid moving parts when lubricating with hand-sprayed lubricants.
- Never work without another person in the vicinity.
- Wear safety glasses when doing the following:
 - using a hammer to drive pins, riveting, staking, etc.
 - drilling, grinding, etc.
 - using spring hooks or attached springs.
 - soldering, cutting wire, removing steel bands, etc.
 - cleaning parts with solvents, spray, or cleaners.
- After cleaning or maintenance, reinstall all safety devices such as guards, shields, signs, and grounding wires.
- Wear ear protection when exposed to noise exceeding 90 dB, such as when using a grinder, band saw or hammer.
- Lift items with a straight back, and push up with your leg muscles, to prevent back strain. Do not lift any equipment or parts weighing more than 30 kg (60 lb.) without assistance.
- Use only FDA or USDA approved solvents, grease or oils.

Contents

| | |
|--|---------------|
| Introduction | 1 |
| About This Manual | 1 |
| Improvements and Customer Support | 1 |
| Warranty Information | 2 |
| About the SensorX 502 System | 2 |
| Main Features and Naming Conventions | 3 |
| Operation | 3 |
| About SensorX X-ray Inspection Unit | 4 |
| Technical Specifications | 4 |
| Transportation and Handling | 6 |
| Installation | 7 |
| Site Requirements | 7 |
| Verifying the Equipment | 7 |
| Installing the SensorX 502 | 8 |
| Electrical Installations | 10 |
| Pneumatic Installations | 11 |
| Ethernet Connection | 11 |
| Check List | 12 |
| Safety Instructions | 13 |
| In General | 13 |
| Safety Arrangements | 15 |
| Warning Labels | 15 |
| Do Not | 17 |
| Radiological Safety Procedures and Precautions | 17 |
| Safety Function | 18 |
| Positions of the Safety sensors | 19 |
| Emergency Stop Buttons | 22 |
| Operation | 23 |
| In General | 23 |
| Controls and Indicators | 23 |
| User Interface | 26 |
| The Main Production Screen | 26 |
| Alarm Page | 27 |
| Information Screen | 28 |
| Programs Screen | 29 |
| The Login Screen | 30 |
| Cleaning | 31 |
| Advanced Screen | 32 |
| X-Ray Diagnostics | 32 |
| Gain Calibration | 34 |
| Hardware Monitor Screen | 35 |
| Emergency Mode | 36 |
| Weighing Calibration Procedure | 40 |

| | |
|--|------------|
| Rework System | 42 |
| Rework terminal | 43 |
| Overflow Mechanism | 44 |
| Operation Procedures | 46 |
| Before Operation | 46 |
| During Operation | 50 |
| After Operation | 52 |
| Troubleshooting | 53 |
| Maintenance | 55 |
| General Instructions | 55 |
| Maintenance Schedule | 56 |
| Maintenance Procedures | 57 |
| Pneumatic System | 58 |
| Air Cylinders | 58 |
| Product Sensors (Only on Rework Terminals) | 60 |
| Belt on SensorX X-Ray Inspection Unit | 62 |
| Belts on the System Conveyors | 62 |
| Motors | 63 |
| Emergency Stop Button | 64 |
| Filter | 64 |
| Cleaning | 65 |
| Cleaning in General | 65 |
| Materials Used in Marel Equipment | 65 |
| Water and Temperature | 66 |
| Detergents | 67 |
| Daily Cleaning | 67 |
| Sanitization | 67 |
| Training Staff | 68 |
| Cleaning Procedures | 68 |
| Preparation | 69 |
| Rinsing the Environment | 70 |
| Rinsing the SensorX 502 | 70 |
| Foaming | 70 |
| Washing | 71 |
| Sanitizing | 71 |
| Assembling After Sanitizing | 71 |
| Final Inspection | 71 |
| Special Cleaning Instructions | 72 |
| Electrical Parts and Diagrams for SensorX 502 | 75 |
| 6002449_G_1 | 76 |
| 2012-101-00002-02 | 116 |
| Appendix | 149 |
| Regulations and licenses | 149 |
| Glossary of Terms | 151 |
| Index | 153 |

Introduction

About This Manual

The *SensorX 502 System, User Manual* is intended to assist you in operating and maintaining the Marel SensorX 502 System.

SensorX 502 System are only sold and used in combination with SensorX, the Marel X-ray product inspection machine.

The manual is divided into the following main chapters:

- Introduction
- Installation
- Safety Instructions
- Operation
- Maintenance
- Cleaning
- Parts Lists – mechanical parts lists
- Electrical diagrams

| | REMARK |
|---|---|
|  | Before you start working on your SensorX 502 System, make sure you read and understand the warnings and the warranty agreement. |

| | REMARK |
|---|---|
|  | Images may differ slightly from customer's end product. |

Improvements and Customer Support

You can help improve this manual and the equipment you purchased. If you find errors in the manual, please let us know. You can contact us at: Marel Iceland ehf, Austurhraun 9, IS-210 Gardabaer, Iceland; phone (+354) 563-8000, fax (+354) 563-8001, attn. Documentation & Localization, email: documentation@marel.com.

For customer support please contact your local Marel service partner.
 For details see www.marel.com or Marel's Service Department, email: service@marel.com.

Warranty Information

For specific warranty information, please consult the written contract of the purchase.

| NOTICE | |
|---|--|
|  | Marel Iceland ehf does not warrant any equipment that has not been used according to specifications. |

About the SensorX 502 System




Figure 1 SensorX 502 system

Table 1 SensorX 502

| | | | |
|----------|-------------------------------|-----------|-----------------------------------|
| 1 | Infeed conveyor | 8 | Product tray |
| 2 | SensorX X-ray inspection unit | 9 | Rework Station |
| 3 | Outfeed conveyor and reject | 10 | Rework terminal (optional) |
| 4 | Return conveyor | 11 | Electrical cabinet for the system |

| | | | |
|----------|------------------------------|-----------|---|
| 5 | Elevating conveyor | 12 | Electrical cabinet inside the X-ray inspection unit |
| 6 | Overflow conveyor (optional) | 13 | SmartSort connection module (accessories) |
| 7 | Product tray conveyor | | |

Main Features and Naming Conventions

The SensorX 502 system consists of a number of standard modules which are combined with the SensorX 502 machine. Table 2 shows an overview of these modules. See also Figure 1 and Table 1 for reference.

Table 2 Main features

| Module: | Definition: |
|----------------|--------------------|
| 4 | Return conveyor |
| 5 | Elevating conveyor |
| 9 | Rework station |
| 10 | Rework terminal |
| 1 | Infeed conveyor |
| 6 | Overflow |

Operation

1. The operator or a infeed system feeds product on the infeed conveyor.
2. SensorX scans the product for bone and other hard contaminants.
3. The contaminant free products are then transported to the outfeed conveyor from where it goes to further processing.
If a contaminant is detected or the product is partially outside the scan area, then the product is rejected with the reject mechanism.
4. The rejected product then travels on the return conveyor to the elevating conveyor and then to the rework station, which is located on the infeed side of the SensorX inspection unit.
5. After the contaminant has been removed at the rework station, the product is sent back to the infeed conveyor to be scanned a second time by the SensorX. This is to verify that the operator succeeded in removing the contaminant.

About SensorX X-ray Inspection Unit

SensorX x-ray inspection unit uses X-ray technology to automatically detect foreign bodies in food products, and measure CL and weight.

When the SensorX x-ray inspection unit is installed, as part of a processing line, X-ray images of individual pieces and information on their bone content may be forwarded to a separate flowline.




Figure 2 SensorX x-ray inspection unit

Table 3 SensorX x-ray inspection unit main parts

| | | | |
|----------|---------------------------|----------|--|
| 1 | Front panel with computer | 4 | X-ray detector |
| 2 | Dehumidification unit | 5 | Motor |
| 3 | X-ray generator assembly | 6 | X-ray notification light (on the indicator beacon) |

Technical Specifications

Table 4 Technical data for the SensorX 502 System

| | |
|-----------------------------|--|
| Belt speed | 0.46 m/sec (102 feet/minute) for infeed and outfeed conveyors. Other conveyors may have slower speed settings depending on operational mode. |
| Power supply voltage | 3x400V + N + PE or 3x(208-230V) + PE |
| Power usage | See rating plate |

| | |
|---|---|
| Frequency | 50/60 Hz |
| Residual current circuit breaker | Type B, 500 mA |
| Dimensions | Variable x 1080 mm x 1930 mm (L x W x H) (Variable x 43 in x 76 in) |
| Belt width/length | |
| Infeed belt | Width 508 mm (20 in), length 5.6 m (220 in) |
| Outfeed belt | Width 2 x 254 mm (2 x 10 in), length 2 m (79 in) |
| Return belt | Width 508 mm (20 in) length 7.5 m (296 in) |
| Elevating belt | Width 406 mm (16 in) length 6.8 m (268 in) |
| X-Ray belt | Width 590 mm (20 in) length 6.4 m (252 in) |
| Weight | Approx. 700 kg (1544 lbs) |
| Noise level | <75 dB (A) |
| X-ray potential | 80kV |
| X-ray current | 10mA |
| X-ray duty cycle | 100% |
| Belt speed | |
| Infeed belt | 0.05 – 0,2 m/s (10- 39,4 ft/min) |
| Power supply voltage | Single phase 230 Vac + N + PE or 3x400V + N + PE or 3x(208-230V) + PE |
| Power usage | 1.1 Kw |
| Frequency | 50/60 Hz |
| Operating Temperature | 0 – 20° C (32°F – 68°F) |
| Dimensions | 5720 mm x 1270 mm x 1780 mm (L x W x H) (225 1/4 in x 50 in x 70 1/8 in) |
| Belt width | Infeed belt 457mm (18 in) Outfeed belt 590 mm (23 in) |
| Belt type/length | |
| Infeed Belt | L=10600 mm |
| Outfeed Belt | L= 6785 mm |
| Weight | Approx. 840 kg (1330 lb) |
| Noise level | <75dB(A) |

Transportation and Handling

Read the following transportation and handling instructions before you attempt to lift or transport the equipment. If you fail to follow these instructions, lifting or transporting the equipment may cause death or major personal injury, or serious damage to the SensorX 502.

- Observe the mass of the SensorX 502 before lifting or moving the equipment. The mass is stated on the rating plate which is located to the left of the electrical cabinet.
- If you use a forklift **3** or pallet jack **1** (Figure 3) for transportation, you should place logs **2** or other material on top of the forks in order to prevent corrosive scratches on the structural member. Always lift under the central construction.
- It is recommended to secure the SensorX on a forklift **3** when transporting the machine to a position on a higher level. To secure the machine on the forklift **3**, use the designated transportation holes **4** (Figure 3).
- Remove the transportation bracket after installation.

| REMARK | |
|----------|---|
| i | Never transport the machine with the X-ray generator installed. |




Figure 3 Transporting the SensorX with a pallet jack and forklift




Figure 4 Transporting the SensorX 502

Installation

Site Requirements

The location of the SensorX 502 is decided upon by the buyer and Marel, the following points are important when choosing proper location for the system:

- **Floor:** The SensorX 502 should be placed on an even and stable surface and bolted to the floor.
- **Environment:** The SensorX 502 should not be placed near doorways or where there is a traffic of people passing. Neither should the system be placed where there is draught, e.g. from a ceiling fan or in an environment where there are vibrations.
- **Accessibility:** There should be enough space around the system for easy cleaning and maintenance.
- **Temperature:** The room temperature must not get below 4 °C (39 °F)0° C (32° F).
- **Electricity:** 3 x 400V + N + PE or 3 x 208V - 230V + PE power supply must be available.
- **Air:** The air must be clean and dry and the local air pressure for the factory must be minimum 7 bar. For more details see "Pneumatic Installations" on page 11.
- **Ethernet:** Ethernet connection is necessary, for example for remote service support.

Verifying the Equipment

Before you install the SensorX 502, verify the following:

- Inspect the equipment for damages incurred during shipment, such as scratches or dents. If the equipment has been damaged, do not operate because of potential X-ray hazard. Report damages immediately to Marel or your local Marel representative to have our technical personnel attend to the problem.
- Compare the equipment you have received to the packing list to see if the shipment is complete. Report any discrepancies to your Marel agent.

Installing the SensorX 502

1. Position the SensorX 502 and other auxiliary equipment according to floor plans.
2. Adjust all legs under the modules so the system is level, length- and width-wise and to ensure a smooth transfer of raw material from the infeed unit to the SensorX 502.

| NOTICE | |
|---|--|
|  | Do not weld near the SensorX 502 System. If welding needs to be done, then it must be done by Marel personnel or under their instructions. |

3. Drill holes for the floor rods **2** that keep the SensorX 502 in place Figure 5.
If you are installing other units attached to the SensorX 502, position these as well and drill holes for the rods.

| NOTICE | |
|--|---|
|  | The customer is responsible that the SensorX 502 is securely fastened to the floor. |

4. Tighten the nut to the floor rod.




Figure 5 Floor leg

| | | | | | |
|---|------|---|-----------|---|-----|
| 1 | Nuts | 2 | Floor rod | 2 | Nut |
|---|------|---|-----------|---|-----|

5. Connect electrical, air. **1**, and water **2** supplies () .




Figure 6 Air 1 and water 2 intake

Electrical Installations

The SensorX 502 uses a 3-phase electrical supply:

- 3 x 400V + N + PE
- 3 x 208V - 230V + PE

The mains is to be terminated in the electrical cabinet. Refer to the Technical Reference Manual. The mains rating is listed on the rating plate on the electrical cabinets.

| NOTICE | |
|---|---|
|  | Make sure the motors turn the belt in the right direction after installation. If not, you must reverse the motors by changing the three-phase connection. |

Make sure to run the cables so they do not affect the function of the SensorX 502 or disturb workers on the line. Cables must never induce danger, electrical or mechanical, to the workers.

Termination of cables is done after all units in the installation have been put in their final position. Ensure that all conduits between units are tight.

| REMARK | |
|---|---|
|  | Do not attach cable ladders or such to the machine. Drilling holes in certain parts of the machine may cause excessive radiation leakage. |

| REMARK | |
|---|---|
|  | Electrical installations are to be performed by a licensed electrician only in accordance with manufacturer's specifications and national and local electrical codes. |

Pneumatic Installations

Compressed air is used to operate air cylinders on the SensorX 502. The SensorX 502 requires a supply of clean and dry air according to ISO standard 8573-1 class 3 (see Table 5).

Table 5 Quality of compressed air

ISO 8573-1

| Class | Solids | | Water | Oil |
|--------------|-----------------------------|---|----------------------------------|---------------------------------------|
| | Particle size max µm | Concentration maximum mg/m³ | Max Pressure Dew point °C | Concentration mg/m³ |
| 1 | 0.1 | 0.1 | - 70 | 0.01 |
| 2 | 1 | 1 | - 40 | 0.1 |
| 3 | 5 | 5 | - 20 | 1 |
| 4 | 15 | 8 | + 3 | 5 |
| 5 | 40 | 10 | + 7 | 25 |
| 6 | - | - | + 10 | - |
| 7 | - | - | Not Specified | - |

Pressure dew point is the temperature to which compressed air must be cooled before water vapor in the air starts to condense into water particles.

Recommended local air pressure is minimum 7 bar. Pressure below the recommended 7 bar will noticeably affect the operating speed of the system at full flow while pressure above 10 bar may damage the equipment. An Alarm shows and the machine stops if it is below 6 bars.

1. Make sure the air supply plumbing is clean before you connect the machine.
2. Set the operating air pressure at 6 bar (85-87 Psi) by adjusting the air regulator in the air cabinet.

| NOTICE | |
|---|---|
|  | The lifespan of air valves and cylinders is affected by the quality of the air supplied. It is therefore important that you only use clean and dry air. |

Ethernet Connection

It is important that network cables are not drawn next to electrical power cables. Carefully prepare all network cable connections to prevent unstable network operations.

Check List

Use this check list for the initial start of the SensorX 502.

- The power outlet matches the power intake as specified on the rating plate.
- All unused cable glands in the electrical cabinet are sealed.
- The electrical cabinet is dry and no moisture can get in.
If the cabinet is damp, check the heaters and cable glands.
- There are no loose objects, for example tools, lying on the belts.
- The belt quality is in order; no sticking links or dirt that can hinder the belt from moving freely.
- Check ambient air temperature and make sure it is within limits.
- Check air quality.
- Make sure that all belts sit properly and evenly.

Safety Instructions

In General

The SensorX 502 is not a dangerous piece of equipment but appropriate operating procedures must be followed. To avoid personal injury or damage to the machine take care of the following:

- **Electricity**

The power must be turned off before any electrical work is performed.

- **Frames**


Do not put your hands through frame holes near motors or any moving parts. Fingers may get crushed.

- **Conveyor ends**

Do not place your hands under the belts, especially not near the rollers at the conveyor ends.

- **Cover on outfeed unit (1) and overflow conveyor (2)(see Figure 1)**

During operation, the cover must always be closed.



| | REMARK |
|---|--|
|  | During operation of the SensorX care should be taken to prevent accidents. |




Figure 7 Potential hazard areas

- Entrance/exit openings**

Because of possible X-ray radiation, do not put your hand inside the entrance/exit openings. Warning signs are placed on the openings.

- The safety covers (conveyor and motor covers)**

Always turn the X-ray off before open the safety covers. Always open and close the covers with care. Do not slam down the covers.

| | NOTICE |
|---|---|
|  | The conveyor cover on SensorX has gas springs to prevent it from slamming down violently. If these gas springs are missing or starting to lose pressure, make sure to replace them to minimize the risk of accidents. |

- Air cylinders**

Use extreme caution while adjusting the air cylinders with air pressure and power on the unit. Always stop the belt before adjusting the cylinders.

- Cleaning main display**

Before you start cleaning the display, press the emergency stop button to prevent an accidental start of the conveyor

- Installation**

Do not attach cable ladders or such to the machine. Drilling holes in certain parts of the machine may cause excessive radiation leakage.

Safety Arrangements

Warning Labels

The SensorX 502 system is supplied with the following warning labels:



X-RAY RADIATION

Potential X-ray hazard. Placed on the front panel cover and on entrance/exit openings.



ELECTRICAL HAZARD

Placed on the front panel cover.



CRUSH HAZARD

Danger of personal injury caused by pressure.



CRUSH HAZARD

Danger of personal injury caused by rotating parts.




Figure 8 Warning labels on SmartSort connection module on SensorX

Do Not

Although the SensorX 502 has been designed and constructed with the highest level of safety in mind, it is very important to emphasize that proper use is the most important factor in a safe and trouble-free operation. Therefore:

- **Do not** use the unit without authorization. You may need special permission from local radiation protection authorities to operate the machine.
- **Do not** extend any part of your body into any openings on the unit while X-ray generation and scanning is in progress.
- If raw material is stuck in the unit, turn the X-rays OFF momentarily, open the conveyor compartment, and attend to the problem safely.
- **Do not** open the safety cover on the outfeed of the SensorX during production.
- **Do not** attempt to remove the test block (from the outfeed of the SenosrX) before it lands in the bin or on the belt because you may pinch your hand in the reject .
- **Do not** insert your hand in the safety cover's opening or other openings.
- **Do not** disconnect electrical power from the unit until at least 15 minutes after it has been stopped. This allows the internal cooling fans to remove heat from the X-ray generator after the generator has been turned OFF.

Radiological Safety Procedures and Precautions

SensorX 502 is designed with the utmost safety in mind when it comes to possible X-ray radiation shielding.

The unit is supplied with numerous safety features to ensure that X-ray generation is not initiated unless all required conditions are met.

The X-ray cabinet is made of stainless steel, adequate in thickness to prevent any radiation leakage. The entrance and exit openings are designed to allow only a minimum amount of leakage radiation. This leakage radiation is under limits given by radiation protection authorities. Any cover that has a radiological protection function is sensed so operation is not possible with the cover open.

Safety Function

The safety functions of the machine helps preventing harm caused by generation of x-rays or mechanical force/movement.

There are few types of safety functions on the machine:

Emergency switch

- Located by main control display

Key switch

- Located by main control display

X-ray notification light

- Located on top of the machine shown
- **Green** when X-ray generator is ready to be started
- **Yellow** while X-ray generator is starting up
- **Red** when X-ray generation is active

Lockout switch

- Disconnects the motor power, the x-ray and the pneumatic air, but still leaves a 24V current on the main display.

Safety sensors on openings

- See - Figure 12.

If any safety function is activated the relevant risk is prevented by safety stop. There are two different levels of safety stop defined, or **safety zones**:

X-ray generator



- Stopped when any Safety door is opened
- Stopped when any Emergency switch is pushed
- Stopped if key switch is not **ON**

Conveyors

- Stopped when any Emergency switch is pushed
- Some are stopped if a relevant Safety door is opened

If any safety function is activated (Safety Door opened or Emergency switch pushed) the relevant switch must be reset by closing the relevant door or pulling out the relevant emergency stop.

Then the machine can be started up again.

Positions of the Safety sensors**Figure 9 Safety sensor for the opening of the safety covers****Figure 10 Safety sensor for the motor cover**




Figure 11 Safety sensor for the inlet removal




Figure 12 Safety sensor on the cover of the SensorX generator




Figure 13 Safety sensor for the opening of the safety covers on SmartSort connection module

Emergency Stop Buttons

On the SensorX 502 system the emergency stop button is located on the front panel of the SensorX machine and by the rework stations.

When the emergency stop is activated, all activity on the system stops immediately.

See "Alarm Page".

- To start the system again after an emergency stop, pull out the emergency stop button, and tap the Start button on the touch screen.




Figure 14 Location of emergency stop buttons

Operation

In General

This chapter describes how to operate the SensorX 502.

| | REMARK |
|----------|--|
| i | Marel recommends that you always leave the mains switch ON during production breaks and off-periods. This keeps the unit's internal temperature control active and prevents variations in temperature, which is one of the factors that can affect the unit's performance. |

Controls and Indicators

This section describes the location and use of basic controls and indicator lights on the SensorX 502.

The Mains switch and the Lockout switch are located on the right side of the SensorX x-ray inspection unit.

Figure 15 shows the position of the controls and indicators, and Table 6 provides their description.




Figure 15 Positions of the control and indicators

Table 6 SensorX 502 system, basic controls and indicators

| Number: | Name: | Description: | | | | |
|---------------|--|---|---------------|--|--|--|
| 1 | SensorX main display and touch screen | Controls the SensorX 502 System. Displays X-ray images and provides the user interface for operating, calibrating, and adjusting various parameters. | | | | |
| 2 | Emergency stop button | Instantly stops all operation of the system, including the conveyor belt and X-ray radiation. You cannot start the system again, unless you pull this button out first and reset the safety circuit. | | | | |
| 3 | X-ray Key lock | Turn this key to Enabled position to allow X-ray radiation. The key cannot be removed in the Enabled position. Turning the key to Disabled position terminates X-ray radiation. | | | | |
| | | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">REMARK</th> </tr> </thead> <tbody> <tr> <td style="text-align: center; vertical-align: middle;"> </td><td style="text-align: left; padding-left: 10px;">Remove the key to prevent unauthorized operation of the machine.</td></tr> </tbody> </table> | REMARK | | | Remove the key to prevent unauthorized operation of the machine. |
| REMARK | | | | | | |
| | Remove the key to prevent unauthorized operation of the machine. | | | | | |
| 4 | Power ON | Power On indicator, illuminates green when the SensorX Main display is powered ON. | | | | |

| | | |
|-----------|---|---|
| 5 | Reset button (under the front panel) | Resets the computer. |
| 6 | X-ray notification light (on the indicator beacon) | Alarm lamp. The lamp is connected to the X-ray generator controller and is constantly illuminated red when the X-ray generator emits radiation. The lamp is green when X-rays can be generated and yellow when the radiation is about to start. Located on top of the SensorX machine. |
| 7 | Lockout switch | Disconnects the motor power, the x-ray and the pneumatic air, but still leaves a 24V current on the main display. A lockout padlock can be placed on this switch, if needed. |
| 8 | Mains switch | Breaker. Disconnects the mains power supply to the system. |
| 9 | Rework terminal (optional) | Displays X-ray images of contaminated products so the operator can locate and remove the contaminant fast and easily. |
| 10 | Trim table backlight adjustment button | Allows the operator to set the light, gradually, from off to full brightness. |
| 11 | Confirmation knife detector (optional) | Button, used to confirm rework of piece. Triggers the display of an image. |
| 12 | Confirmation button (optional) | Button, used to confirm rework of piece. Triggers the display of an image. |

User Interface

The following sections describe the SensorX user interface.

The user interface, which is displayed on the SensorX inspection units main display, is designed for the operator and an administrator, people who are normally responsible for the daily operation of the unit.

After power on, the SensorX Main screen appears on the controller.

The Main Production Screen




Figure 16 SensorX, Main production screen

- X-ray indicator.** Shows when the X-ray generator is running.
 - It is red when the generator is radiating
- Status.** Displays the status of the SensorX system: For example, Running, Stopped and Warming up.
- Alarms.** Tap here to get an overview of alarms (warnings or errors) on the system.
- Language.** Tap here to select a language for the user interface.
- Login.** Displays the login screen, where you can switch roles to access other sections and you may need to provide a password.
- Information.** Displays details on scanned material.
- Program list.** Displays the Programs screen.

8. **Start/Stop button.** Starts and stops X-ray generation and all conveyors in the system.
Turns the X-ray generator and the conveyor belt ON and OFF. If there is a fault on the X-ray and it does not start, then the belt does not start.

| | REMARK |
|---|---|
|  | The belt and X-ray can be started individually in the X-ray diagnostics page (accessed from the Advanced Screen). |

9. **Exit.** Exits this screen and displays the login screen.

Alarm Page




Figure 17 The Alarm page

The Alarm page gives you an overview of alarms (warnings or errors) on the system:

- The Alarm page gives you information. If you tap the Alarm log button, then you get the alarm log.
- If the system is still operational but you receive a warning, you need to check the alarm page for a solution.
- If you get an alarm, the system will not work. An example of an alarm is when the covers on the SensorX inspection unit are not closed. Figure 17 shows an example of what happens when the covers are left open. It shows which covers are open, and you are instructed on how to proceed.

Information Screen




Figure 18 Information Screen

Here you can monitor the product flow through the inspection unit

The information page shows statistics for each lane as well as images of products that are being scanned.

It shows the amount of bones and the weight (if your SensorX x-ray inspection unit weighs the pieces).

The information page shows the statistics as well as images of products that are being scanned.

Programs Screen

Tap the **Programs** button  on the Main Production screen to access the Programs screen.




Figure 19 The Programs screen

In the Programs screen shown in Figure 19 you have three default programs to select from:

- Small size
- Medium size
- Large size

Tap the **Check** button  to confirm the selection.

| | REMARK |
|---|---|
|  | The most sensitive of the default programs is the Small size program. It detects smaller bones in a product than the Large or Medium size programs. |

Marel service personnel custom-makes a program to suit your production needs and adjusts the detection sensitivity accordingly. For instance, more than three programs can be added. The customized programs are named as per your preferences.

The Login Screen



Figure 20 The Login screen

The login screen is used to access different parts of the user interface and it depends on your role as an operator which parts you can access.

In the Login screen, you can see four buttons:

1. **Production button.** Contains the Main Production Screen for operating the machine
2. **Cleaning button.** Contains screen for cleaning the machine
3. **Advanced button.** Contains screens with advanced features for administrative use.
4. **Service button.** Contains screens for servicing the machine, such as the settings screens

| REMARK | |
|---------------|---|
| i | The Service screen is locked with a password and is only for Marel service personnel. |

Cleaning

When you put the system in washing mode, X-ray generation is turned off and all conveyors run slowly.

To activate washing mode (see Figure 21):

- Tap the Start button **1**. A confirmation dialog box is displayed.




Figure 21 The Washing screen

| | REMARK |
|----------|---|
| i | You must leave the lockout switch in OFF position if you want the conveyors to run in washing mode. |

Advanced Screen

Figure 22 The Advanced screen

From the Advanced screen you can access several other system screens.

1. X-ray Diagnostics button. Displays the X-ray Diagnostics screen.
2. Hardware Monitor button . Displays the Hardware Monitor screen.
3. Service web button.
4. Emergency Mode button.
5. Weighing calibration button (Only shown if your machine has the weighing option).
6. Machine setup button (not always in use).
7. CL Measurements button (not always in use).

X-Ray Diagnostics




Figure 23 X-Ray Diagnostics screen

The X-Ray Diagnostics screen is for monitoring, testing and other various actions.

- Under normal circumstances when signal type id set to calibrated the signal level should be approximately 95% when the x-ray is fully on and no product is running through the machine.

- You can turn on and off the X-ray from this screen by tapping 

- You can turn on and off the SensorX inspection units belt by tapping 

- You gain calibrate from this screen. See "Gain Calibration".

Gain Calibration

The machine should be gain calibrated during production breaks:

1. Go to the Advanced Screen.



2. Tap the X-ray diagnostics button.
3. Tap the Gain Calibration button.




Figure 24 X-ray diagnostics screen

| | REMARK |
|---|--|
| i | Make sure that no product is on the belt when performing this operation. |

Hardware Monitor Screen



Figure 25 The Hardware Monitor screen

The Hardware Monitor screen provides an overview of system status. An image of the system is displayed with the following status indicators:

Colored bullet for **all motors** that are equipped with an encoder.

- Gray: the motor is stopped.
- Red: the ticker is not incrementing.
- Green: the ticker is incrementing.

Colored bullet for **all product sensors**.

- Yellow: the product sensor is blocked.
- Green: the sensor is not blocked.

Colored bullet for **all buttons**.

- Yellow: the button has been tapped.
- Green: the button is not tapped.

| REMARK | |
|---------------|---|
| i | If you click a bullet in the Hardware Monitor screen image, a text box is displayed with the bullet's name. |

Emergency Mode

If the SensorX 502 machine cannot be operated, a feature called the Emergency Mode can be activated.

- For example, if the x-ray generator does not run.

The machine works like a conveyor in the Emergency Mode.

- The belts run
- The reject is forced to close

To activate Emergency mode:

1. Enter the **Login** Screen.
2. Tap the **Advanced page** button.
3. In the Advanced Screen, tap **The Emergency Mode button**, see Figure 26.



Figure 26 The Advanced screen

| | REMARK |
|--|--|
| | It is only possible to tap the Emergency Mode button when the x-ray generator is turned OFF . |




Figure 27 The Emergency Mode page

4. To enable the Emergency Mode tap the start button, see Figure 27. A message window appears.



Figure 28 Message box to enable the Emergency Mode

5. Tap the OK button to start the Emergency Mode. If you do not want to start Emergency Mode tap the  button, see Figure 28.

When the system is running in Emergency Mode the page looks like Figure 29 to stop the Emergency Mode either stop the belts or leave the Emergency Mode page.




Figure 29 The Emergency Mode page with Emergency Mode active

When the machine is in Emergency Mode the Alarm Page should look like is shown in Figure 30.



Figure 30 The alarm page with the Emergency Mode enabled

Weighing Calibration Procedure

This procedure takes a step-by-step approach at calibrating the weighing function of the SensorX x-ray inspection unit. While every customer has different requirements for the frequency of this calibration, it is suggested that it is done weekly to ensure continued accuracy.

You need:

- Access to the machine during non-production time
- 5-20 pieces of product, exactly as it would normally pass through the machine
- A scale, to weigh the products

| | REMARK |
|---|--|
|  | The X-ray should be allowed to run for at least one hour, so that the temperature can rise to a normal use temperature. If the X-ray is currently OFF, it can be turned ON through the X-ray Diagnostics utility 1 found in the Advanced tab see Figure 31. |




Figure 31 X-ray Diagnostics

1. Once the machine has been allowed sufficient warm-up time, you need to perform a gain calibration **2** to optimize the signal level. See "Gain Calibration".
2. Use the back button **3** to return to the Advanced screen.
3. Select the **Weighing Calibration** utility located in the Advanced screen (see Figure 32).



Figure 32 Weighing calibration button

4. The Weighing Calibration screen is displayed, and you get instructions on how to complete the calibration.
5. Weigh all the pieces of product that are going to be used for calibration. The weight should be recorded in grams, kilograms or pounds, and each piece should be weighed separately.
6. Once this has been accomplished, begin running the product through the machined one piece at a time.




Figure 33 SensorX weighing calibration procedure

7. As each piece passes through the machine, the data gathered is displayed on this screen. By touching the box to the right of the Reference Weight, you are prompted to enter the actual weight of that piece.

| REMARK | |
|---------------|---|
| i | If a mistake is made and you wish to disregard the data for a piece scanned, you can tap the check box under Use point for calibration , to clear the box. |

8. After passing at least 5 pieces of product through the machine and inputting the weights of each piece, you are able to complete the calibration by selecting the **Finish** button in the lower right.

9. A message is displayed that states that the Weight calibration was successful.



Figure 34 Successful weighing calibration

10. You can return back to the **Login** page and go to the **Main production info** screen.

11. In the Information Screen (For more information, see "Information Screen" on page 28.), you can now check the accuracy of your calibration.

| | REMARK |
|----------|---|
| i | Keep in mind that the more pieces of product you use to calibrate, the more accurate your calculated weight is during production. |

Rework System

The rework system consists of a return conveyor, elevating conveyor and two rework stations, each with a work area and an optional rework terminal.




Figure 35 Rework system

| | | | |
|----------|-------------------|----------|----------------------------|
| 1 | Overflow conveyor | 4 | Work area table |
| 2 | Overflow tray | 5 | Rework terminal (optional) |
| 3 | Product bin | 6 | Elevating conveyor |

The return conveyor and the elevating conveyor transfer a rejected product from the SensorX machine to the product bin. The product bin should only contain one product each time.

Rework terminal

When a piece of product is in the product bin and the operator presses the confirmation button (located below the terminal), an image of the product is displayed on the rework terminal. It makes the removal of the contaminant easier.




Figure 36 Rework terminal

Figure 36 shows an example of the front page on the rework terminal when the operation is in working order.

The return and elevating conveyors run continuously until a piece arrives in the bin, when the product bin is empty.

When a piece enters the product bin, the elevating conveyor stops running continuously and starts buffering incoming pieces.

If the product bin is not emptied and the elevating conveyor buffer is full, then the following pieces go to the overflow tray.

The system allots one piece of product to the product bin every time the confirmation button is pressed. The system optimizes the buffering resources before it diverts pieces to the overflow.




Figure 37 Alarm page on rework terminal

If there is a problem with the connection between the SensorX x-ray inspection unit and the rework station, then the Alarm page appears Figure 37, with instructions on how to proceed.

Overflow Mechanism

The overflow mechanism is used to reject pieces that arrive at the product bin but cannot be handled in a normal fashion (e.g. if they could not be tracked).

A piece that enters the rework station when the product bin is full is sent to the overflow.

If two pieces are insufficiently separated on the conveyor belt, both pieces are put to overflow in order to avoid a situation with two pieces in the bin and no way of knowing which image belongs to which piece.

Similarly, a piece is put to overflow if no image is available for it or if the tracking of the piece is incorrect, for example, if the piece has been moved.

| REMARK | |
|---------------|---|
| i | Monitor the amount of product going to the overflow tray. Optimally, the bulk of the rejected product should go to the product bin. |




Figure 38 Overflow conveyor in closed position




Figure 39 Overflow conveyor in open position

The conveyor **1** opens in horizontal direction.

Operation Procedures

Before Operation

1. Check the interface for the Power on indicator to see if the machine is powered on. If the indicator is OFF, turn the Main switch to **ON**.
2. If the machine was OFF, then it needs to warmup for at least **30 minutes** before operation.
3. Make sure that the product area above and under the conveyor are as dry as possible and without visible wet spots. Wipe upper and lower plastic strips **1** conveyor belt **2** and the grids **3**, shown in (Figure 40). Large drops of water diminish the radiation intensity and affect image acquisition.
4. Install the conveyor belt and put the grids in their proper places.




Figure 40 Wipe off the strips

5. Close the conveyor and motor covers, insert and turn the X-ray key to enable position.
6. Tap the green Start/Stop button  on the Main screen to start X-ray generation and the belt and let the x-ray warm up for at least 30 minutes.
7. The machine should then be **Gain calibrated**. It is critical that no product is scanned during gain calibration.
8. Once the machine has changed the state from **Warm up** to **Running** state, select **Gain calibrate**. For more information, see "Gain Calibration" on page 34..

Perform routine quality checks, for example, with a poultry machine: Run a test block **1** twice through the SensorX, either before production or any time when there is a production break.

1. Select the appropriate program for the product to be processed. See "Programs Screen".




Figure 41 The test procedures

2. Check if the test was successful: the SensorX screen shows two bones in the block (see Figure 42).




Figure 42 Successful block test

3. Never remove the test block **3** from the outfeed conveyor **1**. The safety cover **2** can not be open. You should manually remove the test block **3** from the return conveyor **4** and with the safety cover **2** closed. Remove the test block when the reject has come to a closed position. If the reject fails, then you should remove the test block at the end of the outfeed conveyor (when it has gone through the safety cover). See Figure 43 and Figure 44.
4. The machine is now ready for operation.




Figure 43 Incorrect position of the safety cover




Figure 44 Correct position of the safety cover

| | | | |
|---|------------------|---|-----------------|
| 1 | Outfeed conveyor | 3 | Test block |
| 2 | Safety cover | 4 | Return conveyor |

| NOTICE | |
|--------|--|
| | Do not attempt to remove the test block before it lands in the bin or on the belt because you may pinch your hand in the reject. |

| | REMARK |
|---|---|
|  | If the results are not as expected, contact your local Marel service personnel. |

During Operation

1. You must monitor and make sure that the pieces are separated and their location on the belt must be correct. You can monitor the infeed from the Main Production Screen and from the Information Screen. See "The Main Production Screen", and For more information, see "Information Screen" on page 28..
2. Calibrate the machine during production breaks (For more information, see "Gain Calibration" on page 34.).
3. If the product type changes, you may want to switch to another program.
4. As the pieces become thicker and/or larger, the scope of the X-ray beam narrows. Therefore, make sure the pieces are correctly positioned. The X-ray beam is 500 mm (21 in) wide when it is 25 mm above the conveyor belt.




Figure 45 X-ray beam ranges

5. You must search and remove bones, and then rescan the product that has been diverted to the contaminants gate.




Figure 46 Positioning raw material in the product range

Table 7 Individual machine parts where raw material is positioned on the SensorX

| | | | |
|----------|-----------------------|----------|-------------------|
| 1 | Product range | 4 | Raw material |
| 2 | Product out-of-bounds | 5 | Running direction |
| 3 | Infeed belt | | |

| | REMARK |
|---|--|
|  | A bone in the out-of-bounds area will not be detected and the piece goes through the machine as a bone-free piece. However, the machine has the option to reject pieces that go in the out-of-bounds area. Contact your local Marel representative for your preferred settings. |

After Operation

1. Tap the Start/Stop button on the Main display to shut down X-ray radiation and the belt.
2. Remove the X-ray key to prevent unauthorized operation.
3. Leave power on the machine.
4. Put the machine in washing mode before cleaning.

| REMARK | |
|---|---|
|  | When you leave SensorX 502 connected to electrical power, you should always remove the key from the X-ray lock. Store the key in a safe place to prevent unauthorized operation of the unit. |

We recommend that you always leave SensorX 502 powered ON during production breaks and off-periods. This keeps the unit's internal temperature control active and prevents variations in temperature, one of the factors that can affect the unit's performance.

During cleaning the Mains switch should be ON. The safety functionality remains activated in Washing mode so opening covers and pressing emergency stop will work as expected.

Leave the Lockout switch in ON position (like in normal operation) if you need to run the belts but make sure covers are closed. If you need to remove the belts, rollers or disassemble any parts of the system it is recommended that the machine is locked out by putting the Lockout switch in OFF position.

Troubleshooting

This section describes unexpected scenarios that may occur and how you should react.

Table 8 Troubleshooting

| Description: | Action: |
|---|---|
| X-ray generator does not start | Make sure all safety devices are in a proper state. Use Alarm screen. |
| Diminished contaminant detection/CL-measurement accuracy or weight | Make sure the SensorX 502 machine is warmed up and gain calibrated with no material on belt. Make sure the plastic strips above and below the conveyor belt inside the SensorX 502 are clean and dry. Make sure to clean belts that have collected much dirt. |
| Diminished bone detection accuracy | The unit may need calibration. Also, make sure the plastic strips above and below the conveyor belt inside the unit are clean and dry. If the belt has collected much dirt, clean the belt and adjust the scraper. |
| Defect reject mechanism | Check if the air supply to the reject mechanism is in order. |
| Other problems | Power OFF the machine, and then turn the power ON again after 60 seconds. This resets all software components. If all fails, contact your local SensorX 502 representative to have our technical personnel attend to the problem. |

Maintenance

General Instructions

This chapter describes preventive maintenance of the SensorX 502 and various adjustments that may have to be made to the machine.

In order to ensure optimal performance and maximum lifespan for SensorX 502, the following should be maintained:

- Keep the SensorX 502 clean.
- Keep the mains breaker on at all times. Normally, do not unplug the machine as this shuts off the thermostat in the electrical cabinet and moisture may condense in the stainless steel cabinet.
- Keep the water nozzles clean. Check the nozzle every 40 working hours.

The conveyor belt on the SensorX 502 requires continuous monitoring. The belt soaks up particles from the raw material and darkens after being in use for a while. Therefore:

- Clean the belt carefully (see page 72 for more details).
- Replace the belt when necessary.
- Check if perforations are in order.

Maintenance Schedule

This chapter describes preventive maintenance of the SensorX 502 and various adjustments that may have to be made.

Table 9 contains the maintenance schedule for the system.

Table 9 Maintenance schedule

| | |
|----------------------------------|---|
| Every 40 operating hours: | <ul style="list-style-type: none"> Check the water nozzle, if used. |
| Daily: | <ul style="list-style-type: none"> Check motor and belts for abnormal noise or oil leak. Check that the conveyor belts are clean and free of dirt particles. Replace the belts, if necessary. Check that all product sensors are clean and correctly positioned. Clean the SensorX 502 System. Inspect the water ventilator daily to make sure it is operating normally. |
| Weekly: | <ul style="list-style-type: none"> Check the drum motors for abnormal noise. Check the general condition of the belts. Make sure the steel safety switches on the safety covers are in order. Make sure the emergency stop is in order. Check the condition of the cooling fan filter and replace if necessary. Check the condition on belt rollers and bushings. Replace if necessary. Check all air cylinders. Wipe cylinder piston rods with an oiled cloth at the end of the work week. |
| Monthly: | <ul style="list-style-type: none"> Check the emergency stops. Check the sprockets for wear. Check the belt tension. Check the belt supports for wear. Remove and wash the plastic modular belts. |
| Every six months: | <ul style="list-style-type: none"> Biannual service performed by Marel service personnel. |

| | |
|---|---|
| Beginning of every working shift | <ul style="list-style-type: none"> Check all belts to make sure they are in the right place. Check whether the weighing bins are properly mounted and lids are able to move without friction Check whether the side guards are in upright position. |
| Every working shift: | <ul style="list-style-type: none"> Check for broken links in the plastic modular belt. Check if all bins are properly positioned and firmly in place. |
| Daily: | <ul style="list-style-type: none"> Check motors and belts for abnormal noise. Check that the conveyor belts are clean and free of dirt particles. Replace the belts, if necessary. Check the movement, both horizontally and vertically of the gate arms. The movement should be easy and with no friction. Clean the system. |
| Weekly: | <ul style="list-style-type: none"> Check the idle end for abnormal noise. Check the general condition of the belts. Check all air cylinders. Wipe the cylinder piston rods with an oiled cloth at the end of the work week. Check the function and state of the gate arms. |
| Monthly: | <ul style="list-style-type: none"> Check the emergency stops. Check the sprockets for wear. Check the belt tension. Check the belt supports for wear. Check the bushings of the idle end sprockets (discharge unit). Remove and wash the plastic modular belts. |
| Every six months: | <ul style="list-style-type: none"> Biannual service performed by Marel service personnel. Inspection of the load cell(s) and the pneumatic and electrical system. Check the calibration on the SensorX25 |
| After 10.000 operating hours: | <ul style="list-style-type: none"> Change the oil in gear motors. |

Maintenance Procedures

Procedures for maintaining individual parts of the SensorX 502 are described in the following.

Pneumatic System

To operate properly, the system requires a constant level of air pressure. This is best achieved by setting the pressure to the recommended level while the unit is running (see " Pneumatic Installations" on page 8).

If you increase the air pressure after the air cylinders have been adjusted, the cylinders move faster and the shock is harder. If the pressure is decreased, the opposite happens, a slower and softer cylinder movement.

The water trap in the air cabinet (see Figure 47) is equipped with an automatic water ventilator.




Figure 47 Air cabinet, air pressure regulator

To maintain the pneumatic system:

- Inspect the water ventilator daily to make sure it is operating normally.
- Replace the filter in the water trap when dirty.
- Keep the operating air pressure at 7 bar.

Air Cylinders

To ensure the duration of the air cylinders, the following maintenance procedure should be implemented at the end of every week or whenever the SensorX 502 is inactive for more than a day.

To maintain the air cylinders:

- After the SensorX 502 has been cleaned and shut down, wipe the piston rod in every air cylinder with an oiled cloth.

To replace and adjust the air cylinders:

WARNING

Use extreme caution while adjusting the air cylinders with air pressure and power on the unit. Always stop the belt before adjusting the cylinders.

Due to wear an air cylinder may have to be replaced from time to time. In that case, note the following:

- Always stop the belt before adjusting the cylinders.
- After replacing a cylinder, you must adjust it. Before you do, make sure the air pressure for the unit is at the correct level.
- After the cylinder has been replaced, make sure the piston does not knock against the enclosure.
 - Adjust the shock absorbing mechanism in the cylinder by turning the small adjustment screws on both ends of the cylinder (see Figure 48, **B** and **D**).




Figure 48 Adjusting the shock mechanism

A=speed adjustment screw, **in** movement

B=shock absorbing adjustment screw, **in** movement

C=speed adjustment screw, **out** movement

D=shock absorbing adjustment screw, **out** movement

E=piston length, adjustment screw

F,G=bolt connection

H=ball joint eye

- Make sure the bolt connection **F** (to the frame) has room to rotate.
- Tighten bolt connection **G** (to the gate arm). If a plastic ball joint eye **H** without a steel insert is used, do not fasten the bolt too tightly. Steel ball joint eyes, however, should be tightened firmly.
- Check the operation of the cylinders

To adjust air cylinder speed and buffer cushioning:

- Always stop the belt before adjusting the cylinders.
- To adjust the **out** speed of the piston rod, adjust the speed adjustment screw at the front end of the cylinder (see Figure 48, **C**).
- To adjust the **in** speed of the piston rod, adjust the speed adjustment screw at the rear end of the cylinder (see Figure 48, **A**).
- The speed of the cylinders has to be the same as the belt. When the cylinder opens in the same direction as the running direction of the belt, the cylinder has to close faster than the belt speed (this applies only to the reject on the outfeed unit).




Figure 49 Cylinder and flipper plate

| | |
|----------|---|
| 1 | Cylinder and flipper plate in open position |
| 2 | Cylinder and flipper plate in closed position |

When the right piston speed has been reached, you must adjust the cylinder's buffer cushioning. The cushioning is to minimize the effect of the shock on the equipment when the reject stops abruptly:

1. Adjust the cushioning for the **out** movement with the adjustment screw (see Figure 48, **D**). Turn the screw clockwise to increase the cushioning effect, counterclockwise to decrease the effect.
2. Adjust the cushioning for the **in** movement with the adjustment screw (see Figure 48, **B**). Turn the screw clockwise to increase the cushioning effect, counterclockwise to decrease the effect.

Product Sensors (Only on Rework Terminals)

The product sensors are located on the return conveyor and the elevating conveyor.

Do not allow dirt to build up on or around the sensors. The sensor consists of a light transmitter and receiver. Both parts of the sensor and the entire area between them must be kept clean at all times, or else the light beam may be interrupted.

If the product sensor needs to be replaced, you must adjust the light beam.

To adjust the light beam:

1. Set the height of the light beam across the belt to approximately 5-10 mm (0.2-0.4 in) above the belt.

This is to make sure that a small build-up of dirt and the like on the conveyor belt does not interrupt the light beam.




Figure 50 Adjusting the light beam

| | | | | | |
|----------|-----------|----------|--------|----------|-------------|
| 1 | Belt | 3 | Wedge | 5 | Sensor |
| 2 | Direction | 4 | Sensor | 6 | Beam height |

2. Adjust the light beam. Use, for example, a small wedge-shaped piece of cardboard: Place the wedge in front of the light beam, and check when the beam is interrupted. The height of the light beam can now be measured as the height of the wedge where it crosses the light beam.
3. Check the height from both sides of the belt and from the center.

Belt on SensorX X-Ray Inspection Unit

Remove the belt from the machine for cleaning. Remove the tensioning roller and the scraper.

Check the perforation along the belt's edges for wear. If the holes are worn **2**, the belt **3** should be replaced (see Figure 51).




Figure 51 Wear in belt perforation

Table 10

| | | | | | |
|----------|-------------|----------|-----------|----------|------|
| 1 | Normal hole | 2 | Worn hole | 3 | Belt |
|----------|-------------|----------|-----------|----------|------|

Belts on the System Conveyors

It is very important that the belts on the SensorX 502 system are well maintained.

NOTE

A broken link or section in a belt presents danger to both equipment and operators. If the broken section is caught on something, a large section of the belt will be torn up, causing downtime and expensive belt replacement.

- Check the belts for broken sections or links at regular intervals.
- It is very important for proper operation that the links in the belts do not stick and thus prevent the belts from rotating smoothly on the sprocket wheels.
- Make sure that all belts are centered.
- Store your spare belts away from dust and other debris.

- If you need to replace the belt, follow the instructions in the belt manufacturer's instructions delivered with the equipment and be sure to check the quality of the belt as described below.

Belt Quality

It is important to check the quality of the belt at regular intervals:

1. Look for sticking rods and for dirt that makes the links stiff. In case some of the links are stiff because of dirt, clean the belt more thoroughly, or replace the stiff links with new ones.
2. Make sure the rods have not been damaged by tools, for example screwdrivers or pliers.
3. Before installing a new belt, place it on a bench, pick up one link at a time, and bend the link back and forth to check if it moves freely.

Belt Tension

It is important to keep proper belt tension in order to prevent the belt from slipping on the drive sprockets. All belts should be adjusted to have a proper "sag".

A new belt loses tension relatively fast, and therefore it is often necessary to remove a link from the belt after few weeks of use.

The conveyor belt expands and contracts, for example due to external factors such as changes in temperature, which makes it necessary to accommodate the change in the belt length. This is done by providing one or more unsupported sections on the belt's return side (underside) where the belt may sag. Here, the unsupported section of the belt hangs under its own weight, providing the extra belt length.

NOTE

Be careful not to let the sagging belt reach the conveyor frame or floor. This greatly reduces the belt tension and may cause sprocket disengagement.

Motors

There are two types of motors: drum motor, and gear motor. The drum motor is maintenance-free, but the gear motor needs maintenance.

For both types of motor, the following should be observed:

- Inspect the motors every day of operation. This is necessary to ensure that they run normally and that there is no abnormal noise from the motors. Check for oil leaks.
- Check regularly if the motor cable conduit and the nipple on the motor box are tight enough to prevent water from entering the motor.
- Check wear on sprockets.




Figure 52 Drum motor with sprockets

For gear motor, also follow these instructions:

- Change the oil on the gear motors after every 10,000 operating hours.
For refill, use EG gear oil SAE 90. For further details see the motor manufacturer's instructions.
- Check if homogeneous belt sits properly and holes on belt are aligned with pins in motor.

Emergency Stop Button

Test the emergency stop button at least once every week to check if the button functions as designed. Press the emergency stop, and notice if the X-ray generation and belt stop. For more information, see "Controls and Indicators" on page 23..

Filter

Check condition of the filter every week. Open waterguard and flip down the lower duct **1** and lift up the filter frame **2** and place the filter **3** between the two filter frames.




Figure 53 Filter position

Cleaning

Cleaning in General

The following sections contain general instructions for good cleaning practices which Marel considers appropriate for Marel equipment. The instructions are not a proposal for a complete cleaning plan for the user. The best available practices should be used at all times.

We recommend that you request an introduction to recommended cleaning agents and their use, from a qualified distributor of cleaning solutions. Selecting a sanitizer depends on the type of equipment to be sanitized, the hardness of the water, the application equipment available, the effectiveness of the sanitizer under site conditions, and cost.

Only approved sanitizers should be used in food processing plants. Lists of approved sanitizers are published by the authorities in most countries; see for example the Code of Federal Regulations in USA.

If you have questions on which sanitizer to use or on what is the appropriate solution strength, request technical advice from a reputable sanitizer manufacturer.

- It is very important that SensorX 502 is thoroughly cleaned every day after operation.
- In general, do not use excessively strong solutions of detergent. Chlorine disintegrates belts and strong base solutions ($\text{pH}>13$) corrode aluminum parts, air cylinders for example. The use of chlorine may cause rust spots to appear on the stainless steel.
- High-pressure water jets can easily damage sensitive mechanisms in the equipment. Therefore, do not use high-pressure water jets on the indicators (controller displays), product sensor and load cell, the electrical cabinets, or motor.
Instead, use low water pressure (tap water), or clean these parts by hand and pour water over to rinse.

Materials Used in Marel Equipment

The materials listed here are common in Marel equipment. Use the list to determine the chemical tolerance of individual parts of the equipment.

| NOTICE | |
|---|--|
|  | Specific recommendations on types and strength of solutions used for cleaning or sanitization should, at all times, come from a qualified distributor of cleaning solutions. |

Table 11 List of Materials

| Material | Used in | Resistance to detergents |
|-------------------------|---|---|
| Metals: | | |
| Stainless steel | Frames, various parts | High (in normal conditions, for example temperatures between -20 to +30 °C/-4 to 86 °F) |
| Aluminum | Load cell brackets and spacers, load cells, pneumatic cylinder ends | Low, to strong base solutions |
| Plastics: | | |
| Polyethylene (PE) | Guides | High |
| Polycarbonate (PC) | Displays and keyboards | Limited, to strong base solutions |
| Polypropylene (PP) | Modular conveyor belts | High |
| Acetyl (POM) | Modular conveyor belts | High, may develop precipitations caused by chlorine |
| Polyvinylchloride (PVC) | Endless belts of layered PVC and PUR canvas | Low, especially to minimally diluted solutions |
| Polyurethane (PUR) | | |

Water and Temperature

- Water can contain a significant number of microorganisms. Therefore, inspection of water used for cleaning should be part of a HACCP plan. All impurities in water can influence the effectiveness of a detergent or sanitizer.
- Water hardness is the most important chemical property which directly effects cleaning and sanitizing efficiency. The pH value for normal water ranges from pH 5 to pH 8.5.
- Soils soluble in water are sugars, some starches and most salts.
- Always use clean water for rinsing and cleaning. Never rinse or clean with seawater.
- Rinse with cold water, except when working with fat products. In that case use 40-55 °C (104-131 °F) hot water to dissolve the fat. Some fats have a melting point below the recommended 40-55 °C, so you should adjust the water temperature accordingly.
- Be careful when using hot water. Some proteins denature in high temperatures and may become difficult to remove.
- Avoid temperatures above 55 °C (131 °F) because of the corrosive nature of most chemical sanitizers.

Detergents

The pH value of detergents used on Marel equipment should preferably be pH 12-13. Strong base solutions are the main ingredients in most cleaning agents, for example potassium hydroxide (KOH) or caustic soda (NaOH). Because of its corrosive effects, caustic soda is not a desirable detergent for Marel equipment.

If possible, use detergent solutions with KOH instead.

- Always use detergents according to the detergent manufacturer's instructions.
- Do not use a detergent containing sodium hypochlorite for daily cleaning. Sodium hypochlorite is a common ingredient in detergents, but as it contains chlorine it should be used with great care because of chlorine's corrosive effect on stainless steel.

Daily Cleaning

Cleaning is the complete removal of food soils using appropriate detergent chemicals according to instructions. It is important that cleaning personnel have an understanding of the nature of the different types of food soils and the chemistry of their removal.

- Use high alkaline foaming detergent, 1% solution, pH 12-13, for regular daily cleaning. Avoid using a detergent containing a high amount of sodium hypochlorite for daily cleaning. The foaming detergent must be selected carefully and should contain some corrosion inhibitors and preferably potassium hydroxide (KOH) instead of sodium hydroxide (NaOH).
- Spray the detergent on all surface areas and leave it, to work for a time specified by the cleaning agent's manufacturer. Then rinse the detergent off with clean, cold water.
- To kill any remaining bacteria, you must finish the daily cleaning procedure by spraying the surface with an approved chemical sanitizer.

| NOTICE | |
|---|---|
|  | Quaternary ammonium compounds (QACs) are widely used in the food processing industry. Keep in mind, however, that while these are effective against most bacteria, they act slowly against some common spoilage bacteria. Many common bacteria may also develop tolerance against QACs, which should therefore not be used for an extended period of time unless they are rotated with compounds of a different type. |

- QACs may leave an undesirable film on the surface of the equipment and, as they should not come in contact with food, they should always be rinsed off (before processing is resumed) with cold and, most importantly, clean water.

Sanitization

When choosing a sanitizing agent, please note that chlorine corrodes the stainless steel and disintegrates PVC and PUR belts, especially at higher temperatures. Chlorine is, however, an effective sanitizer, so occasional use of chlorine may be necessary to control the growth of microorganisms.

Marel recommends the following sanitization procedure:

- Spray the sanitizer on surfaces and leave to work according to manufacturer's instructions. Make sure you spray into all corners and hard-to-reach areas.
- After sanitizing, always rinse the equipment carefully with cold and clean water before resuming processing.
- Use chlorine or a comparable sanitizer on the equipment once a week after performing the regular cleaning procedure with a high alkaline foaming detergent.
- Make sure the strength of chlorine, if used, does not exceed 200 ppm.
- On days when chlorine or a comparable sanitizer is not used, use other sanitizers recommended for food processing instead.

| REMARK | |
|---|--|
|  | Rotating different sanitizers (for example chlorine, peracid or acid-anionic) in your sanitization program may ensure more effective sanitization. |

As chlorine evaporates very quickly, its sanitizing effect will fade soon after it is sprayed on the equipment. Letting chlorine stay on the equipment will not improve the sanitizing effect, but only damage the equipment. Quaternary ammonium compounds are considerably more stable than chlorine and are active for a much longer time. Therefore, the benefit of leaving QACs on the equipment for an extended period of time is much greater.

Training Staff

It is important that new cleaning personnel receive the proper training and are made aware of the proper cleaning procedures for this machine. Demonstrate the cleaning procedures for new personnel using the instructions in the following sections. Make sure the cleaning personnel is familiar with safety rules concerning the use of cleaning agents.

Cleaning Procedures

Before you start cleaning the SensorX 502, follow the instructions below to ensure maximum safety during the cleaning.

Cleaning the SensorX 502 is a procedure in eight steps:

- preparation
- rinsing the nearby environment
- rinsing the SensorX 502
- foaming
- washing
- sanitizing
- assembling after sanitizing
- final inspection

Preparation

1. Secure the machine by turning the Motors switch OFF, unless you are using the Washing mode (optionally, lock the switch with a padlock for additional safety).
2. Remove the X-ray key to prevent unauthorized operation.
3. Unlock and open the conveyor cover. Lift the cover all the way up.
4. At this stage you can run the belt on the machine for rinsing off any major soils.
5. Open the motor cover.
6. Lift up the scraper and two rollers to remove the conveyor belt.
7. Clean the rollers and the SensorX conveyor belt separately.
8. Remove the six wear strip frames or roller frames from the conveyor compartment.




Figure 54 Lifting up the scraper and the belt rollers




Figure 55 Remove plastic side guides for cleaning

9. Work stations: open the work table and tilt the lamp unit up to prevent the unit from being soaked.




Figure 56 Flip down the work table and tilt the lamp

Rinsing the Environment

1. Thoroughly rinse nearby walls and floor to prevent cross-contamination from the environment after the SensorX 502 has been cleaned.
2. If possible, do not use water temperatures over 55 °C (131 °F) to avoid heat denatured proteins.

Rinsing the SensorX 502

1. Rinse soils off the machine using water jets or a brush. Rinse thoroughly from the top down with clean water.
2. **Do not** insert soils or water in the air duct, which is located at the back of the SensorX machine.
3. Avoid high water pressure in order not to spread the soils all over the machine.
4. If possible, do not use water temperatures over 55 °C (131 °F) to avoid heat denatured proteins.

Foaming

1. Make sure the foam reaches all corners and hard-to-reach areas.
2. Let the detergent work as specified by the manufacturer.

Washing

1. Keep the conveyor belt running while you rinse off dirt dissolved by the foaming, working from the top down using water jets.
2. Use a brush on solid dirt and not easily accessible surfaces.
3. Wash the belt thoroughly every day of operation. For a more thorough cleaning, remove the modular belts at least once a month and soak in a detergent bath.¹ For details on how to remove the belt, see the belt manufacturer's brochure delivered with the SensorX 502 system.
4. Let the SensorX 502 dry as much as possible before sanitizing.

| NOTICE | |
|---|--|
|  | Cross-contamination can easily occur if clean surfaces come in contact with other less clean surfaces, for example when you replace belts. |

Sanitizing

- All surfaces in contact with the product should be sanitized every day of operation.
- Make sure the surface is as dry as possible before sanitizing, because water remaining from the washing process will dilute the sanitizing agent.
- For the daily sanitization, use sanitizing agents containing, for example, quaternary ammonium compounds. Once a week, sanitize with chlorine (≤ 200 ppm) or a comparable sanitizing agent.
- After sanitizing, rinse the SensorX 502 thoroughly with clean water to eliminate contact between sanitizer and raw material or products in the next production round. This also helps prevent corrosion of the stainless steel by aggressive sanitizers and prevents the forming of an undesirable chemical film.

Assembling After Sanitizing

- Retrace the steps in "Preparation" on page 69 to put the SensorX 502 back into operational condition.

Final Inspection

After cleaning, quality control personnel should evaluate the result of the cleaning process:

- Using your hands, ensure that places are clean where visual control is difficult.
- Regularly measure cleaning results by counting the microorganisms, for example using RODAC cups or ATP measurements.
- After cleaning and sanitizing, make sure that all surfaces dry as well as possible.

¹ The modular belt is heat resistant up to 100° C.

Special Cleaning Instructions

Some parts of the SensorX 502 system require special care during cleaning: the conveyor belt (see page 71), the Main display, and the electrical cabinet.

Cleaning the Conveyor Belts:

- Wash the belts thoroughly every day of operation.
- Remove all belts from the SensorX 502 at least once a week and soak in a detergent bath or spray with detergent.
Let the detergent work according to manufacturer's instructions.
For details on how to remove the belt, see the belt brochure delivered with the unit.
- Rinse thoroughly with clean, cold water or soak in clean water.
- Hang the belts up for drying. This is important to prevent bacterial growth which may contaminate food and cause serious infections. In case the belt cannot dry between shifts, we strongly recommend a rotation using a second belt. This will also increase belt life.

| REMARK | |
|---|--|
|  | Cross-contamination can easily occur if clean surfaces come in contact with other less clean surfaces, for example when you replace belts. |

Cleaning the Main Display:

- Before you start cleaning the display, press the emergency stop button.
- Rinse the Main display thoroughly every day of operation.
- Do not use high-pressure jets on the display. Instead, use low water pressure, or clean by hand and pour water over to rinse.

| NOTICE | |
|---|--|
|  | Before you start cleaning the display, press the emergency stop button to prevent an accidental start of the conveyor. |

Cleaning the Electrical Cabinet:

- Before you start cleaning the display, press the emergency stop button.
- Open the electrical cabinet at least once a month and check for soils.
- Turn the Mains switch to Off.
- Carefully wipe off the dirt with special attention to possible dirt accumulation in door grooves and the bottom of the cabinets.
- Sanitize places where dirt has accumulated by wiping with a sanitizing cloth.
- Secure the cabinet door and make sure the weather strip is intact and properly in place.
- Turn the Mains switch back to ON position to maintain constant power and prevent condensation of moisture in the unit.

| | NOTICE |
|---|--|
|  | Do not use water for cleaning inside the electrical cabinet. The electrical components in the cabinet must never become wet. If they do, you must make sure they are completely dry before the SensorX 502 system is powered on again. |

Electrical Parts and Diagrams for SensorX 502

Marel ehf
Austurhraun 9
IS-210 Gardabear

Iceland
T: +354 563 8000
F: +354 563 8001
I: www.marel.com



ELECTRICAL DIAGRAM

SENSOR X SX25

SENSOR X - SX25

3ph230/3ph+N 400 VAC

DRAWING/BOM NO.: **6002449**

REFERENCE DRAWING NUMBER :

DIMENSIONS OF ENCLOSURE [mm]: -

CUSTOMER : SENSOR X SX25

CUSTOMER CITY :

CUSTOMER STATE :

CUSTOMER COUNTRY :

AX ITEM NUMBER:

AX REFERENCE NUMBER:

NUMBER OF PAGES : **40**

HARDWARE ENGINEER : **GHJ**

CREATED ON : **2018.11.19**

EDITED BY : **bjorn.fridriksson**

EDIT DATE : **2020.08.19** (YYYY-MM-DD)

PROJECT REVISION : **G**

next:
2

STRUCTURE IDENTIFIER OVERVIEW

previous:

1

THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF

PROJ. TYPE: SENSOR X - SX25
CUSTOMER: SENSOR X SX25
COUNTRY:

PAGE DESCRIPTOR: STRUCTURE IDENTIFIER OVERVIEW
=GEN GENERAL INFORMATION

| | | |
|--|--------------------------------------|-------------------------|
| | LAST EDIT DATE: 2018.10.09 | PAGE REV. PROJ. REV. |
| | REVISED ON: | BY: |

SCALE: PAGE:
1:1 2
DWG. NO. 6002449

next:

TABLE OF CONTENTS

Column X: An automatically generated page was edited

| PAGE | HIGHER-LEVEL FUNCTION (=) | MOUNTING LOCATION (+) | PAGE DESCRIPTION | EDITED BY | EDIT DATE | X |
|------|---------------------------|-----------------------|---|-----------|------------|---|
| 1 | GENERAL INFORMATION | | TITLE PAGE | BJFR | 2018.10.04 | |
| 2 | GENERAL INFORMATION | | STRUCTURE IDENTIFIER OVERVIEW | BJFR | 2018.10.09 | |
| 3 | GENERAL INFORMATION | | TABLE OF CONTENTS | | 2020.08.19 | |
| 4 | GENERAL INFORMATION | | REVISION OVERVIEW | | 2020.08.19 | |
| 5 | GENERAL INFORMATION | | PROJECT SPECIFICATION | BJFR | 2018.11.16 | |
| 6 | GENERAL INFORMATION | | PROJECT SPECIFICATION | BJFR | 2018.11.16 | |
| 7 | GENERAL INFORMATION | | TAG PLATES | BJFR | 2018.11.16 | |
| 8 | GENERAL INFORMATION | | TABLE OF CONTENTS | | 2020.08.19 | |
| 8 | GENERAL INFORMATION | SYSTEM OVERVIEW | CONNECTION DIAGRAMS | BJFR | 2018.10.10 | |
| 9 | GENERAL INFORMATION | SYSTEM OVERVIEW | RS232 & 9 PIN CONNECTOR | BJFR | 2018.10.10 | |
| 10 | GENERAL INFORMATION | SYSTEM OVERVIEW | CAN OVERVIEW, SX23 AND SX25 | | 2020.08.19 | |
| 11 | GENERAL INFORMATION | SYSTEM OVERVIEW | ETHERNET OVERVIEW, SX23 AND SX25 | BJFR | 2018.10.10 | |
| 12 | GENERAL INFORMATION | SYSTEM OVERVIEW | SYSTEM LAYOUT, CABLES, SX25 SENSOR X 25 | BJFR | 2018.10.10 | |
| 13 | GENERAL INFORMATION | SYSTEM OVERVIEW | SYSTEM LAYOUT, SX25 SENSOR X 25 | BJFR | 2018.11.16 | |
| 14 | GENERAL INFORMATION | MAIN CONTROL CABINET | CABINET LAYOUT | | 2020.08.19 | |
| 15 | GENERAL INFORMATION | MAIN CONTROL CABINET | TERMINAL STRIP, SX25 | BJFR | 2018.11.16 | |
| 16 | GENERAL INFORMATION | MAIN CONTROL CABINET | POWER CIRCUIT, INPUT | BJFR | 2018.10.10 | |
| 17 | GENERAL INFORMATION | MAIN CONTROL CABINET | POWER CIRCUIT | | 2020.08.19 | |
| 18 | GENERAL INFORMATION | MAIN CONTROL CABINET | POWER CIRCUIT, MOTORS | BJFR | 2018.10.10 | |
| 19 | GENERAL INFORMATION | MAIN CONTROL CABINET | SAFETY CIRCUIT, SX25 | | 2020.08.19 | |
| 20 | GENERAL INFORMATION | MAIN CONTROL CABINET | SAFETY CIRCUIT, SX25 | | 2020.08.19 | |
| 21 | GENERAL INFORMATION | MAIN CONTROL CABINET | CONTROL CIRCUIT, INVERTERS | | 2020.08.19 | |
| 22 | GENERAL INFORMATION | MAIN CONTROL CABINET | CONTROL CIRCUIT, X-RAY GENERATOR | | 2020.08.19 | |
| 23 | GENERAL INFORMATION | MAIN CONTROL CABINET | CONTROL CIRCUIT | | 2020.08.19 | |
| 24 | GENERAL INFORMATION | VALVE CABINET 1 | CABINET LAYOUT | | 2020.08.19 | |
| 25 | GENERAL INFORMATION | VALVE CABINET 1 | CONTROL CIRCUIT, STEPPER MOTORS | | 2020.08.19 | |
| 26 | GENERAL INFORMATION | VALVE CABINET 1 | CONTROL CIRCUIT, I/O'S | | 2020.08.19 | |
| 27 | GENERAL INFORMATION | VALVE CABINET 1 | KD1 X30 FOUR VALVES | BJFR | 2018.10.10 | |
| 1 | REPORTS | | PLC LIST | | 2020.08.19 | |
| 2 | REPORTS | | CABLE OVERVIEW | | 2020.08.19 | X |
| 3 | REPORTS | | CABLE OVERVIEW | | 2020.08.19 | X |
| 4 | REPORTS | | CABLE LIST | | 2020.08.19 | X |
| 5 | REPORTS | | CABLE LIST | | 2020.08.19 | X |

previous:

2

next:

4



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL

ALL RIGHTS RESERVED WORLDWIDE.

www.marel.com

PROJ. TYPE: SENSOR X - SX25
CUSTOMER: SENSOR X SX25
COUNTRY:

PAGE DESC.: TABLE OF CONTENTS
=GEN GENERAL INFORMATION

LAST EDIT DATE:
2020.08.19

PAGE REV.
PROJ. REV.

SCALE: PAGE:
1:1 3

DWG. NO. 6002449
SHEET / TOTAL : (3 / 40)

REVISED ON: BY:
CREATED ON: 2018.11.19 BY: GHJ

REVISION OVERVIEW

previous:

3



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

PROJ. TYPE: SENSOR X - SX25
CUSTOMER: SENSOR X SX25
COUNTRY:

PAGE DESCRI.: REVISION OVERVIEW
=GEN GENERAL INFORMATION

LAST EDIT DATE

PAGE REV.

SCALE: PAGE:
1:1

4

6002449

| Ethernet Cable RJ-45 8-pin plug or 4-pin plug | | | |
|--|-------|----------------|-------|
| 8-Pin | 4-Pin | Signal | Wire |
| 1 | 1 | Tx+ (Transmit) | WH/OG |
| 2 | 2 | Tx- (Transmit) | OG |
| 3 | 3 | Rx+ (Receive) | WH/GN |
| 4 | | Not used | BU |
| 5 | | Not used | WH/BU |
| 6 | 4 | Rx- (Receive) | GN |
| 7 | | Not used | WH/BN |
| 8 | | Not used | BN |

| Can connections (Combicon Plug) | | |
|------------------------------------|--------------|------|
| Pin | Signal | Wire |
| 1 | V+ (24Vdc) | RD |
| 2 | C+ (Can Hi) | WH |
| 3 | Screen | SH |
| 4 | C- (Can Low) | BU |
| 5 | V- (0V) | BK |

| Can connections (9-pin Plug) | | |
|---------------------------------|--------------|------|
| Pin | Signal | Wire |
| 2 | C- (Can Low) | BU |
| 3 | V- (0V) | BK |
| 7 | C+ (Can Hi) | WH |
| | | |
| | | |

| Serial Bus | | |
|------------|--------|------|
| Pin | Signal | Wire |
| 2 | RX/TX | YE |
| 3 | TX/RX | GN |
| 5 | 0V | BU |
| | | |
| | | |

Control cable wire Colour/Number comparison table

Reference table between Colours and Numbers if data from cable in document is incomplete.

| Colour code | Numbers |
|---------------|---------|
| Blue | BU |
| Red | RD |
| Green | GN |
| Yellow | YE |
| White | WH |
| Black | BK |
| Brown | BN |
| Violet | VT |
| Orange | OG |
| Pink | PK |
| Cyan | CY |
| Grey | GY |
| Red/Blue | RD/BU |
| Green/Red | GN/RD |
| Yellow/Red | YE/RD |
| White/Red | WH/RD |
| Red/Black | RD/BK |
| Red/Brown | RD/BN |
| Yellow/Blue | YE/BU |
| White/Bue | WH/BU |
| Blue/Black | BU/BK |
| Orange/Blue | OG/BU |
| Yellow/Green | YE/GN |
| White/Green | WH/GN |
| Orange/Green | OG/GN |
| Green/Blue | GN/BU |
| Grey/Blue | GY/BU |
| Green/Black | GN/BK |
| Grey/Green | GY/GN |
| Yellow/Brown | YE/BN |
| White/Brown | WH/BN |
| Brown/Black | BN/BK |
| Grey/Brown | GY/BN |
| Yellow/Violet | YE/VT |
| Violet/Black | VT/BK |
| White/Violet | WH/VT |

Other wire codes

| | |
|-------------------|-------|
| Green/Yellow (PE) | GN/YE |
| Screen | SH |
| Transparent | TP |
| Beige | BE |
| | |
| | |
| | |

INTERNAL WIRE SPECIFICATION

REMARK: USE UL(MTW) WIRE,
RATED VOLTAGE UL (AWM) U:600V, UL (MTW) U:600V

| Wiring type | Colour | Cross section |
|---|--|--|
| Main current: Phase 1-3 Phase Neutral | Black Light blue | Min. AWG 14 Min. AWG 14 |
| Control current: Vac Phase, Voltage = mains Phase, Voltage < mains Switched Zero (0Vac) | Black Red Red White | Min. AWG 16 Min. AWG 16 Min. AWG 16 Min. AWG 16 |
| Vdc +Vdc -Vdc Switched Zero (0Vdc) | Dark Blue Dark Blue Dark Blue White/Blue | Min. AWG 16 Min. AWG 16 Min. AWG 16 Min. AWG 16 |
| External source voltage | Orange | Min. AWG 16 |
| Earthing: Main current Control current Door earthing Phase < 16mm ² Phase 16 - 35mm ² Phase 35 - 400mm ² | Yellow/Green Yellow/Green Yellow/Green Yellow/Green Yellow/Green Yellow/Green | Min. AWG 10 Min. AWG 16 Min. AWG 3 Min. equal to ph. Min. 7/0 Min. AWG 13/0 |
| Screening: No earth wire | Black shrink-wrap (Yellow/Green not allowed) | |

previous:
4

next:
6

DEVICE TAG EXPLANATION

FIRST LETTER IS ACCORDING IEC-EN-81346

SECOND LETTER IS MAREL SUBCLASS DEFINITION FOR E-PARTS

| LETTER CODE | DESCRIPTION / EXAMPLES | LETTER CODE | DESCRIPTION / EXAMPLES | LETTER CODE | DESCRIPTION / EXAMPLES |
|----------------|--|----------------|---|----------------|--|
| A | TWO OR MORE PURPOSES OR TASKS | G | INITIATING FLOW OF ENERGY | S | CONVERTING MANUAL OPERATION TO SIGNAL |
| AG | GENERAL ACCESESORIES (PANEL ASSEMBLY COMPONENTS) | GB | BATTERY / UPS | SC | CONTROL SWITCH (PUSHBUTTON, SELECTOR SWITCH) |
| AK | CONTROL PANEL I/O AND ANALOG PROCESSING | K | PROCESSING SIGNALS | SE | EMERGENCY STOP, PULL CORD |
| AP | DISPLAY / TOUCH SCREEN / SIGNAL LIGHT BOX / OPERATOR PANEL | KA | ANALOG I/O UNITS | SK | KEYBOARD |
| AQ | POWER PANEL INCLUDES MAIN VOLTAGE | KB | BUS INTERFACE | SS | SAFETY SWITCH |
| AS | SWITCH BOX (BOX WITH A SINGLE SWITCH) | KC | PROGRAMMABLE CONTROLLER | | |
| AT | TRANSFORMER PANEL / BOX | KD | DIGITAL I/O UNITS | | |
| AV | VALVE PANEL / BOX | KE | ETHERNET SWITCH / ROUTERS / GATEWAYS | T | CONVERSION OF ENERGY |
| AW | CONTROL PANEL WEIGHING | KF | FILTER (EMC, LINE, LOAD) | TA | AMPLIFIER |
| AX | JUNCTION BOX / TERMINAL BOX | KH | ENVIRONMENTAL CNTR. (THERMOSTAD, HUMIDITY) | TC | SIGNAL CONVERSION |
| AY | OTHERS | KR | RELAY, GENERAL | TD | DIAGNOSTIC ADAPTER (CAN, ETHERNET) |
| AZ | BACKPLATE, MOUNTING PLATE | KO | RELAY, OPTO | TF | MOTOR CONTROLLER (FREQ. INVERTER, SERVO) |
| | | KP | RELAY, SOLID STATE | TP | POWER SUPPLY, DC |
| B | CONVERTING INPUT TO SIGNAL | KS | RELAY, SAFETY / CONTROLLER | TV | VIBRATOR CONTROLLER |
| BA | GAS / LIQUID PRESSURE (E.G. AIR, WATER) | KT | RELAY, TIMER | TT | TRANSFORMER |
| BB | SAFETY LIGHT BEAM/CURTAIN | KV | VALVE, SOLENOID | | |
| BD | DIFFUSE PHOTO SENSOR | M | PROVIDING MECHANICAL ENERGY | U | KEEPING OBJECTS IN POSITION |
| BE | ENCODER/RESOLVER | MA | CYLINDER / ACTUATORS | UU | HOLDING / SUPPORT BRACKETS (INSULATOR) |
| BF | LEVEL, FLOAT SWITCH | ML | LOW VOLTAGE MOTORS (<50V) | | |
| BH | HEAT PROBE TEMPERATURE | MT | MOTORS, WITH INTEGRATED FREQUENCY INVERTER | V | PROCESSING, TREATING MATERIALS |
| BK | MECHANICAL SWITCH (MICRO, LIMIT SWITCH) | MS | MOTOR, SERVO | VF | NON ELECTRICAL |
| BL | LOADCELL | MV | MOTOR, VIBRATOR | | |
| BM | INDUCTIVE PROXIMITY SENSOR | M | MOTORS, GENERAL (>50V) | | |
| BN | CAPACITIVE PROXIMITY SENSOR | P | PRESENTING INFORMATION | W | TRANSPORTING ENERGY, SIGNALS, MATERIALS |
| BO | REED CONTACT/MAGNET SENSOR | PD | OPERATOR INTERFACE (HMI, HIM ETC.) | WA | CABLE ASSEMBLY (E.G. CABLE LOOMS) |
| BP | PHOTO SENSOR RX/TX | PJ | AUDIBLE PRESENTATION (BELL, SIRENE, HORN) | WB | BUS CABLES (CAN, ETHERCAT) |
| BR | REFLECTIVE PHOTO SENSOR | PL | VISUAL PRESENTATION (SIGNAL LIGHT, LED, MIMIC PANELS) | WC | CONTROL CABLES (<50V) |
| BS | SAFETY SENSOR (INTRINSICALLY SAFETY FUNCTION) | PM | PANEL METERS (AMPS, VOLTS, WATTS, HOURS, PRESSURE) | WE | ETHERNET CABLES |
| BT | TAG READER (RF-ID) | PP | PRINTER | WM | MOTOR CABLES |
| BU | ULTRASONIC SENSOR | | | WP | POWER CABLES (>50V) |
| BV | VISION | Q | CONTROLLED SWITCHING ENERGY | WX | PREFABRICATED CABLES |
| BX | X-RAY SENSOR | QC | POWER CONTACTORS | W | CABLE, GENERAL |
| BZ | LASER SENSOR | QF | MOTOR CIRCUIT BREAKER | | |
| C | STORING ENERGY | QM | MOTOR STARTER / SOFT STARTER | X | CONNECTING OBJECTS |
| CA | GAS / LIQUID RESERVOIR (E.G. AIR, WATER) | QR | POWER SWITCH (DISCONNECT) | XB | BUS CONNECTION MODULE |
| CC | CAPACITORS | QP | MOTOR PROTECTION | XC | CONTROL CONNECTOR (<50V) |
| CM | MEMORY | | | XD | I/O CONNECTION MODULE |
| E | THERMAL / RADIANT ENERGY | R | RESTRICTING / STABILIZING MOTION OR ENERGY | XF | AIR FITTINGS |
| EF | AIR CONDITIONER / HEAT EXCHANGER | RA | AIR PRESSURE REGULATOR | XG | WIRE TERMINATION ACCESSORIES (FERULE, WIRE NUMBER) |
| EL | LIGHTS/LAMPS | RD | DIODE | XP | POWER CONNECTOR (>50V) |
| ER | HEATER (RESISTANCE) | RR | RESISTOR | X | TERMINALS |
| EX | X-RAY GENERATOR | RY | INDUCTOR | | |
| EZ | LASER | | | | |
| F | SELF ACTING PROTECTION | | | | |
| FC | MINIATURE CIRCUIT BREAKER | | | | |
| FO | MOTOR OVERLOAD | | | | |
| FF | FUSE | | | | |
| FM | PROTECTING MODULE CLASS 2 | | | | |
| FN | SURGE PROTECTION | | | | |
| FV | VOLTAGE MONITORING | | | | |

previous:

5

next:

7

Marel ehf

Austurhraun 9 IS-210 Gardabær Iceland

| | | | | |
|----------------------|----------------------|---------------------------|-----------------------------|-------------------|
| Machine | * 2 | | | |
| Model | * 3 | Year * 5 | | |
| Type | SENSOR X - SX25 | Serial no. * 6 | | |
| Voltage | 3ph230/3ph+N 400 VAC | Short circuit rating 5 KA | | |
| Frequency | 50/60 Hz | Largest motor FLA 2 A | Enclosure prot. rating IP46 | |
| Current | 8,0/4,6 A | EL. diagr. no. 6002449 | Nominal power | Mass of Machinery |
| For mobile machinery | | | | |
| www.marel.com | | | | |

MACHINEPLATE INFORMATION

| | | |
|----------------|--------------------|--|
| * 2 MACHINE: | MACHINE NAME: | SEE INFORMATION FROM PRODUCTION SYSTEM |
| * 3 MODEL: | MACHINE CODE NO: | SEE INFORMATION FROM PRODUCTION SYSTEM |
| * 4 TYPE: | BOM LIST NO: | SEE INFORMATION FROM PRODUCTION SYSTEM |
| * 5 YEAR: | MANUFACTURING YEAR | SEE INFORMATION FROM PRODUCTION SYSTEM |
| * 6 SERIAL NO: | SERIAL NUMBER: | SEE INFORMATION FROM PRODUCTION SYSTEM |

previous:

6

next:

8



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL

ALL RIGHTS RESERVED WORLDWIDE.

www.marel.com

PROJ. TYPE: SENSOR X - SX25

CUSTOMER: SENSOR X SX25

COUNTRY:

PAGE DESCRI.: TAG PLATES
=GEN GENERAL INFORMATION

LAST EDIT DATE:
2018.11.16

PAGE REV.
PROJ. REV. G

SCALE: PAGE:
1:1 7

DWG. NO. 6002449

SHEET / TOTAL : (7 / 40)

TABLE OF CONTENTS

Column X: An automatically generated page was edited

[previous:](#)

 Mazel

THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF

N PROJ. TYPE: SENSOR X - SX25
S CUSTOMER: SENSOR X SX25
C COUNTRY:

PAGE DESC'R.: TABLE OF CONTENTS

LAST EDIT DATE:
2020-03-10

PAGE REV.

SCALE: PAGE:
1:1

8

next:
+SOV/8


8

6002449


DWG. NO.

SHEET / TOTAL : (8 / 40)


EXAMPLE 1





EXAMPLE 2



EXAMPLE 3

previous:
+/8next:
9




| CAN CONNECTIONS | | |
|-----------------|-------------|------|
| PIN | SIGNAL | WIRE |
| 1 | V+ (24VDC) | RD |
| 2 | C+ (CAN HI) | WH |
| 3 | SCREEN | SH |
| 4 | C- (CAN LO) | BU |
| 5 | V- (0V) | BK |

previous:

8

next:


10



| CAN CONNECTIONS | | |
|-----------------|-------------|------|
| PIN | SIGNAL | WIRE |
| 1 | V+ (24VDC) | RD |
| 2 | C+ (CAN HI) | WH |
| 3 | SCREEN | SH |
| 4 | C- (CAN LO) | BU |
| 5 | V- (0V) | BK |


NOTE:
CAN TERMINATION RESISTORS R1 AND R2
ARE PLACED AT EACH END OF CAN NETWORK.





previous:
9next:
11





| Ethernet Cable RJ-45 8-pin plug or 4-pin plug | | | |
|--|-------|----------------|-------|
| 8-Pin | 4-Pin | Signal | Wire |
| 1 | 1 | Tx+ (Transmit) | WH/OR |
| 2 | 2 | Tx- (Transmit) | OR |
| 3 | 3 | Rx+ (Receive) | WH/GN |
| 4 | | Not used | BU |
| 5 | | Not used | WH/BU |
| 6 | 4 | Rx- (Receive) | GN |
| 7 | | Not used | WH/BN |
| 8 | | Not used | BN |

previous:
10next:
12

previous:
11next:
13

previous:
12next:
+AQ1/14

previous:
+SOV/13next:
15



previous:



14

next:



16

CONNECTION DIAGRAMS



EXAMPLE 1




EXAMPLE 2



EXAMPLE 3




previous:
15



POWER TO COOLING MACHINE (OPTIONAL)

24VDC CONTROL CIRCUITS

previous:
16next:
18




previous:

17


next:


19




previous:
18

next:
20


previous:
19next:
21

previous:
20next:
22



previous:
21

next:
23



previous:

22



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

PROJ. TYPE: SENSOR X - SX25
CUSTOMER: SENSOR X SX25
COUNTRY:

PAGE DESCRI.: CONTROL CIRCUIT
=GEN GENERAL INFORMATION
+AQ1 MAIN CONTROL CABINET

LAST EDIT DATE
2020.08.19

PAGE REV.
PROJ. REV.


SCALE:
1:1
DWG. NO.

PAGE: 23

next:
15

+AV1/24

100

previous:
+AQ1/23next:
25

+AQ1

MAIN CONTROL CABINET

+24VDC,
+AQ1/21.8
-X10 32
0V,
+AQ1/21.8
31


+AQ1-WCAV1
12x0,5 mm²
RD BU
-XB1 V+ C+ SH C- V-
+SOV/10.1
TBC6 +24V
TBC6 +24V

TBC6
+24V

-KD2
MCSTEP2
STEPPER
MOTOR
CONTROL
+SOV/10.1
-X01
+ -
MOTOR IN
24-48Vdc
+24V EN
-X30
W1 W2 W3 W4
STEPPER MOTOR

-KD3
MCSTEP2
STEPPER
MOTOR
CONTROL
+SOV/10.2
-X01
+ -
MOTOR IN
24-48Vdc
+24V EN
-X30
W1 W2 W3 W4
STEPPER MOTOR

-KE1
ES5
+24V
+SOV/11.2
+24V 0V



-WCML1
4x0,5 mm²
GN YE BU RD
-AXML1
-X10 1 2 3 4
BK OR YE RD
-ML1
STEPPER MOTOR 1
PLASTIC LOWER

-WCML2
4x0,5 mm²
GN YE BU RD
-AXML2
-X10 1 2 3 4
BK OR YE RD
-ML2
STEPPER MOTOR 2
ALUMINIUM
UPPER

previous:


24



next:

26

+AQ1

MAIN CONTROL CABINET

previous:
25next:
27

previous:
26next:
=REP+/1

| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|--------------------|---------------|---------------|---------------|-------------|---------------------------------|-----------------------|----------------|-----------------|--------------------------|
| I/O PAGE REFERENCE | I/O UNIT NAME | I/O UNIT TYPE | I/O UNIT PLUG | CAN ADDRESS | SIGNAL FUNCTION | COMPONENT CONN. POINT | COMPONENT NAME | COMPONENT TYPE | COMPONENT PAGE REFERENCE |
| =GEN+AV1/26.0 | =GEN+AV1-KD1 | MSC816 | -X11 | O 10 11 | | | | | |
| =GEN+AV1/26.1 | =GEN+AV1-KD1 | MSC816 | -X11 | I 10 11 | | | | | |
| =GEN+AV1/26.1 | =GEN+AV1-KD1 | MSC816 | -X12 | O 10 12 | | | | | |
| =GEN+AV1/26.2 | =GEN+AV1-KD1 | MSC816 | -X12 | I 10 12 | | 5 | =GEN+AV1-RA1 | PRESSURE SWITCH | =GEN+AV1/26.1 |
| =GEN+AV1/26.2 | =GEN+AV1-KD1 | MSC816 | -X13 | O 10 13 | | | | | |
| =GEN+AV1/26.3 | =GEN+AV1-KD1 | MSC816 | -X13 | I 10 13 | | | | | |
| =GEN+AV1/26.4 | =GEN+AV1-KD1 | MSC816 | -X14 | O 10 14 | | | | | |
| =GEN+AV1/26.4 | =GEN+AV1-KD1 | MSC816 | -X14 | I 10 14 | | | | | |
| =GEN+AV1/26.5 | =GEN+AV1-KD1 | MSC816 | -X15 | O 10 15 | WATER VALVE | A1 | =GEN+AV1-KW1 | | =GEN+AV1/26.5 |
| =GEN+AV1/26.5 | =GEN+AV1-KD1 | MSC816 | -X15 | I 10 15 | | | | | |
| =GEN+AV1/26.6 | =GEN+AV1-KD1 | MSC816 | -X16 | O 10 16 | | | | | |
| =GEN+AV1/26.6 | =GEN+AV1-KD1 | MSC816 | -X16 | I 10 16 | | | | | |
| =GEN+AV1/26.7 | =GEN+AV1-KD1 | MSC816 | -X17 | O 10 17 | OPTIONAL POTENTIAL FREE CONTACT | A1 | =GEN+AQ1-KR5 | 24VDC | =GEN+AQ1/21.6 |
| =GEN+AV1/26.8 | =GEN+AV1-KD1 | MSC816 | -X17 | I 10 17 | | | | | |
| =GEN+AV1/26.8 | =GEN+AV1-KD1 | MSC816 | -X18 | O 10 18 | INFEED BELT RUN | A1 | =GEN+AQ1-KR6 | 24VDC | =GEN+AQ1/21.7 |
| =GEN+AV1/26.9 | =GEN+AV1-KD1 | MSC816 | -X18 | I 10 18 | EXTERNAL BELT INTERLOCK | 12 | =GEN+AQ1-KR7 | | =GEN+AQ1/21.5 |
| =GEN+AV1/27.1 | =GEN+AV1-KD1 | MSC816 | -X30 | O 10 11 | REJECT 1 | | =GEN+AV1-KV1 | | =GEN+AV1/27.3 |
| =GEN+AV1/27.1 | =GEN+AV1-KD1 | MSC816 | -X30 | O 10 12 | REJECT 2 | | =GEN+AV1-KV2 | | =GEN+AV1/27.3 |
| =GEN+AV1/27.1 | =GEN+AV1-KD1 | MSC816 | -X30 | O 10 13 | BYPASS IN TRIM SYSTEM | | =GEN+AV1-KV3 | | =GEN+AV1/27.4 |
| =GEN+AV1/27.1 | =GEN+AV1-KD1 | MSC816 | -X30 | O 10 14 | OPTIONAL | | =GEN+AV1-KV4 | | =GEN+AV1/27.5 |
| =GEN+AV1/27.1 | =GEN+AV1-KD1 | MSC816 | -X30 | O 10 15 | | | | | |
| =GEN+AV1/27.2 | =GEN+AV1-KD1 | MSC816 | -X30 | O 10 16 | | | | | |
| =GEN+AV1/27.2 | =GEN+AV1-KD1 | MSC816 | -X30 | O 10 17 | | | | | |
| =GEN+AV1/27.2 | =GEN+AV1-KD1 | MSC816 | -X30 | O 10 18 | | | | | |

previous:
=GEN+AV1/27

next:
2

| | | | | | | | |
|--|---|---|--|---|--------------------------|---------------------------|---------------------------------|
|  <p>marel</p> | <small>THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.</small> | <small>PROJ. TYPE: SENSOR X - SX25 CUSTOMER: SENSOR X SX25 COUNTRY:</small> | <small>PAGE DESCRI.: PLC LIST =REP REPORTS</small> | <small>LAST EDIT DATE: 2020.08.19</small> | <small>PAGE REV.</small> | <small>SCALE: 1:1</small> | <small>PAGE: 1</small> |
| | | | | <small>REVISED ON: 2018.11.19</small> | <small>BY: GHJ</small> | | <small>DWG. NO. 6002449</small> |

(29 / 40)

CABLE OVERVIEW

| CABLE NAME | SOURCE (FROM) | TARGET (TO) | CABLE TYPE | ALL CONDUCTORS | CONDUCTORS USED | CROSS-SECTION mm | LENGTH [m] | REMARK | PLACEMENT |
|-----------------|--------------------|--------------|--------------|----------------|-----------------|------------------|------------|--------|---------------|
| =GEN+SOV-WBXX1 | =GEN+SOV-XX1 | =GEN+SOV-XX2 | CAN | 2x2 | 3 | 0,5 | | | =GEN+SOV/9.6 |
| =GEN+SOV-WCXX1 | =GEN+AQ1-EX1 | =GEN+AQ1-KC1 | CONTROL | 4 | 3 | 0,5 | | | =GEN+SOV/9.2 |
| =GEN+AQ1-WCAV1 | =GEN+AQ1-X10 | =GEN+AQ1-X10 | CONTROL | 12 | 19 | 0,5 | | | =GEN+AQ1/21.7 |
| | =GEN+AQ1 | =GEN+AV1-XB1 | | | | | | | |
| | | =GEN+AV1-KD1 | | | | | | | |
| | | =GEN+AV1 | | | | | | | |
| =GEN+AQ1-WCER2 | =GEN+AQ1-X3 | =GEN+AQ1-X10 | CONTROL | 2 | 2 | 0,5 | | | =GEN+AQ1/23.8 |
| =GEN+AQ1-WCEX1 | =GEN+AQ1-X10 | =GEN+AQ1-EX1 | CONTROL | 4 | 4 | 0,5 | | | =GEN+AQ1/22.6 |
| | | =GEN+AQ1 | | | | | | | |
| =GEN+AQ1-WCKC1 | =GEN+AQ1-X10 | =GEN+AQ1-KC1 | CONTROL | 2 | 2 | 0,5 | | | =GEN+AQ1/23.4 |
| | | =GEN+AQ1 | | | | | | | |
| =GEN+AQ1-WCML3 | =GEN+AQ1-X10 | =GEN+AQ1-ML3 | CONTROL | 2 | 2 | 0,5 | | | =GEN+AQ1/23.7 |
| =GEN+AQ1-WCPL1 | =GEN+AQ1-X10 | =GEN+AQ1-PL1 | CONTROL | | 5 | | | | =GEN+AQ1/22.1 |
| | | =GEN+AQ1 | | | | | | | |
| =GEN+AQ1-WCRA1 | =GEN+AQ1-X10 | =GEN+AV1-RA1 | CONTROL | 2 | 1 | 0,75 | | | =GEN+AQ1/19.5 |
| =GEN+AQ1-WCSC1 | =GEN+AQ1-X10 | =GEN+AQ1-SC1 | CONTROL | 4 | 3 | 0,5 | | | =GEN+AQ1/20.5 |
| | | =GEN+AQ1 | | | | | | | |
| =GEN+AQ1-WCSE1 | =GEN+AQ1-X10 | =GEN+AQ1-SE1 | CONTROL | 4 | 3 | 0,5 | | | =GEN+AQ1/20.2 |
| | | =GEN+AQ1 | | | | | | | |
| =GEN+AQ1-WCSP2 | =GEN+AQ1-X10 | =GEN+AQ1-SP2 | CONTROL | 4 | 3 | 0,5 | | | =GEN+AQ1/20.3 |
| | | =GEN+AQ1 | | | | | | | |
| =GEN+AQ1-WCXB2 | =GEN+AQ1-X10 | =GEN+AV1-XB2 | CONTROL | 2 | 2 | 0,5 | | | =GEN+AQ1/23.2 |
| | | =GEN+AQ1 | =GEN+AV1 | | | | | | |
| =GEN+AQ1-WMM1 | =GEN+AQ1-M1 | =GEN+AQ1 | MOTOR | 4+2 | 6 | 1/0,5 | 10 | | =GEN+AQ1/18.0 |
| | | =GEN+AQ1-TF1 | | | | | | | |
| =GEN+AQ1-WMM1.1 | =GEN+AQ1-XTF | =GEN+AQ1-M1 | CONTROL | 4 | 4 | 0,22 | | | =GEN+AQ1/21.1 |
| =GEN+AQ1-WPER1 | =GEN+AQ1-XPE | =+ | POWER | 3 | 3 | 0,75 | | | =GEN+AQ1/17.3 |
| | | =GEN+AQ1-ER1 | =GEN+AQ1 | | | | | | |
| | | =GEN+AQ1-KR2 | | | | | | | |
| | | =GEN+AQ1-KR3 | | | | | | | |
| =GEN+AQ1-WPEX1 | =GEN+AQ1-EX1 | =GEN+AQ1 | POWER | 3 | 3 | 1 | | | =GEN+AQ1/17.0 |
| | | =GEN+AQ1-VF1 | | | | | | | |
| =GEN+AV1-BH1 | =GEN+AV1-BH1 | =GEN+AV1 | | | 3 | | | | =GEN+AV1/27.8 |
| | | =GEN+AV1-KD1 | | | | | | | |
| =GEN+AV1-WBBX1 | =GEN+AV1-BX1 | =GEN+AV1 | CAN | 2x2 | 1 | 0,5 | | | =GEN+SOV/10.4 |
| | | =GEN+AV1-XB2 | | | | | | | |
| =GEN+AV1-WBFE1 | =GEN+AQ1-FE1 | =GEN+AV1-XB2 | CAN | 2x2 | 1 | 0,5 | | | =GEN+SOV/10.5 |
| | | =GEN+AQ1 | =GEN+AV1 | | | | | | |
| =GEN+AV1-WBKC1 | =GEN+AQ1-KC1 | =GEN+AV1 | CAN | 2x2 | 2 | 0,5 | | | =GEN+SOV/10.1 |
| | | =GEN+AV1-XB2 | =GEN+AV1-XB1 | | | | | | |
| =GEN+AV1-WBTF1 | =GEN+AQ1-TF1 | =GEN+AV1-XB2 | CAN | 2x2 | 1 | 0,5 | | | =GEN+SOV/10.5 |
| | | =GEN+AQ1 | =GEN+AV1 | | | | | | |
| =GEN+AV1-WCKW1 | =GEN+AV1 | =GEN+AV1-KW1 | CONTROL | 3 | 2 | 0,5 | 3 | | =GEN+AV1/26.5 |
| | | =GEN+AV1-KD1 | | | | | | | |
| =GEN+AV1-WCML1 | =GEN+AV1-AXML1-X10 | =GEN+AV1-KD2 | CONTROL | 4 | 4 | 0,5 | | | =GEN+AV1/25.6 |
| | | =GEN+AV1 | =GEN+AV1-ML1 | | | | | | |

previous:
1next:
3

THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL ALL RIGHTS RESERVED WORLDWIDE. www.marel.com

PROJ. TYPE: SENSOR X - SX25

CUSTOMER: SENSOR X SX25

COUNTRY:

PAGE DESCRI.: CABLE OVERVIEW
=REP REPORTS

LAST EDIT DATE:
2020.08.19

PAGE REV.
PROJ. REV.

G
G

SCALE: PAGE:
1:1 2

REVISED ON: 2020.08.19 BY:
CREATED ON: 2018.11.19 BY: GHJ

DWG. NO. 6002449
SHEET / TOTAL : (30 / 40)

CABLE OVERVIEW

[previous:](#)

2

next:
1

4

| SOURCE (FROM) | CONNECTION | PAGE REFERENCE | WIRE | TARGET (TO) | CONNECTION | PAGE REFERENCE |
|----------------------------|------------|---|----------------|-----------------|------------|----------------|
| CABLE NAME: =GEN+SOV-WBXX1 | | CABLE TYPE: CAN 2x0,5 mm ² PART NO.: 718-3702-Y2422PUR | | COMMENT: | | |
| =GEN+SOV-XX1 | SH | =GEN+SOV/9.7 | RD,WH,SH,BU,BK | | | |
| =GEN+SOV-XX1 | CAN- | =GEN+SOV/9.7 | BK | =GEN+SOV-XX2 | 3 | =GEN+SOV/9.6 |
| =GEN+SOV-XX1 | CAN+ | =GEN+SOV/9.7 | BU | =GEN+SOV-XX2 | 2 | =GEN+SOV/9.6 |
| CABLE NAME: =GEN+SOV-WCXX1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | COMMENT: RS-232 | | |
| =GEN+AQ1-EX1 | COM | =GEN+SOV/9.2 | RD | | | |
| =GEN+AQ1-EX1 | RX | =GEN+SOV/9.2 | BU | =GEN+AQ1-KC1 | COM | =GEN+SOV/9.2 |
| =GEN+AQ1-EX1 | TX | =GEN+SOV/9.2 | GN | =GEN+AQ1-KC1 | TX | =GEN+SOV/9.2 |
| CABLE NAME: =GEN+AQ1-WCAV1 | | CABLE TYPE: CONTROL 12x0,5 mm ² PART NO.: 718-3702-0009 | | COMMENT: | | |
| =GEN+AQ1-X10 | 32 | =GEN+AQ1/21.3 | RD | =GEN+AQ1-X10 | 32 | =GEN+AV1/25.3 |
| =GEN+AQ1-X10 | 31 | =GEN+AQ1/21.3 | BU | =GEN+AQ1-X10 | 31 | =GEN+AV1/25.4 |
| =GEN+AQ1-X10 | 51 | =GEN+AQ1/21.3 | GN | =GEN+AQ1-X10 | 51 | =GEN+AV1/26.6 |
| =GEN+AQ1-X10 | 53 | =GEN+AQ1/21.7 | YE | =GEN+AQ1-X10 | 53 | =GEN+AV1/26.7 |
| =GEN+AQ1-X10 | 54 | =GEN+AQ1/21.7 | WH | =GEN+AQ1-X10 | 54 | =GEN+AV1/26.8 |
| =GEN+AQ1-X10 | 93 | =GEN+AV1/26.4 | BK | =GEN+AV1-KD1 | -X14 | =GEN+AV1/26.4 |
| =GEN+AQ1-X10 | 94 | =GEN+AV1/26.4 | BN | =GEN+AV1-KD1 | -X14:14 | =GEN+AV1/26.4 |
| =GEN+AQ1-X10 | 87 | =GEN+AV1/26.4 | VT | =GEN+AQ1-X10 | 87 | =GEN+AQ1/22.1 |
| =GEN+AQ1-X10 | 86 | =GEN+AV1/26.0 | OG | =GEN+AQ1-X10 | 86 | =GEN+AQ1/22.1 |
| =GEN+AQ1-X10 | 52 | =GEN+AQ1/21.7 | PK | =GEN+AQ1-X10 | 52 | =GEN+AV1/26.9 |
| | | | CY | | | |
| =GEN+AQ1-X10 | 88 | =GEN+AV1/26.3 | GY | =GEN+AV1-KD1 | -X13:13 | =GEN+AV1/26.3 |
| =GEN+AQ1-X10 | 31 | =GEN+AV1/25.4 | BU | =GEN+AV1-XB1 | | =GEN+AV1/25.3 |
| =GEN+AQ1-X10 | 51 | =GEN+AV1/26.6 | GN | =GEN+AV1-KD1 | -X16:16 | =GEN+AV1/26.6 |
| =GEN+AQ1-X10 | 86 | =GEN+AV1/26.0 | OG | =GEN+AV1-KD1 | -X11:11 | =GEN+AV1/26.0 |
| =GEN+AQ1-X10 | 52 | =GEN+AV1/26.9 | PK | =GEN+AV1-KD1 | -X18:18 | =GEN+AV1/26.9 |
| =GEN+AQ1-X10 | 32 | =GEN+AV1/25.3 | RD | =GEN+AV1-XB1 | +24V | =GEN+AV1/25.3 |
| =GEN+AQ1-X10 | 87 | =GEN+AV1/26.4 | VT | =GEN+AV1-KD1 | -X14:14 | =GEN+AV1/26.4 |
| =GEN+AQ1-X10 | 54 | =GEN+AV1/26.8 | WH | =GEN+AV1-KD1 | -X18:18 | =GEN+AV1/26.8 |
| =GEN+AQ1-X10 | 53 | =GEN+AV1/26.7 | YE | =GEN+AV1-KD1 | -X17:17 | =GEN+AV1/26.7 |
| CABLE NAME: =GEN+AQ1-WCER2 | | CABLE TYPE: CONTROL 2x0,5 mm ² PART NO.: 718-3702-00105 | | COMMENT: | | |
| =GEN+AQ1-X3 | 2 | =GEN+AQ1/23.8 | RD | =GEN+AQ1-X10 | 37 | =GEN+AQ1/23.8 |
| =GEN+AQ1-X3 | 1 | =GEN+AQ1/23.8 | BU | =GEN+AQ1-X10 | 31 | =GEN+AQ1/23.8 |
| CABLE NAME: =GEN+AQ1-WCEX1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | COMMENT: | | |
| =GEN+AQ1-X10 | 32 | =GEN+AQ1/22.7 | RD | =GEN+AQ1-EX1 | 3 | =GEN+AQ1/22.6 |
| =GEN+AQ1-X10 | 81 | =GEN+AQ1/22.6 | BU | =GEN+AQ1-EX1 | 1 | =GEN+AQ1/22.6 |
| =GEN+AQ1-X10 | 82 | =GEN+AQ1/22.7 | GN | =GEN+AQ1-EX1 | 2 | =GEN+AQ1/22.6 |

previous:
3next:
5

| SOURCE (FROM) | CONNECTION | PAGE REFERENCE | WIRE | TARGET (TO) | CONNECTION | PAGE REFERENCE |
|----------------------------|------------|--|------|--------------|------------|----------------|
| CABLE NAME: =GEN+AQ1-WCEX1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | COMMENT: | | |
| =GEN+AQ1-X10 | 84 | =GEN+AQ1/22.7 | YE | =GEN+AQ1-EX1 | 5 | =GEN+AQ1/22.6 |
| CABLE NAME: =GEN+AQ1-WCKC1 | | CABLE TYPE: CONTROL 2x0,5 mm ² PART NO.: 718-3702-00105 | | COMMENT: | | |
| =GEN+AQ1-X10 | 35 | =GEN+AQ1/23.5 | RD | =GEN+AQ1-KC1 | +24V | =GEN+AQ1/23.5 |
| =GEN+AQ1-X10 | 31 | =GEN+AQ1/23.6 | BU | =GEN+AQ1-KC1 | | =GEN+AQ1/23.5 |
| CABLE NAME: =GEN+AQ1-WCML3 | | CABLE TYPE: CONTROL 2x0,5 mm ² PART NO.: 718-3702-00105;718-3702-00105 | | COMMENT: | | |
| =GEN+AQ1-X10 | 36 | =GEN+AQ1/23.7 | RD | =GEN+AQ1-ML3 | 1 | =GEN+AQ1/23.7 |
| =GEN+AQ1-X10 | 31 | =GEN+AQ1/23.7 | BU | =GEN+AQ1-ML3 | 2 | =GEN+AQ1/23.7 |
| | | | RD | | | |
| | | | BU | | | |
| CABLE NAME: =GEN+AQ1-WCPL1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011;718-3702-0011 | | COMMENT: | | |
| =GEN+AQ1-X10 | 32 | =GEN+AQ1/22.4 | BN | =GEN+AQ1-PL1 | BN | =GEN+AQ1/22.4 |
| =GEN+AQ1-X10 | 86 | =GEN+AQ1/22.1 | GN | =GEN+AQ1-PL1 | GN | =GEN+AQ1/22.1 |
| =GEN+AQ1-X10 | 88 | =GEN+AQ1/22.2 | GY | =GEN+AQ1-PL1 | GY | =GEN+AQ1/22.2 |
| =GEN+AQ1-X10 | 85 | =GEN+AQ1/22.2 | RD | =GEN+AQ1-PL1 | RD | =GEN+AQ1/22.2 |
| =GEN+AQ1-X10 | 87 | =GEN+AQ1/22.1 | YE | =GEN+AQ1-PL1 | YE | =GEN+AQ1/22.1 |
| CABLE NAME: =GEN+AQ1-WCRA1 | | CABLE TYPE: CONTROL 2x0,75 mm ² PART NO.: 718-3701-0001;718-3701-0001 | | COMMENT: | | |
| =GEN+AQ1-X10 | 42 | =GEN+AQ1/19.5 | BN | =GEN+AV1-RA1 | | =GEN+AQ1/19.5 |
| | | | BU | | | |
| | | | BN | | | |
| | | | BU | | | |
| CABLE NAME: =GEN+AQ1-WCSC1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011;718-3702-0011 | | COMMENT: | | |
| =GEN+AQ1-X10 | 62 | =GEN+AQ1/20.5 | RD | =GEN+AQ1-SC1 | 13 | =GEN+AQ1/20.5 |
| =GEN+AQ1-X10 | 61 | =GEN+AQ1/20.5 | BU | =GEN+AQ1-SC1 | 13 | =GEN+AQ1/20.5 |
| | | | GN | | | |
| =GEN+AQ1-X10 | 68 | =GEN+AQ1/20.5 | YE | =GEN+AQ1-SC1 | 14 | =GEN+AQ1/20.5 |
| | | | RD | | | |
| | | | BU | | | |
| | | | GN | | | |
| | | | YE | | | |
| CABLE NAME: =GEN+AQ1-WCSE1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011;718-3702-0011 | | COMMENT: | | |
| =GEN+AQ1-X10 | 62 | =GEN+AQ1/20.3 | RD | =GEN+AQ1-SE1 | 21 | =GEN+AQ1/20.3 |
| =GEN+AQ1-X10 | 61 | =GEN+AQ1/20.2 | BU | =GEN+AQ1-SE1 | 21 | =GEN+AQ1/20.2 |
| | | | GN | | | |
| =GEN+AQ1-X10 | 64 | =GEN+AQ1/20.3 | YE | =GEN+AQ1-SE1 | 22 | =GEN+AQ1/20.3 |
| | | | RD | | | |
| | | | BU | | | |
| | | | GN | | | |

previous:
4next:
6

| SOURCE (FROM) | CONNECTION | PAGE REFERENCE | WIRE | TARGET (TO) | CONNECTION | PAGE REFERENCE |
|-----------------------------|------------|--|--|--------------|------------|----------------|
| CABLE NAME: =GEN+AQ1-WCSE1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011;718-3702-0011 | YE | COMMENT: | | |
| CABLE NAME: =GEN+AQ1-WCSP2 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011;718-3702-0011 | RD BU GN YE RD BU GN YE | COMMENT: | | |
| =GEN+AQ1-X10 | 62 | =GEN+AQ1/20.4 | RD | =GEN+AQ1-SP2 | 13 | =GEN+AQ1/20.4 |
| =GEN+AQ1-X10 | 61 | =GEN+AQ1/20.3 | BU | =GEN+AQ1-SP2 | 21 | =GEN+AQ1/20.3 |
| =GEN+AQ1-X10 | 66 | =GEN+AQ1/20.4 | GN | | | |
| | | | YE | =GEN+AQ1-SP2 | 14 | =GEN+AQ1/20.4 |
| | | | RD | | | |
| | | | BU | | | |
| | | | GN | | | |
| | | | YE | | | |
| CABLE NAME: =GEN+AQ1-WCXB2 | | CABLE TYPE: CONTROL 2x0,5 mm ² PART NO.: 718-3702-00105 | RD BU BU | COMMENT: | +24V | =GEN+AQ1/23.3 |
| =GEN+AQ1-X10 | 34 | =GEN+AQ1/23.3 | RD | =GEN+AV1-XB2 | +24V | =GEN+AQ1/23.3 |
| =GEN+AQ1-X10 | 31 | =GEN+AQ1/23.4 | BU | =GEN+AV1-XB2 | | =GEN+AQ1/23.3 |
| CABLE NAME: =GEN+AQ1-WMM1 | | CABLE TYPE: MOTOR 4+2x1/0,5 mm ² PART NO.: 718-3701-0042 | 1 2 3 PE WH BN SH | COMMENT: | | |
| =GEN+AQ1-M1 | U | =GEN+AQ1/18.0 | 1 | =GEN+AQ1-TF1 | U | =GEN+AQ1/18.1 |
| =GEN+AQ1-M1 | V | =GEN+AQ1/18.0 | 2 | =GEN+AQ1-TF1 | V | =GEN+AQ1/18.1 |
| =GEN+AQ1-M1 | W | =GEN+AQ1/18.0 | 3 | =GEN+AQ1-TF1 | W | =GEN+AQ1/18.1 |
| =GEN+AQ1-M1 | PE | =GEN+AQ1/18.0 | PE | =GEN+AQ1-TF1 | PE | =GEN+AQ1/18.1 |
| =GEN+AQ1-M1 | A | =GEN+AQ1/18.0 | WH | =GEN+AQ1-TF1 | T1 | =GEN+AQ1/18.1 |
| =GEN+AQ1-M1 | B | =GEN+AQ1/18.0 | BN | =GEN+AQ1-TF1 | T2 | =GEN+AQ1/18.1 |
| | | | SH | | | |
| CABLE NAME: =GEN+AQ1-WMM1.1 | | CABLE TYPE: CONTROL 4x0,22 mm ² PART NO.: 718-3702-0006 | BU RD GN YE BN WH | COMMENT: | | |
| | | | BU | | | |
| | | | RD | | | |
| =GEN+AQ1-XTF | DI1 | =GEN+AQ1/21.1 | GN | =GEN+AQ1-M1 | | =GEN+AQ1/21.1 |
| =GEN+AQ1-XTF | 32 | =GEN+AQ1/21.2 | YE | =GEN+AQ1-M1 | | =GEN+AQ1/21.1 |
| =GEN+AQ1-XTF | 31 | =GEN+AQ1/21.1 | BN | =GEN+AQ1-M1 | | =GEN+AQ1/21.1 |
| =GEN+AQ1-XTF | DI2 | =GEN+AQ1/21.1 | WH | =GEN+AQ1-M1 | | =GEN+AQ1/21.1 |
| CABLE NAME: =GEN+AQ1-WPER1 | | CABLE TYPE: POWER 3x0,75 mm ² PART NO.: 718-3701-0003 | BN BU GN/YE | COMMENT: | | |
| =GEN+AQ1-ER1 | 1 | =GEN+AQ1/17.3 | BN | =GEN+AQ1-KR2 | 11 | =GEN+AQ1/17.3 |
| =GEN+AQ1-ER1 | 2 | =GEN+AQ1/17.3 | BU | =GEN+AQ1-KR3 | 11 | =GEN+AQ1/17.4 |
| =GEN+AQ1-XPE | PE | =GEN+AQ1/17.3 | GN/YE | =+ | | =GEN+AQ1/17.3 |
| CABLE NAME: =GEN+AQ1-WPEX1 | | CABLE TYPE: POWER 3x1 mm ² PART NO.: 718-3703-1029677 | BN BU GN/YE GNYE | COMMENT: | | |
| =GEN+AQ1-EX1 | L | =GEN+AQ1/17.0 | BN | =GEN+AQ1-VF1 | 1L1 | =GEN+AQ1/17.0 |
| =GEN+AQ1-EX1 | N | =GEN+AQ1/17.1 | BU | =GEN+AQ1-VF1 | 1L2 | =GEN+AQ1/17.0 |
| | | | GN/YE | | | |
| =GEN+AQ1-EX1 | PE | =GEN+AQ1/17.1 | GNYE | =GEN+AQ1-VF1 | PE | =GEN+AQ1/17.1 |

previous:

5

next:



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

| SOURCE (FROM) | CONNECTION | PAGE REFERENCE | WIRE | TARGET (TO) | CONNECTION | PAGE REFERENCE |
|----------------------------|------------|---|----------------|--------------|------------|----------------|
| CABLE NAME: =GEN+AV1-BH1 | | CABLE TYPE: PART NO.: | | COMMENT: | | |
| =GEN+AV1-BH1 | RD | =GEN+AV1/27.8 | BU | =GEN+AV1-KD1 | iBUT | =GEN+AV1/27.8 |
| =GEN+AV1-BH1 | BU | =GEN+AV1/27.9 | RD | =GEN+AV1-KD1 | LED | =GEN+AV1/27.8 |
| =GEN+AV1-BH1 | YE | =GEN+AV1/27.8 | YE | =GEN+AV1-KD1 | GND | =GEN+AV1/27.8 |
| CABLE NAME: =GEN+AV1-WBBX1 | | CABLE TYPE: CAN 2x2x0,5 mm ² PART NO.: 718-3702-Y2422PUR | | COMMENT: | | |
| =GEN+AV1-BX1 | -X50 | =GEN+SOV/10.4 | RD,WH,SH,BU,BK | =GEN+AV1-XB2 | CAN | =GEN+SOV/10.4 |
| CABLE NAME: =GEN+AV1-WBFE1 | | CABLE TYPE: CAN 2x2x0,5 mm ² PART NO.: 718-3702-Y2422PUR | | COMMENT: | | |
| =GEN+AQ1-FE1 | CAN | =GEN+SOV/10.7 | XX,WH,SH,BU,BK | =GEN+AV1-XB2 | CAN | =GEN+SOV/10.5 |
| CABLE NAME: =GEN+AV1-WBKC1 | | CABLE TYPE: CAN 2x2x0,5 mm ² PART NO.: 718-3702-Y2422PUR | | COMMENT: | | |
| =GEN+AQ1-KC1 | CAN | =GEN+SOV/10.1 | XX,WH,SH,BU,BK | =GEN+AV1-XB1 | CAN | =GEN+SOV/10.1 |
| =GEN+AV1-XB2 | CAN | =GEN+SOV/10.3 | XX,WH,SH,BU,BK | =GEN+AV1-XB1 | CAN | =GEN+SOV/10.2 |
| CABLE NAME: =GEN+AV1-WBTF1 | | CABLE TYPE: CAN 2x2x0,5 mm ² PART NO.: 718-3702-Y2422PUR | | COMMENT: | | |
| =GEN+AQ1-TF1 | CAN | =GEN+SOV/10.7 | XX,WH,SH,BU,BK | =GEN+AV1-XB2 | CAN | =GEN+SOV/10.5 |
| CABLE NAME: =GEN+AV1-WCKW1 | | CABLE TYPE: CONTROL 3x0,5 mm ² PART NO.: 718-3703-1012364 | | COMMENT: | | |
| =GEN+AV1-KD1 | -X15:15 | =GEN+AV1/26.5 | BN | | | |
| =GEN+AV1-KD1 | -X15 | =GEN+AV1/26.5 | BU | | | |
| | | | GR/YE | | | |
| | | | BN | =GEN+AV1-KW1 | A1 | =GEN+AV1/26.5 |
| | | | BU | =GEN+AV1-KW1 | A2 | =GEN+AV1/26.5 |
| CABLE NAME: =GEN+AV1-WCML1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | COMMENT: | | |
| =GEN+AV1-AXML1-X10 | 4 | =GEN+AV1/25.6 | RD | =GEN+AV1-KD2 | W4 | =GEN+AV1/25.6 |
| =GEN+AV1-AXML1-X10 | 3 | =GEN+AV1/25.6 | BU | =GEN+AV1-KD2 | W3 | =GEN+AV1/25.6 |
| =GEN+AV1-AXML1-X10 | 1 | =GEN+AV1/25.6 | GN | =GEN+AV1-KD2 | W1 | =GEN+AV1/25.6 |
| =GEN+AV1-AXML1-X10 | 2 | =GEN+AV1/25.6 | YE | =GEN+AV1-KD2 | W2 | =GEN+AV1/25.6 |
| CABLE NAME: =GEN+AV1-WCML2 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | COMMENT: | | |
| =GEN+AV1-AXML2-X10 | 4 | =GEN+AV1/25.8 | RD | =GEN+AV1-KD3 | W4 | =GEN+AV1/25.8 |
| =GEN+AV1-AXML2-X10 | 3 | =GEN+AV1/25.8 | BU | =GEN+AV1-KD3 | W3 | =GEN+AV1/25.8 |
| =GEN+AV1-AXML2-X10 | 1 | =GEN+AV1/25.8 | GN | =GEN+AV1-KD3 | W1 | =GEN+AV1/25.7 |
| =GEN+AV1-AXML2-X10 | 2 | =GEN+AV1/25.8 | YE | =GEN+AV1-KD3 | W2 | =GEN+AV1/25.8 |
| CABLE NAME: =GEN+AV1-WEKC1 | | CABLE TYPE: ETHERNET 2x2x0,22 mm ² PART NO.: 718-3702-F5P2PUR | | COMMENT: | | |
| =GEN+AQ1-KC1 | RJ45 | =GEN+SOV/11.2 | | =GEN+AV1-KE1 | RJ45 | =GEN+SOV/11.2 |

previous:
6next:
8

| SOURCE (FROM) | CONNECTION | PAGE REFERENCE | WIRE | TARGET (TO) | CONNECTION | PAGE REFERENCE |
|----------------------------|------------|---|------|-------------|------------|----------------|
| CABLE NAME: =GEN+AV1-WEKC1 | | CABLE TYPE: ETHERNET 2x2x0,22 mm ² PART NO.: 718-3702-F5P2PUR | | SH | COMMENT: | |

previous:

5

next:

9



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL

ALL RIGHTS RESERVED WORLDWIDE.

www.marel.com

PROJ. TYPE: SENSOR X - SX25
CUSTOMER: SENSOR X SX25
COUNTRY:

PAGE DESCRI.: CABLE LIST
=REP REPORTS

LAST EDIT DATE:
2020.08.19

PAGE REV.
PROJ. REV.

SCALE: PAGE:
1:1 8

REVISED ON: 2020.08.19 BY:
CREATED ON: 2018.11.19 BY: GHJ

DWG. NO. 6002449
SHEET / TOTAL : (36 / 40)

| | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|---------|----------------|----------------------|------------------|--|--------------------|---------------|------|-----------|----------------|-----------------|
| POS.NO. | DEVICE TAG | MAREL AX NUMBER (IS) | MAREL PLM NUMBER | DESCRIPTION | MANUFACTURER | TYPE NUMBER | QTY. | LENGTH | ENCL. ITEM NO. | PAGE REFERENCE |
| 1 | =GEN+SOV-WBXX1 | 718-3702-Y2422PUR | 400003831 | CABLE CAN PUR 2X2X0,5mm ² | CEAM | 1978e | 1 | | | =GEN+SOV/9.6 |
| 2 | =GEN+SOV-WCXX1 | 718-3702-0011 | 400003826 | CABLE CONTROL PUR 4X0,5mm ² | CEAM | 2135e-0405354 | 1 | | | =GEN+SOV/9.2 |
| 3 | =GEN+AQ1-1 | 055-0010-0 | 400007116 | MOUNTING RAIL TS 35x15 487MM | RITTAL | SZ2318.000 | 1 | 308 mm 1 | | =GEN+AQ1 (+AQ1) |
| 4 | =GEN+AQ1-1 | 715-3302-11782300000 | 095145398 | TRIPLE-TIER TERMINAL ZDLD 2.5-2N | WEIDMULLER | ZDLD 2.5-2N | 6 | | 52 | =GEN+AQ1 (+AQ1) |
| 5 | =GEN+AQ1-2 | 055-0010-0 | 400007116 | MOUNTING RAIL TS 35x15 487MM | RITTAL | SZ2318.000 | 1 | 235 mm 2 | | =GEN+AQ1 (+AQ1) |
| 6 | =GEN+AQ1-3 | 055-0010-0 | 400007116 | MOUNTING RAIL TS 35x15 487MM | RITTAL | SZ2318.000 | 1 | 322 mm 3 | | =GEN+AQ1 (+AQ1) |
| 7 | =GEN+AQ1-7 | 721-4904-1030490 | 400007256 | CABLE DUCT HxW 60x25mm INSIDE | HAGER | BA760025 | 1 | 177 mm 7 | | =GEN+AQ1 (+AQ1) |
| 8 | =GEN+AQ1-8 | 721-4904-1030490 | 400007256 | CABLE DUCT HxW 60x25mm INSIDE | HAGER | BA760025 | 1 | 308 mm 8 | | =GEN+AQ1 (+AQ1) |
| 9 | =GEN+AQ1-9 | 721-4904-1030490 | 400007256 | CABLE DUCT HxW 60x25mm INSIDE | HAGER | BA760025 | 1 | 219 mm 9 | | =GEN+AQ1 (+AQ1) |
| 10 | =GEN+AQ1-10 | 721-4904-1030490 | 400007256 | CABLE DUCT HxW 60x25mm INSIDE | HAGER | BA760025 | 1 | 345 mm 10 | | =GEN+AQ1 (+AQ1) |
| 11 | =GEN+AQ1-11 | 721-4904-1030490 | 400007256 | CABLE DUCT HxW 60x25mm INSIDE | HAGER | BA760025 | 1 | 313 mm 11 | | =GEN+AQ1 (+AQ1) |
| 12 | =GEN+AQ1-12 | 721-4904-1030491 | 400007117 | CABLE DUCT HxW 60x40mm INSIDE | HAGER | BA760040 | 1 | 280 mm 43 | | =GEN+AQ1 (+AQ1) |
| 13 | =GEN+AQ1-13 | 721-4904-1030491 | 400007117 | CABLE DUCT HxW 60x40mm INSIDE | HAGER | BA760040 | 1 | 266 mm 44 | | =GEN+AQ1 (+AQ1) |
| 14 | =GEN+AQ1-14 | 721-4904-1030491 | 400007117 | CABLE DUCT HxW 60x40mm INSIDE | HAGER | BA760040 | 1 | 384 mm 45 | | =GEN+AQ1 (+AQ1) |
| 15 | =GEN+AQ1-. | 715-3303-1954000000 | 095147910 | END SUPPORT ZEW 35 | WEIDMULLER | ZEW 35 | 10 | | 12 | =GEN+AQ1 (+AQ1) |
| 16 | =GEN+AQ1-ER2 | 765-0340-1048232 | 400005050 | THERMOELECTRIC DEHUMIDIFIER | HOFFMAN | AVDR4SS4 | 1 | | | =GEN+AQ1/23.8 |
| 17 | =GEN+AQ1-FC1 | 717-4403-1051573 | 400011051 | CIRCUIT BREAKER 2P 10A | ABB | SU202M-C10 | 1 | | 59 | =GEN+AQ1/18.0 |
| 18 | =GEN+AQ1-FC1a | 717-4403-1051573 | 400011051 | CIRCUIT BREAKER 2P 10A | ABB | SU202M-C10 | 1 | | 60 | =GEN+AQ1/17.0 |
| 19 | =GEN+AQ1-FC1b | 717-4403-1051572 | 400010861 | CIRCUIT BREAKER 1P 4A | ABB | SU201M-C4 | 1 | | 53 | =GEN+AQ1/17.5 |
| 20 | =GEN+AQ1-FC2a | 400011050 | 400011050 | CIRCUIT BREAKER 2P 4A | ABB | SU202M-C4 | 1 | | 61 | =GEN+AQ1/17.2 |
| 21 | =GEN+AQ1-FC2b | 717-4403-1051572 | 400010861 | CIRCUIT BREAKER 1P 4A | ABB | SU201M-C4 | 1 | | 54 | =GEN+AQ1/17.5 |
| 22 | =GEN+AQ1-FC3a | 717-4403-1051573 | 400011051 | CIRCUIT BREAKER 2P 10A | ABB | SU202M-C10 | 1 | | 62 | =GEN+AQ1/17.7 |
| 23 | =GEN+AQ1-FC3b | 717-4403-1051572 | 400010861 | CIRCUIT BREAKER 1P 4A | ABB | SU201M-C4 | 1 | | 55 | =GEN+AQ1/17.6 |
| 24 | =GEN+AQ1-FC4b | 717-4403-1051572 | 400010861 | CIRCUIT BREAKER 1P 4A | ABB | SU201M-C4 | 1 | | 56 | =GEN+AQ1/17.7 |
| 25 | =GEN+AQ1-FC5b | 717-4403-1051572 | 400010861 | CIRCUIT BREAKER 1P 4A | ABB | SU201M-C4 | 1 | | 57 | =GEN+AQ1/17.7 |
| 26 | =GEN+AQ1-FC6b | 717-4403-1051571 | 400011047 | CIRCUIT BREAKER 1P 10A | ABB | SU201M-C10 | 1 | | 58 | =GEN+AQ1/17.8 |
| 27 | =GEN+AQ1-FE1 | 717-3400-1022409 | 400003755 | XPS-MC - SAFETY CONTROLLER | SCHNEIDER ELECTRIC | XPSMC32ZC | 1 | | 18 | =GEN+AQ1/19.0 |
| 28 | =GEN+AQ1-FE1 | 717-3400-1023402 | 400003756 | PLUG-IN SPRING CONNECTOR | SCHNEIDER ELECTRIC | XPS MCTC32 | 1 | | | =GEN+AQ1/19.0 |
| 29 | =GEN+AQ1-FE1 | 715-3005-00010 | 095425803 | CONNECTOR FEMALE- SUBCON 9/F-SH | PHOENIX CONTACT | SUBCON 9/F-SH | 1 | | | =GEN+AQ1/19.0 |
| 30 | =GEN+AQ1-FS1 | 717-3407-1023751 | 400003796 | MACHINE SAFETY SWITCH 2XNO M30X1,5 | ELOBAU | 171 V62V01 | 1 | | | =GEN+AQ1/19.2 |
| 31 | =GEN+AQ1-FS1 | 717-3407-1012325 | 4265925 | MAGNET FOR ELOBAU SENSOR | ELOBAU | 304 200 00 VH | 1 | | | =GEN+AQ1/19.2 |
| 32 | =GEN+AQ1-FS2 | 717-3407-1023751 | 400003796 | MACHINE SAFETY SWITCH 2XNO M30X1,5 | ELOBAU | 171 V62V01 | 1 | | | =GEN+AQ1/19.3 |
| 33 | =GEN+AQ1-FS2 | 717-3407-1012325 | 4265925 | MAGNET FOR ELOBAU SENSOR | ELOBAU | 304 200 00 VH | 1 | | | =GEN+AQ1/19.3 |
| 34 | =GEN+AQ1-FS3 | 717-3407-1023751 | 400003796 | MACHINE SAFETY SWITCH 2XNO M30X1,5 | ELOBAU | 171 V62V01 | 1 | | | =GEN+AQ1/19.4 |
| 35 | =GEN+AQ1-FS3 | 717-3407-1012325 | 4265925 | MAGNET FOR ELOBAU SENSOR | ELOBAU | 304 200 00 VH | 1 | | | =GEN+AQ1/19.4 |
| 36 | =GEN+AQ1-FS4 | 717-3407-1023751 | 400003796 | MACHINE SAFETY SWITCH 2XNO M30X1,5 | ELOBAU | 171 V62V01 | 1 | | | =GEN+AQ1/19.5 |
| 37 | =GEN+AQ1-FS4 | 717-3407-1012325 | 4265925 | MAGNET FOR ELOBAU SENSOR | ELOBAU | 304 200 00 VH | 1 | | | =GEN+AQ1/19.5 |
| 38 | =GEN+AQ1-FS5 | 717-3407-1023751 | 400003796 | MACHINE SAFETY SWITCH 2XNO M30X1,5 | ELOBAU | 171 V62V01 | 1 | | | =GEN+AQ1/19.6 |
| 39 | =GEN+AQ1-FS5 | 717-3407-1012325 | 4265925 | MAGNET FOR ELOBAU SENSOR | ELOBAU | 304 200 00 VH | 1 | | | =GEN+AQ1/19.6 |
| 40 | =GEN+AQ1-FS6 | 717-3407-1023751 | 400003796 | MACHINE SAFETY SWITCH 2XNO M30X1,5 | ELOBAU | 171 V62V01 | 1 | | | =GEN+AQ1/19.7 |
| 41 | =GEN+AQ1-FS6 | 717-3407-1012325 | 4265925 | MAGNET FOR ELOBAU SENSOR | ELOBAU | 304 200 00 VH | 1 | | | =GEN+AQ1/19.7 |
| 42 | =GEN+AQ1-FS7 | 717-3407-1023751 | 400003796 | MACHINE SAFETY SWITCH 2XNO M30X1,5 | ELOBAU | 171 V62V01 | 1 | | | =GEN+AQ1/19.8 |

previous:

8

next:

10

| | | | | | | | | |
|--|--|--|--|----------------------------|-----------|---|------------------|-----------------------------|
|  | THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL. | PROJ. TYPE: SENSOR X - SX25 CUSTOMER: SENSOR X SX25 COUNTRY: | PAGE DESCRI.: PARTS LIST =REP REPORTS | LAST EDIT DATE: 2020.08.19 | PAGE REV. | G | SCALE: 1:1 | PAGE: 9 |
| | | | | REVISED ON: 2018.11.19 | BY: GHJ | | DWG. NO. 6002449 | SHEET / TOTAL : (37 / 40) |
| © MAREL ALL RIGHTS RESERVED WORLDWIDE. www.marel.com | | | | | | | | |

| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | |
|---------|----------------|---------------------------|------------------|---|--------------------|-------------------|------|--------|----------------|----------------|
| POS.NO. | DEVICE TAG | MAREL AX NUMBER (IS) | MAREL PLM NUMBER | DESCRIPTION | MANUFACTURER | TYPE NUMBER | QTY. | LENGTH | ENCL. ITEM NO. | PAGE REFERENCE |
| 43 | =GEN+AQ1-FS7 | 717-3407-1012325 | 4265925 | MAGNET FOR ELOBAU SENSOR | ELOBAU | 304 200 00 VH | 1 | | | =GEN+AQ1/19.8 |
| 44 | =GEN+AQ1-FS8 | 717-3407-1023751 | 400003796 | MACHINE SAFETY SWITCH 2XNO M30X1,5 | ELOBAU | 171 V62V01 | 1 | | | =GEN+AQ1/19.9 |
| 45 | =GEN+AQ1-FS8 | 717-3407-1012325 | 4265925 | MAGNET FOR ELOBAU SENSOR | ELOBAU | 304 200 00 VH | 1 | | | =GEN+AQ1/19.9 |
| 46 | =GEN+AQ1-FS9 | 717-3407-1023751 | 400003796 | MACHINE SAFETY SWITCH 2XNO M30X1,5 | ELOBAU | 171 V62V01 | 1 | | | =GEN+AQ1/20.7 |
| 47 | =GEN+AQ1-FS9 | 717-3407-1012325 | 4265925 | MAGNET FOR ELOBAU SENSOR | ELOBAU | 304 200 00 VH | 1 | | | =GEN+AQ1/20.7 |
| 48 | =GEN+AQ1-FS10 | 717-3407-1023751 | 400003796 | MACHINE SAFETY SWITCH 2XNO M30X1,5 | ELOBAU | 171 V62V01 | 1 | | | =GEN+AQ1/20.8 |
| 49 | =GEN+AQ1-FS10 | 717-3407-1012325 | 4265925 | MAGNET FOR ELOBAU SENSOR | ELOBAU | 304 200 00 VH | 1 | | | =GEN+AQ1/20.8 |
| 50 | =GEN+AQ1-FS11 | 717-3407-1023751 | 400003796 | MACHINE SAFETY SWITCH 2XNO M30X1,5 | ELOBAU | 171 V62V01 | 1 | | | =GEN+AQ1/20.9 |
| 51 | =GEN+AQ1-FS11 | 717-3407-1012325 | 4265925 | MAGNET FOR ELOBAU SENSOR | ELOBAU | 304 200 00 VH | 1 | | | =GEN+AQ1/20.9 |
| 52 | =GEN+AQ1-KC1 | 4263855 | 4263855 | CONTROL PANEL M6315 MI980 & CAN | MAREL | M6315 MI980 & CAN | 1 | | | =GEN+SOV/10.1 |
| 53 | =GEN+AQ1-KC1 | 715-3005-00010 | 095425803 | CONNECTOR FEMALE- SUBCON 9/F-SH | PHOENIX CONTACT | SUBCON 9/F-SH | 1 | | | =GEN+SOV/10.1 |
| 54 | =GEN+AQ1-KR1 | 717-3406-1LC1D183BL | 400003782 | CONTACTOR 3P/18A 24VDC - SPRING TERMINALS | SCHNEIDER ELECTRIC | LC1-D183BL | 1 | | 63 | =GEN+AQ1/19.6 |
| 55 | =GEN+AQ1-KR2 | 717-3406-1012307 | 400003784 | RELAY 24V xx/DC 1XCO 6A | WEIDMULLER | TRZ 24VDC 1CO | 1 | | | =GEN+AQ1/21.3 |
| 56 | =GEN+AQ1-KR3 | 717-3406-1012307 | 400003784 | RELAY 24V xx/DC 1XCO 6A | WEIDMULLER | TRZ 24VDC 1CO | 1 | | 26 | =GEN+AQ1/21.4 |
| 57 | =GEN+AQ1-KR5 | 717-3406-1012307 | 400003784 | RELAY 24V xx/DC 1XCO 6A | WEIDMULLER | TRZ 24VDC 1CO | 1 | | 38 | =GEN+AQ1/21.6 |
| 58 | =GEN+AQ1-KR6 | 717-3406-1012307 | 400003784 | RELAY 24V xx/DC 1XCO 6A | WEIDMULLER | TRZ 24VDC 1CO | 1 | | 37 | =GEN+AQ1/21.7 |
| 59 | =GEN+AQ1-KR7 | 717-3406-1012307 | 400003784 | RELAY 24V xx/DC 1XCO 6A | WEIDMULLER | TRZ 24VDC 1CO | 1 | | 36 | =GEN+AQ1/21.5 |
| 60 | =GEN+AQ1-PL1 | 400014269 | 400014269 | 3 COLOR LIGHT RD, YE, GN | BANNER | K50LRGYP-806021 | 1 | | | =GEN+AQ1/22.0 |
| 61 | =GEN+AQ1-R1 | 711-2000-32205 | 400003735 | RESISTOR 2,2 KOHM 0,25 W | IHLUTIR | 711-2000-32205 | 1 | | | =GEN+AQ1/21.2 |
| 62 | =GEN+AQ1-R2 | 711-2000-32205 | 400003735 | RESISTOR 2,2 KOHM 0,25 W | IHLUTIR | 711-2000-32205 | 1 | | | =GEN+AQ1/21.1 |
| 63 | =GEN+AQ1-SC1 | 717-3405-1m22s-wrs | 400003776 | SWITCH SELECTOR, 2 POS. WITH KEY | EATON MOELLER | M22S-WRS | 1 | | | =GEN+AQ1/20.5 |
| 64 | =GEN+AQ1-SC1 | 717-3405-1m22-xc-r | 400003777 | KEY CODING ADAPTER | EATON MOELLER | M22-XC-R | 1 | | | =GEN+AQ1/20.5 |
| 65 | =GEN+AQ1-SC1 | 717-3404-1M22S-CK10+M22-A | 400003768 | CONTACT BLOCK+ ADAPTER, 1NO (CC,FF) | EATON MOELLER | M22-CK10+M22-A | 2 | | | =GEN+AQ1/20.5 |
| 66 | =GEN+AQ1-SE1 | 717-3405-1M22-PV+K01 | 400003773 | EMERGENCY-STOP PUSHBUTTON, 1NC | EATON MOELLER | M22-PV/K01 | 1 | | | =GEN+AQ1/20.2 |
| 67 | =GEN+AQ1-SP1 | 717-3406-0001 | 400003779 | ON-OFF SWITCH 3-POLE 25A | EATON MOELLER | P1-25/E | 1 | | | =GEN+AQ1/16.4 |
| 68 | =GEN+AQ1-SP1 | 717-3404-1012272 | 400003771 | AUXILIARY CONTACT BLOCK NEUTRAL 1NO | EATON MOELLER | N-P1E | 1 | | | =GEN+AQ1/16.4 |
| 69 | =GEN+AQ1-SP1 | 717-3405-1012295 | 400003778 | ON-OFF HANDLE, BLACK LOCKABLE | EATON MOELLER | SVB-SW-T0 | 1 | | | =GEN+AQ1/16.4 |
| 70 | =GEN+AQ1-SP2 | 717-3406-0001 | 400003779 | ON-OFF SWITCH 3-POLE 25A | EATON MOELLER | P1-25/E | 1 | | | =GEN+AQ1/16.4 |
| 71 | =GEN+AQ1-SP2 | 717-3404-1012272 | 400003771 | AUXILIARY CONTACT BLOCK NEUTRAL 1NO | EATON MOELLER | N-P1E | 1 | | | =GEN+AQ1/16.4 |
| 72 | =GEN+AQ1-SP2 | 717-3405-1012295 | 400003778 | ON-OFF HANDLE, BLACK LOCKABLE | EATON MOELLER | SVB-SW-T0 | 1 | | | =GEN+AQ1/16.4 |
| 73 | =GEN+AQ1-TF1 | 725-8400-1020401 | 400003843 | INVERTER 1-PH 0,37KW | LENZE | E84AVSCE3712SX0 | 1 | | 13 | =GEN+AQ1/18.1 |
| 74 | =GEN+AQ1-TF1 | 725-8400-1020427 | 400001196 | HMI FOR LENZE 8400 INVERTER | LENZE | EZAEBK1001 | 1 | | 14 | =GEN+AQ1/18.1 |
| 75 | =GEN+AQ1-TP1 | 719-3600-1026588 | 400005363 | POWER SUPPLY 1PH / 24VDC-20A | PULS | CPS20.241 | 1 | | 46 | =GEN+AQ1/17.7 |
| 76 | =GEN+AQ1-VF1 | 713-2900-1023406 | 400003736 | EMC FILTER 230V 6,0A | | FN2070-6-06 | 1 | | 42 | =GEN+AQ1/17.0 |
| 77 | =GEN+AQ1-WCAV1 | 718-3702-0009 | 400003823 | CABLE CONTROL PUR 12X0,5mm² | CEAM | 2135e-0405362 | 1 | | | =GEN+AQ1/21.7 |
| 78 | =GEN+AQ1-WCER2 | 718-3702-00105 | 400003825 | CABLE CONTROL PUR 2X0,5mm² | CEAM | 2135e-0405352 | 1 | | | =GEN+AQ1/23.8 |
| 79 | =GEN+AQ1-WCEX1 | 718-3702-0011 | 400003826 | CABLE CONTROL PUR 4X0,5mm² | CEAM | 2135e-0405354 | 1 | | | =GEN+AQ1/22.6 |
| 80 | =GEN+AQ1-WCKC1 | 718-3702-00105 | 400003825 | CABLE CONTROL PUR 2X0,5mm² | CEAM | 2135e-0405352 | 1 | | | =GEN+AQ1/23.4 |
| 81 | =GEN+AQ1-WCML3 | 718-3702-00105 | 400003825 | CABLE CONTROL PUR 2X0,5mm² | CEAM | 2135e-0405352 | 2 | | | =GEN+AQ1/23.7 |
| 82 | =GEN+AQ1-WCRA1 | 718-3701-0001 | 400003801 | CABLE POWER 2X0,75mm² | HELUKAPEL | black H03VV-F | 2 | | | =GEN+AQ1/19.5 |
| 83 | =GEN+AQ1-WCSE1 | 718-3702-0011 | 400003826 | CABLE CONTROL PUR 4X0,5mm² | CEAM | 2135e-0405354 | 2 | | | =GEN+AQ1/20.2 |
| 84 | =GEN+AQ1-WCSP2 | 718-3702-0011 | 400003826 | CABLE CONTROL PUR 4X0,5mm² | CEAM | 2135e-0405354 | 2 | | | =GEN+AQ1/20.3 |

previous:

9

next:

11

| | | | | | | | |
|---|---|-----------------------------|----------|--|----------------------------|-----------|--|
|  © MAREL ALL RIGHTS RESERVED WORLDWIDE. www.marel.com | <small>THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.</small> | PROJ. TYPE: SENSOR X - SX25 | | <small>PAGE DESCRIPT.: PARTS LIST REPORTS =REP</small> | LAST EDIT DATE: 2020.08.19 | PAGE REV. | <small>SCALE: 1:1 DWG. NO. 6002449 SHEET / TOTAL : (38 / 40)</small> |
| | | CUSTOMER: SENSOR X SX25 | COUNTRY: | | REVISED ON: 2018.11.19 | BY: GHJ | |
| | | | | | CREATED ON: 2018.11.19 | BY: GHJ | |

| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | |
|---------|-----------------|----------------------|------------------|--|-----------------|------------------------------|------|----------|----------------|-----------------|
| POS.NO. | DEVICE TAG | MAREL AX NUMBER (IS) | MAREL PLM NUMBER | DESCRIPTION | MANUFACTURER | TYPE NUMBER | QTY. | LENGTH | ENCL. ITEM NO. | PAGE REFERENCE |
| 85 | =GEN+AQ1-WCXB2 | 718-3702-00105 | 400003825 | CABLE CONTROL PUR 2X0,5mm ² | CEAM | 2135e-0405352 | 1 | | | =GEN+AQ1/23.2 |
| 86 | =GEN+AQ1-WMM1 | 718-3701-0042 | 400003816 | CABLE MOTOR PUR 4X1,0mm ² +2X0,5mm ² | CEAM | 1864e | 1 | 10 m | | =GEN+AQ1/18.0 |
| 87 | =GEN+AQ1-WMM1.1 | 718-3702-0006 | 400003820 | CABLE CONTROL 4X0,22mm ² | NEXANS | AK53192019 | 1 | | | =GEN+AQ1/21.1 |
| 88 | =GEN+AQ1-WPER1 | 718-3701-0003 | 400003802 | CABLE POWER 3X0,75mm ² | HELUKAPEL | H03VV-F | 1 | | | =GEN+AQ1/17.3 |
| 89 | =GEN+AQ1-WPEX1 | 718-3703-1029677 | 400003832 | CABLE POWER W/ANGLE PLUG 3X1mm ² | NICK ELECTRONIC | gi25,5-H05VVF3G1.00-C1BW/5,0 | | | | =GEN+AQ1/17.0 |
| 90 | =GEN+AQ1-X0 | 715-3302-17904190000 | 400003747 | TERMINAL, BLUE ZDU 4/3AN BL | WEIDMULLER | ZDU 4/3AN BL | 1 | 29 | | =GEN+AQ1 (+AQ1) |
| 91 | =GEN+AQ1-X0 | 715-3303-1954000000 | 095147910 | END SUPPORT ZEW 35 | WEIDMULLER | ZEW 35 | 2 | 12 | | =GEN+AQ1 (+AQ1) |
| 92 | =GEN+AQ1-X0 | 715-3302-17904180000 | 400001160 | TERMINAL ZDU 4/3AN | WEIDMULLER | ZDU 4/3AN | 2 | 30;31 | | =GEN+AQ1 (+AQ1) |
| 93 | =GEN+AQ1-X1 | 715-3303-1954000000 | 095147910 | END SUPPORT ZEW 35 | WEIDMULLER | ZEW 35 | 2 | 12 | | =GEN+AQ1 (+AQ1) |
| 94 | =GEN+AQ1-X1 | 715-3302-17904170000 | 400003745 | TERMINAL EARTH ZPE 4/3AN | WEIDMULLER | ZPE 4/3AN | 2 | 28 | | =GEN+AQ1 (+AQ1) |
| 95 | =GEN+AQ1-X1 | 715-3302-17904180000 | 400001160 | TERMINAL ZDU 4/3AN | WEIDMULLER | ZDU 4/3AN | 3 | 30..32 | | =GEN+AQ1 (+AQ1) |
| 96 | =GEN+AQ1-X1 | 715-3302-11608660000 | 400003180 | TERMINAL EARTH ZPE 2.5/4AN | WEIDMULLER | ZPE 2.5/4AN | 1 | 33 | | =GEN+AQ1 (+AQ1) |
| 97 | =GEN+AQ1-X1 | 715-3302-11608570000 | 400003183 | FEED-THROUGH TERMINAL ZDU 2,5/4AN | WEIDMULLER | ZDU 2,5/4AN | 2 | 34;35 | | =GEN+AQ1 (+AQ1) |
| 98 | =GEN+AQ1-X1 | 715-3302-17904190000 | 400003747 | TERMINAL, BLUE ZDU 4/3AN BL | WEIDMULLER | ZDU 4/3AN BL | 1 | 29 | | =GEN+AQ1 (+AQ1) |
| 99 | =GEN+AQ1-X10 | 715-3303-1954000000 | 095147910 | END SUPPORT ZEW 35 | WEIDMULLER | ZEW 35 | 2 | 12 | | =GEN+AQ1 (+AQ1) |
| 100 | =GEN+AQ1-X10 | 715-3302-11782300000 | 095145398 | TRIPLE-TIER TERMINAL ZDLD 2.5-2N | WEIDMULLER | ZDLD 2.5-2N | 27 | 39 | | =GEN+AQ1 (+AQ1) |
| 101 | =GEN+AV1-3 | 055-0010-0 | 400007116 | MOUNTING RAIL TS 35x15 487MM | RITTAL | SZ2318.000 | 1 | 358 mm 3 | | =GEN+AV1 (+AV1) |
| 102 | =GEN+AV1-4 | 055-0010-0 | 400007116 | MOUNTING RAIL TS 35x15 487MM | RITTAL | SZ2318.000 | 1 | 198 mm 4 | | =GEN+AV1 (+AV1) |
| 103 | =GEN+AV1-. | 715-3303-1954000000 | 095147910 | END SUPPORT ZEW 35 | WEIDMULLER | ZEW 35 | 6 | 5...10 | | =GEN+AV1 (+AV1) |
| 104 | =GEN+AV1-BH1 | ELM-ESEN-MT1820-2M | 6131905 | TEMPERATUR SENSOR MT1820 | | DS18S20+ | 1 | | | =GEN+AV1/27.8 |
| 105 | =GEN+AV1-KD1 | ELM-ECAN-MCS816 | 400003933 | MODULE, I/O MCS816 | MAREL | MCS816 | 1 | 18 | | =GEN+SOV/10.0 |
| 106 | =GEN+AV1-KD2 | 4668755 | 4668755 | MODULE, I/O MCSTEP2 | MAREL | MCSTEP2 | 1 | 22 | | =GEN+AV1/25.6 |
| 107 | =GEN+AV1-KD3 | 4668755 | 4668755 | MODULE, I/O MCSTEP2 | MAREL | MCSTEP2 | 1 | 23 | | =GEN+AV1/25.7 |
| 108 | =GEN+AV1-KE1 | elm-enet-es5 | 400003944 | ETHERNET SWITCH, 5-PORTS, 24VDC | MAREL | ES5 | 1 | 17 | | =GEN+SOV/11.2 |
| 109 | =GEN+AV1-KV1 | 750-1010-1023776 | 400003869 | VALVE SV10 BLOCK X4 (4 VALVES) | SMC | 750-SV10-00100410 | 1 | | | =GEN+AV1/27.3 |
| 110 | =GEN+AV1-KV1 | 750-1020-1020595 | 400003878 | VALVE SV20 BLOCK X4 (4 VALVES) | SMC | 750-1020-1020595 | 1 | 12 | | =GEN+AV1 (+AV1) |
| 111 | =GEN+AV1-KV2 | 750-SV20-21005FU | 400003882 | VALVE SV20 SOLENOID | SMC | SV2100-5FU | 1 | | | =GEN+AV1/27.3 |
| 112 | =GEN+AV1-KV2 | 750-SV20-503AC6 | 400003883 | VALVE SV20 BASE | SMC | SV2000-50-3A-C6 | 1 | | | =GEN+AV1/27.3 |
| 113 | =GEN+AV1-KV3 | 750-SV20-21005FU | 400003882 | VALVE SV20 SOLENOID | SMC | SV2100-5FU | 1 | | | =GEN+AV1/27.4 |
| 114 | =GEN+AV1-KV3 | 750-SV20-503AC6 | 400003883 | VALVE SV20 BASE | SMC | SV2000-50-3A-C6 | 1 | | | =GEN+AV1/27.4 |
| 115 | =GEN+AV1-KV4 | 750-SV20-21005FU | 400003882 | VALVE SV20 SOLENOID | SMC | SV2100-5FU | 1 | | | =GEN+AV1/27.5 |
| 116 | =GEN+AV1-KV4 | 750-SV20-503AC6 | 400003883 | VALVE SV20 BASE | SMC | SV2000-50-3A-C6 | 1 | | | =GEN+AV1/27.5 |
| 117 | =GEN+AV1-KW1 | 718-3703-1012364 | 400003833 | CABLE FOR WATER VALVE 3X0,5mm ² , L=3M | SMC | AB2AA2U1309 | 1 | | | =GEN+AV1/26.5 |
| 118 | =GEN+AV1-R1 | 711-2000-21205 | 400003733 | RESISTOR 120/OHM 0,25 W | FIRSTRONICS | RD14JN121T52 | 1 | | | =GEN+SOV/10.4 |
| 119 | =GEN+AV1-R2 | 711-2000-21205 | 400003733 | RESISTOR 120/OHM 0,25 W | FIRSTRONICS | RD14JN121T52 | 1 | | | =GEN+SOV/10.3 |
| 120 | =GEN+AV1-RA1 | 752-9000-1040016 | 4317873 | FILTER/PRESSURE REG. | SMC | AR20-F02EH-R | 1 | 21 | | =GEN+AQ1/19.5 |
| 121 | =GEN+AV1-WBBX1 | 718-3702-Y2422PUR | 400003831 | CABLE CAN PUR 2X2X0,5mm ² | CEAM | 1978e | 1 | | | =GEN+SOV/10.4 |
| 122 | =GEN+AV1-WBFE1 | 718-3702-Y2422PUR | 400003831 | CABLE CAN PUR 2X2X0,5mm ² | CEAM | 1978e | 1 | | | =GEN+SOV/10.5 |
| 123 | =GEN+AV1-WBKC1 | 718-3702-Y2422PUR | 400003831 | CABLE CAN PUR 2X2X0,5mm ² | CEAM | 1978e | 1 | | | =GEN+SOV/10.1 |
| 124 | =GEN+AV1-WBTF1 | 718-3702-Y2422PUR | 400003831 | CABLE CAN PUR 2X2X0,5mm ² | CEAM | 1978e | 1 | | | =GEN+SOV/10.5 |
| 125 | =GEN+AV1-WCKW1 | 718-3703-1012364 | 400003833 | CABLE FOR WATER VALVE 3X0,5mm ² , L=3M | SMC | AB2AA2U1309 | 1 | 3 m | | =GEN+AV1/26.5 |
| 126 | =GEN+AV1-WCML1 | 718-3702-0011 | 400003826 | CABLE CONTROL PUR 4X0,5mm ² | CEAM | 2135e-0405354 | 1 | | | =GEN+AV1/25.6 |

previous:
10next:
12

previous
11

next:



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

PROJ. TYPE: SENSOR X - SX25
CUSTOMER: SENSOR X SX25
COUNTRY:

GE DESCRIPTIVE: PARTS LIST
REP REPORTS

LAST EDIT DATE:
020.08.19

PAGE REV.

LE: PAGE: 1

12

6002449

© MAPE

MAREL.

www.marel.com

1

Marel ehf
Austurhraun 9
IS-210 Gardabear

Iceland
T: +354 563 8000
F: +354 563 8001
I: www.marel.com



ELECTRICAL DIAGRAM SENSOR X CONV. SYSTEM SX302/502

2012-101

3X230+PE/3X400+N+PE

DRAWING/BOM NO.: 2012-101-00002-02

| | | | | | |
|------------------------------|---|----------------|------------------|---|--------------|
| REFERENCE DRAWING NUMBER | : | - | BASIC FEEDBACK | : | - |
| DIMENSIONS OF ENCLOSURE [mm] | : | - | | | |
| CUSTOMER | : | STANDARD | | | |
| CUSTOMER CITY | : | - | | | |
| CUSTOMER STATE | : | - | | | |
| CUSTOMER COUNTRY | : | - | | | |
| AX ITEM NUMBER: | : | 2012-101-00002 | | | |
| AX REFERENCE NUMBER: | : | - | | | |
| NUMBER OF PAGES | : | 32 | EDITED BY | : | |
| HARDWARE ENGINEER | : | KRUN | EDIT DATE | : | (YYYY-MM-DD) |
| CREATED ON | : | 2014.09.30 | PROJECT REVISION | : | |

STRUCTURE IDENTIFIER OVERVIEW

previous:

1



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF

PROJ. TYPE: 2012-101
CUSTOMER: STANDARD
COUNTRY:

PAGE DESC.: STRUCTURE IDENTIFIER OVERVIEW
=GEN GENERAL INFORMATION

LAST EDIT DATE:

PAGE REV.

SCALE: PAGE:
1: 1

2

© MAREL 2014. ALL RIGHTS RESERVED WORLDWIDE

www.mare.com

next:

3

BWS-NQ 2012-101-00002-02

DWG. NO. 2012-
SHEET / TOTAL :

TABLE OF CONTENTS

Column X: An automatically generated page was edited

| PAGE | HIGHER-LEVEL FUNCTION (=) | MOUNTING LOCATION (+) | PAGE DESCRIPTION | EDITED BY | EDIT DATE | X |
|------|---------------------------|-----------------------|---|-----------|------------|---|
| 1 | GENERAL INFORMATION | | TITLE PAGE | | 2017.02.22 | |
| 2 | GENERAL INFORMATION | | STRUCTURE IDENTIFIER OVERVIEW | | 2017.02.22 | |
| 3 | GENERAL INFORMATION | | TABLE OF CONTENTS | | 2017.02.22 | |
| 4 | GENERAL INFORMATION | | PROJECT SPECIFICATION | | 2017.02.22 | |
| 5 | GENERAL INFORMATION | | PROJECT SPECIFICATION | | 2017.02.22 | |
| 6 | GENERAL INFORMATION | | TAG PLATES | | 2017.02.22 | |
| 6 | GENERAL INFORMATION | SYSTEM OVERVIEW | CONNECTION DIAGRAMS | | 2017.02.22 | |
| 7 | GENERAL INFORMATION | SYSTEM OVERVIEW | CAN OVERVIEW, SX302/502 BASIC FEEDBACK | | 2017.02.22 | |
| 8 | GENERAL INFORMATION | SYSTEM OVERVIEW | ETHERNET OVERVIEW, SYSTEMS | | 2017.02.22 | |
| 9 | GENERAL INFORMATION | SYSTEM OVERVIEW | SYSTEM LAYOUT, CABLES, SX302/502 BASIC FEEDBACK | | 2017.02.22 | |
| 10 | GENERAL INFORMATION | SYSTEM OVERVIEW | SYSTEM LAYOUT, SX302/502 BASIC FEEDBACK | | 2017.02.22 | |
| 11 | GENERAL INFORMATION | CONVEYOR CABINET | CABINET LAYOUT | | 2017.02.22 | |
| 12 | GENERAL INFORMATION | CONVEYOR CABINET | TERMINAL STRIP, SYSTEMS | | 2017.02.22 | |
| 13 | GENERAL INFORMATION | CONVEYOR CABINET | CONTROL BOX LAYOUT +AC1 | | 2017.02.22 | |
| 14 | GENERAL INFORMATION | CONVEYOR CABINET | POWER CIRCUIT, INPUT | | 2017.02.22 | |
| 15 | GENERAL INFORMATION | CONVEYOR CABINET | POWER CIRCUIT, MOTORS, SX302/502 BASIC FEEDBACK | | 2017.02.22 | |
| 16 | GENERAL INFORMATION | CONVEYOR CABINET | SAFETY CIRCUIT | | 2017.02.22 | |
| 17 | GENERAL INFORMATION | CONVEYOR CABINET | CONTROL CIRCUIT, SYSTEMS | | 2017.02.22 | |
| 18 | GENERAL INFORMATION | CONVEYOR CABINET | CONTROL CIRCUIT, INVERTERS SX302/502 BASIC FEEDBACK | | 2017.02.22 | |
| 19 | GENERAL INFORMATION | CONVEYOR CABINET | CONTROL CIRCUIT, I/O'S SX302/502 BASIC FEEDBACK | | 2017.02.22 | |
| 20 | GENERAL INFORMATION | CONVEYOR CABINET | CONTROL CIRCUIT, WORK LIGHTS 1-2 | | 2017.02.22 | |
| 21 | REPORTS | | PLC LIST | | 2017.02.22 | |
| 22 | REPORTS | | CABLE OVERVIEW | | 2017.02.22 | |
| 23 | REPORTS | | CABLE OVERVIEW | | 2017.02.22 | |
| 24 | REPORTS | | CABLE LIST | | 2017.02.22 | |
| 25 | REPORTS | | CABLE LIST | | 2017.02.22 | |
| 26 | REPORTS | | CABLE LIST | | 2017.02.22 | |
| 27 | REPORTS | | CABLE LIST | | 2017.02.22 | |
| 28 | REPORTS | | CABLE LIST | | 2017.02.22 | |
| 29 | REPORTS | | CABLE LIST | | 2017.02.22 | |
| 30 | REPORTS | | PARTS LIST | | 2017.02.22 | |
| 31 | REPORTS | | PARTS LIST | | 2017.02.22 | |
| | | | | | | |

previous:

2

next:

4



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL 2014 ALL RIGHTS RESERVED WORLDWIDE.

www.marel.com

PROJ. TYPE: 2012-101
CUSTOMER: STANDARD
COUNTRY: -

PAGE DESC.: TABLE OF CONTENTS
=GEN GENERAL INFORMATION

LAST EDIT DATE:
2017.02.22

PAGE REV.
PROJ. REV.

SCALE: PAGE:
1:1 3

REVISED ON:
CREATED ON: 2014.09.30

BY:
BY: KRUN
DWG. NO. 2012-101-00002-02
SHEET / TOTAL : (3 / 32)

| Ethernet Cable RJ-45 8-pin plug or 4-pin plug | | | |
|--|-------|----------------|-------|
| 8-Pin | 4-Pin | Signal | Wire |
| 1 | 1 | Tx+ (Transmit) | WH/OG |
| 2 | 2 | Tx- (Transmit) | OG |
| 3 | 3 | Rx+ (Receive) | WH/GN |
| 4 | | Not used | BU |
| 5 | | Not used | WH/BU |
| 6 | 4 | Rx- (Receive) | GN |
| 7 | | Not used | WH/BN |
| 8 | | Not used | BN |

| Can connections (Combicon Plug) | | |
|------------------------------------|--------------|------|
| Pin | Signal | Wire |
| 1 | V+ (24Vdc) | RD |
| 2 | C+ (Can Hi) | WH |
| 3 | Screen | SH |
| 4 | C- (Can Low) | BU |
| 5 | V- (0V) | BK |

| Can connections (9-pin Plug) | | |
|---------------------------------|--------------|------|
| Pin | Signal | Wire |
| 2 | C- (Can Low) | BU |
| 3 | V- (0V) | BK |
| 7 | C+ (Can Hi) | WH |
| | | |
| | | |

| Serial Bus | | |
|------------|--------|------|
| Pin | Signal | Wire |
| 2 | RX/TX | YE |
| 3 | TX/RX | GN |
| 5 | 0V | BU |
| | | |
| | | |

Control cable wire Colour/Number comparison table

Reference table between Colours and Numbers if data from cable in document is incomplete.

| Colour code | Numbers |
|---------------|---------|
| Blue | BU |
| Red | RD |
| Green | GN |
| Yellow | YE |
| White | WH |
| Black | BK |
| Brown | BN |
| Violet | VT |
| Orange | OG |
| Pink | PK |
| Cyan | CY |
| Grey | GY |
| Red/Blue | RD/BU |
| Green/Red | GN/RD |
| Yellow/Red | YE/RD |
| White/Red | WH/RD |
| Red/Black | RD/BK |
| Red/Brown | RD/BN |
| Yellow/Blue | YE/BU |
| White/Bue | WH/BU |
| Blue/Black | BU/BK |
| Orange/Blue | OG/BU |
| Yellow/Green | YE/GN |
| White/Green | WH/GN |
| Orange/Green | OG/GN |
| Green/Blue | GN/BU |
| Grey/Blue | GY/BU |
| Green/Black | GN/BK |
| Grey/Green | GY/GN |
| Yellow/Brown | YE/BN |
| White/Brown | WH/BN |
| Brown/Black | BN/BK |
| Grey/Brown | GY/BN |
| Yellow/Violet | YE/VT |
| Violet/Black | VT/BK |
| White/Violet | WH/VT |

Other wire codes

| | |
|-------------------|-------|
| Green/Yellow (PE) | GN/YE |
| Screen | SH |
| Transparent | TP |
| Beige | BE |
| | |
| | |
| | |

INTERNAL WIRE SPECIFICATION

REMARK: USE UL(MTW) WIRE,
RATED VOLTAGE UL (AWM) U:600V, UL (MTW) U:600V

| Wiring type | Colour | Cross section |
|---|--|--|
| Main current: Phase 1-3 Phase Neutral | Black Light blue | Min. 2,5mm ² Min. 2,5mm ² |
| Control current: Vac Phase, Voltage = mains Phase, Voltage < mains Switched Zero (0Vac) | Black Red Red White | Min. 2,5mm ² Min. 1mm ² Min. 1mm ² Min. 1mm ² |
| Vdc +Vdc -Vdc Switched Zero (0Vdc) | Dark Blue Dark Blue Dark Blue White/Blue | Min. 1mm ² Min. 1mm ² Min. 1mm ² Min. 1mm ² |
| External source voltage | Orange | Min. 1mm ² |
| Earthing: Main current Control current Door earthing Phase < 16mm ² Phase 16 - 35mm ² Phase 35 - 400mm ² | Yellow/Green Yellow/Green Yellow/Green Yellow/Green Yellow/Green Yellow/Green | Min. 2,5mm ² Min. 1mm ² Min. 6mm ² Min. equal to ph. Min. 16mm ² |
| Screening: No earth wire | Black shrink-wrap (Yellow/Green not allowed) | |

previous:
3

next:
5

DEVICE TAG EXPLANATION

FIRST LETTER IS ACCORDING IEC-EN-81346

SECOND LETTER IS MAREL SUBCLASS DEFINITION FOR E-PARTS

| LETTER CODE | DESCRIPTION / EXAMPLES | LETTER CODE | DESCRIPTION / EXAMPLES | LETTER CODE | DESCRIPTION / EXAMPLES |
|----------------|--|----------------|---|----------------|--|
| A | TWO OR MORE PURPOSES OR TASKS | G | INITIATING FLOW OF ENERGY | S | CONVERTING MANUAL OPERATION TO SIGNAL |
| AG | GENERAL ACESORIES (PANEL ASSEMBLY COMPONENTS) | GB | BATTERY / UPS | SC | CONTROL SWITCH (PUSHBUTTON, SELECTOR SWITCH) |
| AK | CONTROL PANEL I/O AND ANALOG PROCESSING | K | PROCESSING SIGNALS | SE | EMERGENCY STOP, PULL CORD |
| AP | DISPLAY / TOUCH SCREEN / SIGNAL LIGHT BOX / OPERATOR PANEL | KA | ANALOG I/O UNITS | SK | KEYBOARD |
| AQ | POWER PANEL INCLUDES MAIN VOLTAGE | KB | BUS INTERFACE | SS | SAFETY SWITCH |
| AS | SWITCH BOX (BOX WITH A SINGLE SWITCH) | KC | PROGRAMMABLE CONTROLLER | | |
| AT | TRANSFORMER PANEL / BOX | KD | DIGITAL I/O UNITS | | |
| AV | VALVE PANEL / BOX | KE | ETHERNET SWITCH / ROUTERS / GATEWAYS | T | CONVERSION OF ENERGY |
| AW | CONTROL PANEL WEIGHING | KF | FILTER (EMC, LINE, LOAD) | TA | AMPLIFIER |
| AX | JUNCTION BOX / TERMINAL BOX | KH | ENVIRONMENTAL CNTR. (THERMOSTAT, HUMIDITY) | TC | SIGNAL CONVERSION |
| AY | OTHERS | KR | RELAY, GENERAL | TD | DIAGNOSTIC ADAPTER (CAN, ETHERNET) |
| AZ | BACKPLATE, MOUNTING PLATE | KO | RELAY, OPTO | TF | MOTOR CONTROLLER (FREQ. INVERTER, SERVO) |
| | | KP | RELAY, SOLID STATE | TP | POWER SUPPLY, DC |
| B | CONVERTING INPUT TO SIGNAL | KS | RELAY, SAFETY / CONTROLLER | TV | VIBRATOR CONTROLLER |
| BA | GAS / LIQUID PRESSURE (E.G. AIR, WATER) | KT | RELAY, TIMER | TT | TRANSFORMER |
| BB | SAFETY LIGHT BEAM/CURTAIN | KV | VALVE, SOLENOID | | |
| BD | DIFFUSE PHOTO SENSOR | M | PROVIDING MECHANICAL ENERGY | U | KEEPING OBJECTS IN POSITION |
| BE | ENCODER/RESOLVER | MA | CYLINDER / ACTUATORS | UU | HOLDING / SUPPORT BRACKETS (INSULATOR) |
| BF | LEVEL, FLOAT SWITCH | ML | LOW VOLTAGE MOTORS (<50V) | | |
| BH | HEAT PROBE TEMPERATURE | MT | MOTORS, WITH INTEGRATED FREQUENCY INVERTER | V | PROCESSING, TREATING MATERIALS |
| BK | MECHANICAL SWITCH (MICRO, LIMIT SWITCH) | MS | MOTOR, SERVO | VF | NON ELECTRICAL |
| BL | LOADCELL | M | MOTORS, GENERAL (>50V) | | |
| BM | INDUCTIVE PROXIMITY SENSOR | P | PRESENTING INFORMATION | W | TRANSPORTING ENERGY, SIGNALS, MATERIALS |
| BN | CAPACITIVE PROXIMITY SENSOR | PD | OPERATOR INTERFACE (HMI, HIM ETC.) | WA | CABLE ASSEMBLY (E.G. CABLE LOOMS) |
| BO | REED CONTACT/MAGNET SENSOR | PJ | AUDIBLE PRESENTATION (BELL, SIRENE, HORN) | WB | BUS CABLES (CAN, ETHERCAT) |
| BP | PHOTO SENSOR RX/TX | PL | VISUAL PRESENTATION (SIGNAL LIGHT, LED, MIMIC PANELS) | WC | CONTROL CABLES (<50V) |
| BR | REFLECTIVE PHOTO SENSOR | PM | PANEL METERS (AMPS, VOLTS, WATTS, HOURS, PRESSURE) | WE | ETHERNET CABLES |
| BS | SAFETY SENSOR (INTRINSICALLY SAFETY FUNCTION) | PP | PRINTER | WM | MOTOR CABLES |
| BT | TAG READER (RF-ID) | | | WP | POWER CABLES (>50V) |
| BU | ULTRASONIC SENSOR | | | WX | PREFABRICATED CABLES |
| BV | VISION | | | W | CABLE, GENERAL |
| BX | X-RAY SENSOR | Q | CONTROLLED SWITCHING ENERGY | | |
| BZ | LASER SENSOR | QC | POWER CONTACTORS | X | CONNECTING OBJECTS |
| | | QF | MOTOR CIRCUIT BREAKER | XB | BUS CONNECTION MODULE |
| C | STORING ENERGY | QM | MOTOR STARTER / SOFT STARTER | XC | CONTROL CONNECTOR (<50V) |
| CA | GAS / LIQUID RESERVOIR (E.G. AIR, WATER) | QR | POWER SWITCH (DISCONNECT) | XD | I/O CONNECTION MODULE |
| CC | CAPACITORS | QP | MOTOR PROTECTION | XF | AIR FITTINGS |
| CM | MEMORY | | | XG | WIRE TERMINATION ACCESSORIES (FERULE, WIRE NUMBER) |
| E | THERMAL / RADIANT ENERGY | R | RESTRICTING / STABILIZING MOTION OR ENERGY | XP | POWER CONNECTOR (>50V) |
| EF | AIR CONDITIONER / HEAT EXCHANGER | RA | AIR PRESSURE REGULATOR | X | TERMINALS |
| EL | LIGHTS/LAMPS | RD | DIODE | | |
| ER | HEATER (RESISTANCE) | RR | RESISTOR | | |
| EX | X-RAY GENERATOR | RY | INDUCTOR | | |
| EZ | LASER | | | | |
| F | SELF ACTING PROTECTION | | | | |
| FC | MINIATURE CIRCUIT BREAKER | | | | |
| FO | MOTOR OVERLOAD | | | | |
| FF | FUSE | | | | |
| FM | PROTECTING MODULE CLASS 2 | | | | |
| FN | SURGE PROTECTION | | | | |
| FV | VOLTAGE MONITORING | | | | |

previous:

4

next:

6

Marel ehf

Austurhraun 9 IS-210 Gardabær Iceland

Machine **SENSOR X CONV. SYSTEM SX302/502**

Model **2012-101-00002** Year **2014**

Type **2012-101** Serial no. **[]**

Voltage **3X230+PE/3X400+N+PE** Short circuit rating **5 KA**

Frequency **50/60 Hz** Largest motor FLA **2 A** Enclosure prot. rating **IP46**

Current **15,7/8,8 A** EL. diagr. no. **2012-101-00002-02**

For mobile machinery Nominal power **[]** Mass of Machinery **[]**

www.marel.com

previous:

5next:
+SOV/6

THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL 2014 ALL RIGHTS RESERVED WORLDWIDE.

www.marel.com

PROJ. TYPE: **2012-101**
CUSTOMER: **STANDARD**
COUNTRY: **-**

PAGE DESC.: **TAG PLATES
=GEN GENERAL INFORMATION**


LAST EDIT DATE:
2017.02.22

PAGE REV.
PROJ. REV.


SCALE: **PAGE:
1:1**
DWG. NO. **2012-101-00002-02**

6SHEET / TOTAL : **(5 / 32)**


EXAMPLE 1





EXAMPLE 2



EXAMPLE 3

previous:
+/6next:
7



| CAN CONNECTIONS | | |
|-----------------|-------------|------|
| PIN | SIGNAL | WIRE |
| 1 | V+ (24VDC) | RD |
| 2 | C+ (CAN HI) | WH |
| 3 | SCREEN | SH |
| 4 | C- (CAN LO) | BU |
| 5 | V- (0V) | BK |

NOTE:
CAN TERMINATION RESISTORS R1 AND R2
ARE PLACED AT EACH END OF CAN NETWORK.


previous:

6

next:

8

MONITORS OPTION




| Ethernet Cable RJ-45 8-pin plug or 4-pin plug | | | |
|--|-------|----------------|-------|
| 8-Pin | 4-Pin | Signal | Wire |
| 1 | 1 | Tx+ (Transmit) | WH/OR |
| 2 | 2 | Tx- (Transmit) | OR |
| 3 | 3 | Rx+ (Receive) | WH/GN |
| 4 | | Not used | BU |
| 5 | | Not used | WH/BU |
| 6 | 4 | Rx- (Receive) | GN |
| 7 | | Not used | WH/BN |
| 8 | | Not used | BN |

previous:

7

next:

9




previous:

8

next:



10




previous:

9

next:
+AQ2/11


previous:
+SOV/10next:
12

POWER CIRCUIT -X1




20 PCS.

POWER CIRCUIT -X2




POTENTIAL FREE CONTACT

CONTROL CIRCUIT -X10




25 PCS.

CONTROL CIRCUIT -X11




5 PCS.

-XTF3



CONTROL CIRCUIT -XTF3

-XTF4



CONTROL CIRCUIT -XTF4


=CBELT

+AC1


-XAC1

=MON

-XRM




CONTROL CIRCUIT -XRM



5 PCS. -XAC1

previous:
11next:
13

+AC1**-SE1**

previous:

12

next:

14



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL 2014 ALL RIGHTS RESERVED WORLDWIDE.

www.marel.com

PROJ. TYPE: 2012-101

CUSTOMER: STANDARD

COUNTRY: -

PAGE DESCRI.: CONTROL BOX LAYOUT +AC1

=GEN GENERAL INFORMATION

+AQ2 CONVEYOR CABINET

LAST EDIT DATE:

2017.02.22

PAGE REV.

PROJ. REV.


SCALE: PAGE:

1:1

13

DWG. NO. 2012-101-00002-02


SHEET / TOTAL : (13 / 32)



previous:
13


next:
15

-X2 = 230VAC FOR SERVICE -X10 = 24VDC CONTROL CIRCUIT




previous:
14

next:
16



previous:
15

next:
17




previous:

16

next:

18










previous:

17

next:



19

=CBELT
+AC1



MONITORS OPTION

OPTIONAL
POTENTIAL FREE
CONTACT



OPTIONAL OVERFLOW

NOTE!

10mm AIR SUPPLY FROM
X-RAY MACHINE

OVERFLOW


OPTIONAL

previous:

18

next:

20



previous:

19

next:

=REP+/21

| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|--------------------|---------------|---------------|---------------|-------------|-----------------|-----------------------|----------------|----------------|--------------------------|
| I/O PAGE REFERENCE | I/O UNIT NAME | I/O UNIT TYPE | I/O UNIT PLUG | CAN ADDRESS | SIGNAL FUNCTION | COMPONENT CONN. POINT | COMPONENT NAME | COMPONENT TYPE | COMPONENT PAGE REFERENCE |
| =GEN+AQ2/19.1 | =GEN+AQ2-KD1 | MSC816 | -X11 | O 8 11 | | | | | |
| =GEN+AQ2/19.1 | =GEN+AQ2-KD1 | MSC816 | -X11 | I 8 11 | | 4 | =CBELT+AC1-BP1 | RX | =GEN+AQ2/19.1 |
| =GEN+AQ2/19.3 | =GEN+AQ2-KD1 | MSC816 | -X12 | O 8 12 | | | | | |
| =GEN+AQ2/19.3 | =GEN+AQ2-KD1 | MSC816 | -X12 | I 8 12 | | 4 | =REW+AQ2-BP2 | RX | =GEN+AQ2/19.3 |
| =GEN+AQ2/19.5 | =GEN+AQ2-KD1 | MSC816 | -X13 | O 8 13 | CONFIRM BUTTON | YE | =MON1+AQ2-SB1 | PIEZO BUTTON | =GEN+AQ2/19.6 |
| =GEN+AQ2/19.6 | =GEN+AQ2-KD1 | MSC816 | -X13 | I 8 13 | = | BN | =MON1+AQ2-SB1 | PIEZO BUTTON | =GEN+AQ2/19.6 |
| =GEN+AQ2/19.8 | =GEN+AQ2-KD1 | MSC816 | -X14 | O 8 14 | = | YE | =MON2+AQ2-SB2 | PIEZO BUTTON | =GEN+AQ2/19.8 |
| =GEN+AQ2/19.9 | =GEN+AQ2-KD1 | MSC816 | -X14 | I 8 14 | = | BN | =MON2+AQ2-SB2 | PIEZO BUTTON | =GEN+AQ2/19.8 |
| =GEN+AQ2/19.7 | =GEN+AQ2-KD1 | MSC816 | -X16 | O 8 16 | | A1 | =GEN+AQ2-KR2 | 24VUC | =GEN+AQ2/19.7 |
| =GEN+AQ2/19.8 | =GEN+AQ2-KD1 | MSC816 | -X16 | I 8 16 | | | | | |
| =GEN+AQ2/19.1 | =GEN+AQ2-KD1 | MSC816 | -X30 | O 8 21 | OVERFLOW | | =GEN+AQ2-KV1 | | =GEN+AQ2/19.3 |
| =GEN+AQ2/19.1 | =GEN+AQ2-KD1 | MSC816 | -X30 | O 8 22 | OPTIONAL | | =GEN+AQ2-KV2 | | =GEN+AQ2/19.4 |
| =GEN+AQ2/19.1 | =GEN+AQ2-KD1 | MSC816 | -X30 | O 8 23 | | | | | |
| =GEN+AQ2/19.1 | =GEN+AQ2-KD1 | MSC816 | -X30 | O 8 24 | | | | | |
| =GEN+AQ2/19.1 | =GEN+AQ2-KD1 | MSC816 | -X30 | O 8 25 | | | | | |
| =GEN+AQ2/19.2 | =GEN+AQ2-KD1 | MSC816 | -X30 | O 8 26 | | | | | |
| =GEN+AQ2/19.2 | =GEN+AQ2-KD1 | MSC816 | -X30 | O 8 27 | | | | | |
| =GEN+AQ2/19.2 | =GEN+AQ2-KD1 | MSC816 | -X30 | O 8 28 | | | | | |

previous:
=GEN+AQ2/20

next:
22



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL 2014 ALL RIGHTS RESERVED WORLDWIDE.

www.marel.com

PROJ. TYPE: 2012-101
CUSTOMER: STANDARD
COUNTRY: -

PAGE DESCRI.: PLC LIST
=REP REPORTS

LAST EDIT DATE:
2017.02.22

PAGE REV.
PROJ. REV.

SCALE: PAGE:
1:1 21
DWG. NO. 2012-101-00002-02
SHEET / TOTAL : (/ 32)

REVISED ON:
CREATED ON: 2014.09.30

BY:
BY: KRUN

CABLE OVERVIEW

| CABLE NAME | SOURCE (FROM) | TARGET (TO) | CABLE TYPE | ALL CONDUCTORS | CONDUCTORS USED | CROSS-SECTION mm | LENGTH [m] | REMARK | PLACEMENT |
|-------------------|-----------------|----------------|----------------------|----------------|-----------------|------------------|------------|--------|---------------|
| =GEN+AQ2-WBTF1 | =GEN+AQ2-KD1 | =GEN+AQ2-TF1 | CAN | 2x2 | 1 | 1,5 | | | =GEN+SOV/7.1 |
| =GEN+AQ2-WCAC1 | =CBELT+AC1-XAC1 | =GEN+AQ2-KD1 | CONTROL | 4 | 3 | 0,5 | | | =GEN+AQ2/19.1 |
| =GEN+AQ2-WCAQ2.2 | =GEN+AQ2-X10 | =GEN+AQ2-X11 | CONTROL | 4 | 4 | 0,5 | | | =GEN+AQ2/17.2 |
| =GEN+AQ2-WCEL1 | =GEN+AQ2-X10 | =GEN+AQ2-EL1 | CONTROL | 4 | 3 | 0,5 | | | =GEN+AQ2/20.3 |
| | =GEN+AQ2 | | | | | | | | |
| =GEN+AQ2-WCEL2 | =GEN+AQ2-X10 | =GEN+AQ2-EL2 | CONTROL | 4 | 3 | 0,5 | | | =GEN+AQ2/20.8 |
| | =GEN+AQ2 | | | | | | | | |
| =GEN+AQ2-WCKC1 | =GEN+AQ2-X10 | =MON1+AQ2-KC1 | CONTROL | 2 | 2 | 0,5 | | | =GEN+AQ2/17.4 |
| | =GEN+AQ2 | | | | | | | | |
| =GEN+AQ2-WCKC2 | =GEN+AQ2-X10 | =MON2+AQ2-KC2 | CONTROL | 2 | 2 | 0,5 | | | =GEN+AQ2/17.6 |
| | =GEN+AQ2 | | | | | | | | |
| =GEN+AQ2-WCRM1 | =MON1+AQ2-XRM1 | =GEN+AQ2-KD1 | CONTROL | 4 | 4 | 0,5 | | | =GEN+AQ2/19.5 |
| | =GEN+AQ2 | =MON1+AQ2-KC1 | | | | | | | |
| =GEN+AQ2-WCRM2 | =MON2+AQ2-XRM2 | =GEN+AQ2-KD1 | CONTROL | 4 | 4 | 0,5 | | | =GEN+AQ2/19.8 |
| | =GEN+AQ2 | =MON2+AQ2-KC2 | | | | | | | |
| =GEN+AQ2-WCSB1 | =GEN+AQ2-X10 | =GEN+AQ2-SB1 | | | 4 | | | | =GEN+AQ2/20.0 |
| =GEN+AQ2-WCSB2 | =GEN+AQ2-X10 | =GEN+AQ2-SB2 | | | 4 | | | | =GEN+AQ2/20.5 |
| =GEN+AQ2-WCSE1 | =GEN+AQ2-X10 | =CBELT+AC1-SE1 | CONTROL | 4 | 4 | 0,5 | | | =GEN+AQ2/16.3 |
| | =GEN+AQ2 | =CBELT+AC1 | | | | | | | |
| =GEN+AQ2-WEKC1 | =GEN+AQ2-KE1 | =MON1+AQ2-KC1 | ETHERNET | 2x2 | 1 | 0,22 | | | =GEN+SOV/8.4 |
| | =GEN+AQ2 | | | | | | | | |
| =GEN+AQ2-WEKC2 | =GEN+AQ2-KE1 | =MON2+AQ2-KC2 | ETHERNET | 2x2 | 1 | 0,22 | | | =GEN+SOV/8.6 |
| | =GEN+AQ2 | | | | | | | | |
| =GEN+AQ2-WPAQ2.1 | =GEN+AQ2-X1 | =GEN+AQ2-X2 | ÖLFLEX CLASSIC 100 G | 5 | 3 | 4 | | | =GEN+AQ2/14.3 |
| =GEN+AQ1-WCAQ2 | =GEN+AQ2-X10 | =GEN+AQ1-X10 | CONTROL | 18 | 16 | 0,5 | | | =GEN+AQ2/16.1 |
| | =GEN+AQ2 | =GEN+AQ1 | | | | | | | |
| =GEN+AQ1-WPAQ2 | =GEN+AQ2-X1 | =GEN+AQ1-X1 | ÖLFLEX CLASSIC 100 G | 5 | 5 | 4 | | | =GEN+AQ2/14.1 |
| | =GEN+AQ2 | =GEN+AQ1 | | | | | | | |
| =GEN+AV1-WBAQ2 | =GEN+AQ2-KD1 | =GEN+AV1-XB1 | CAN | 2x2 | 1 | 1,5 | | | =GEN+SOV/7.1 |
| | =GEN+AQ2 | =GEN+AV1 | | | | | | | |
| =GEN+AV1-WEAQ2 | =GEN+AQ2-KE1 | =GEN+AV1-KE1 | ETHERNET | 2x2 | 1 | 0,22 | | | =GEN+SOV/8.1 |
| | =GEN+AQ2 | =GEN+AV1 | | | | | | | |
| =MON1+AQ2-BM1 | =MON1+AQ2-XRM1 | =MON1+AQ2-BM1 | | | 3 | | | | =GEN+AQ2/19.4 |
| =MON1+AQ2-SB1 | =MON1+AQ2-XRM1 | =MON1+AQ2-SB1 | | | 4 | | | | =GEN+AQ2/19.5 |
| =MON2+AQ2-BM2 | =MON2+AQ2-XRM2 | =MON2+AQ2-BM2 | | | 3 | | | | =GEN+AQ2/19.7 |
| =MON2+AQ2-SB2 | =MON2+AQ2-XRM2 | =MON2+AQ2-SB2 | | | 4 | | | | =GEN+AQ2/19.8 |
| =INF+AQ2-WMM1 | =GEN+AQ2 | =INF+AQ2-M1 | MOTOR | 4+2 | 6 | 1/0,5 | 10 | | =GEN+AQ2/15.0 |
| | =GEN+AQ2-TF1 | | | | | | | | |
| =TAW+AQ2-WMM2 | =GEN+AQ2 | =TAW+AQ2-M2 | MOTOR | 4+2 | 6 | 1/0,5 | 10 | | =GEN+AQ2/15.2 |
| | =GEN+AQ2-TF2 | | | | | | | | |
| =CBELT+AC1-BP1 | =CBELT+AC1-XAC1 | =CBELT+AC1-BP1 | | | 5 | | | | =GEN+AQ2/19.0 |
| | =GEN+AQ2 | | | | | | | | |
| =CBELT+AQ2-WMM3 | =GEN+AQ2 | =CBELT+AQ2-M3 | MOTOR | 4+2 | 6 | 1/0,5 | 10 | | =GEN+AQ2/15.4 |
| | =GEN+AQ2-TF3 | | | | | | | | |
| =CBELT+AQ2-WMM3.1 | =GEN+AQ2-XTF3 | =CBELT+AQ2-M3 | CONTROL | 4 | 4 | 0,22 | | | =GEN+AQ2/18.5 |
| | =REW+AQ2-BP2 | =GEN+AQ2 | =REW+AQ2-BP2 | | 5 | | | | =GEN+AQ2/19.2 |

previous:
21next:
23

THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL 2014 ALL RIGHTS RESERVED WORLDWIDE.

www.marel.com

PROJ. TYPE: 2012-101

CUSTOMER: STANDARD

COUNTRY: -

PAGE DESCRI.: CABLE OVERVIEW
=REP REPORTS

LAST EDIT DATE:
2017.02.22

PAGE REV.
PROJ. REV.

SCALE: PAGE:
1:1

22

DWG. NO. 2012-101-00002-02

SHEET / TOTAL : (/ 32)

CABLE OVERVIEW

previous:

previou
22

next:

next.
24

| SOURCE (FROM) | CONNECTION | PAGE REFERENCE | WIRE | TARGET (TO) | CONNECTION | PAGE REFERENCE |
|------------------------------|------------|--|----------------|----------------------------|-------------------|----------------|
| CABLE NAME: =GEN+AQ2-WBTF1 | | CABLE TYPE: CAN 2x2x1,5 mm ² PART NO.: 718-3702-Y1815PVC | | RD WH SH BU BK | COMMENT: | |
| =GEN+AQ2-KD1 | -X51 | =GEN+SOV/7.1 | XX,WH,SH,BU,BK | =GEN+AQ2-TF1 | CAN | =GEN+SOV/7.1 |
| CABLE NAME: =GEN+AQ2-WCAC1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | RD BU GN YE | COMMENT: | |
| =CBELT+AC1-XAC1 | 32 | =GEN+AQ2/19.1 | RD | =GEN+AQ2-KD1 | -X11 | =GEN+AQ2/19.1 |
| =CBELT+AC1-XAC1 | 31 | =GEN+AQ2/19.1 | BU | =GEN+AQ2-KD1 | -X11 | =GEN+AQ2/19.1 |
| =CBELT+AC1-XAC1 | 51 | =GEN+AQ2/19.1 | GN | =GEN+AQ2-KD1 | -X11:11 | =GEN+AQ2/19.1 |
| CABLE NAME: =GEN+AQ2-WCAQ2.2 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | RD BU GN YE | COMMENT: | |
| =GEN+AQ2-X10 | 32 | =GEN+AQ2/17.1 | RD | =GEN+AQ2-X11 | 32 | =GEN+AQ2/17.3 |
| =GEN+AQ2-X10 | 31 | =GEN+AQ2/17.1 | BU | =GEN+AQ2-X11 | 31 | =GEN+AQ2/17.3 |
| =GEN+AQ2-X10 | 50 | =GEN+AQ2/17.0 | GN | =GEN+AQ2-X11 | 50 | =GEN+AQ2/17.3 |
| =GEN+AQ2-X10 | 42 | =GEN+AQ2/17.1 | YE | =GEN+AQ2-X11 | 42 | =GEN+AQ2/17.3 |
| CABLE NAME: =GEN+AQ2-WCEL1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | RD BU GN YE | COMMENT: | |
| =GEN+AQ2-X10 | 32 | =GEN+AQ2/20.2 | RD | =GEN+AQ2-EL1 | 24VDC | =GEN+AQ2/20.3 |
| =GEN+AQ2-X10 | 31 | =GEN+AQ2/20.2 | BU | =GEN+AQ2-EL1 | 0V | =GEN+AQ2/20.3 |
| =GEN+AQ2-X10 | 51 | =GEN+AQ2/20.2 | GN | | | |
| =GEN+AQ2-X10 | 51 | =GEN+AQ2/20.2 | YE | =GEN+AQ2-EL1 | PWM | =GEN+AQ2/20.3 |
| CABLE NAME: =GEN+AQ2-WCEL2 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | RD BU GN YE | COMMENT: | |
| =GEN+AQ2-X10 | 32 | =GEN+AQ2/20.7 | RD | =GEN+AQ2-EL2 | 24VDC | =GEN+AQ2/20.8 |
| =GEN+AQ2-X10 | 31 | =GEN+AQ2/20.7 | BU | =GEN+AQ2-EL2 | 0V | =GEN+AQ2/20.8 |
| =GEN+AQ2-X10 | 53 | =GEN+AQ2/20.7 | GN | | | |
| =GEN+AQ2-X10 | 53 | =GEN+AQ2/20.7 | YE | =GEN+AQ2-EL2 | PWM | =GEN+AQ2/20.8 |
| CABLE NAME: =GEN+AQ2-WCKC1 | | CABLE TYPE: CONTROL 2x0,5 mm ² PART NO.: 718-3702-00105 | | RD BU | COMMENT: | |
| =GEN+AQ2-X10 | 32 | =GEN+AQ2/17.4 | RD | =MON1+AQ2-KC1 | -X50:1 | =GEN+AQ2/17.4 |
| =GEN+AQ2-X10 | 31 | =GEN+AQ2/17.5 | BU | =MON1+AQ2-KC1 | -X50:5 | =GEN+AQ2/17.5 |
| CABLE NAME: =GEN+AQ2-WCKC2 | | CABLE TYPE: CONTROL 2x0,5 mm ² PART NO.: 718-3702-00105 | | RD BU | COMMENT: | |
| =GEN+AQ2-X10 | 32 | =GEN+AQ2/17.6 | RD | =MON2+AQ2-KC2 | -X50:1 | =GEN+AQ2/17.6 |
| =GEN+AQ2-X10 | 31 | =GEN+AQ2/17.7 | BU | =MON2+AQ2-KC2 | -X50:5 | =GEN+AQ2/17.7 |
| CABLE NAME: =GEN+AQ2-WCRM1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | RD BU GN | COMMENT: OPTIONAL | |
| =MON1+AQ2-XRM1 | 32 | =GEN+AQ2/19.6 | RD | =GEN+AQ2-KD1 | -X13 | =GEN+AQ2/19.6 |
| =MON1+AQ2-XRM1 | 31 | =GEN+AQ2/19.6 | BU | =GEN+AQ2-KD1 | -X13 | =GEN+AQ2/19.6 |
| =MON1+AQ2-XRM1 | 51 | =GEN+AQ2/19.5 | GN | =GEN+AQ2-KD1 | -X13:13 | =GEN+AQ2/19.5 |

previous:
23next:
25

| SOURCE (FROM) | CONNECTION | PAGE REFERENCE | WIRE | TARGET (TO) | CONNECTION | PAGE REFERENCE |
|------------------------------|------------|---|------|-------------------|------------|----------------|
| CABLE NAME: =GEN+AQ2-WCRM1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | COMMENT: OPTIONAL | | |
| =MON1+AQ2-XRM1 | 52 | =GEN+AQ2/19.6 | YE | =GEN+AQ2-KD1 | -X13:13 | =GEN+AQ2/19.6 |
| CABLE NAME: =GEN+AQ2-WCRM2 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | COMMENT: OPTIONAL | | |
| =MON2+AQ2-XRM2 | 32 | =GEN+AQ2/19.8 | RD | =GEN+AQ2-KD1 | -X14 | =GEN+AQ2/19.8 |
| =MON2+AQ2-XRM2 | 31 | =GEN+AQ2/19.8 | BU | =GEN+AQ2-KD1 | -X14 | =GEN+AQ2/19.8 |
| =MON2+AQ2-XRM2 | 51 | =GEN+AQ2/19.8 | GN | =GEN+AQ2-KD1 | -X14:14 | =GEN+AQ2/19.8 |
| =MON2+AQ2-XRM2 | 52 | =GEN+AQ2/19.9 | YE | =GEN+AQ2-KD1 | -X14:14 | =GEN+AQ2/19.9 |
| CABLE NAME: =GEN+AQ2-WCSB1 | | CABLE TYPE: PART NO.: | | COMMENT: | | |
| =GEN+AQ2-X10 | 52 | =GEN+AQ2/20.1 | BN | =GEN+AQ2-SB1 | BN | =GEN+AQ2/20.1 |
| =GEN+AQ2-X10 | 31 | =GEN+AQ2/20.1 | GY | =GEN+AQ2-SB1 | GY | =GEN+AQ2/20.1 |
| =GEN+AQ2-X10 | 32 | =GEN+AQ2/20.0 | WH | =GEN+AQ2-SB1 | WH | =GEN+AQ2/20.1 |
| =GEN+AQ2-X10 | 51 | =GEN+AQ2/20.2 | YE | =GEN+AQ2-SB1 | GN | =GEN+AQ2/20.1 |
| CABLE NAME: =GEN+AQ2-WCSB2 | | CABLE TYPE: PART NO.: | | COMMENT: | | |
| =GEN+AQ2-X10 | 54 | =GEN+AQ2/20.6 | BN | =GEN+AQ2-SB2 | BN | =GEN+AQ2/20.6 |
| =GEN+AQ2-X10 | 31 | =GEN+AQ2/20.6 | GY | =GEN+AQ2-SB2 | GY | =GEN+AQ2/20.6 |
| =GEN+AQ2-X10 | 32 | =GEN+AQ2/20.6 | WH | =GEN+AQ2-SB2 | WH | =GEN+AQ2/20.6 |
| =GEN+AQ2-X10 | 53 | =GEN+AQ2/20.7 | YE | =GEN+AQ2-SB2 | GN | =GEN+AQ2/20.6 |
| CABLE NAME: =GEN+AQ2-WCSE1 | | CABLE TYPE: CONTROL 4x0,5 mm ² PART NO.: 718-3702-0011 | | COMMENT: | | |
| =GEN+AQ2-X10 | 62 | =GEN+AQ2/16.3 | RD | =CBELT+AC1-SE1 | 21 | =GEN+AQ2/16.3 |
| =GEN+AQ2-X10 | 61 | =GEN+AQ2/16.3 | BU | =CBELT+AC1-SE1 | 11 | =GEN+AQ2/16.3 |
| =GEN+AQ2-X10 | 69 | =GEN+AQ2/16.3 | GN | =CBELT+AC1-SE1 | 12 | =GEN+AQ2/16.3 |
| =GEN+AQ2-X10 | 70 | =GEN+AQ2/16.3 | YE | =CBELT+AC1-SE1 | 22 | =GEN+AQ2/16.3 |
| CABLE NAME: =GEN+AQ2-WEKC1 | | CABLE TYPE: ETHERNET 2x2x0,22 mm ² PART NO.: 718-3702-F5P2PUR | | COMMENT: | | |
| =GEN+AQ2-KE1 | RJ45 | =GEN+SOV/8.4 | | =MON1+AQ2-KC1 | RJ45 | =GEN+SOV/8.4 |
| | | | SH | | | |
| CABLE NAME: =GEN+AQ2-WEKC2 | | CABLE TYPE: ETHERNET 2x2x0,22 mm ² PART NO.: 718-3702-F5P2PUR | | COMMENT: | | |
| =GEN+AQ2-KE1 | RJ45 | =GEN+SOV/8.6 | | =MON2+AQ2-KC2 | RJ45 | =GEN+SOV/8.6 |
| | | | SH | | | |
| CABLE NAME: =GEN+AQ2-WPAQ2.1 | | CABLE TYPE: ÖLFLEX CLASSIC 100 G 5x4 mm ² PART NO.: 718-3701-0031 | | COMMENT: | | |
| =GEN+AQ2-X1 | 9 | =GEN+AQ2/14.3 | BN | =GEN+AQ2-X2 | 1 | =GEN+AQ2/14.4 |
| =GEN+AQ2-X1 | 7 | =GEN+AQ2/14.2 | BK | =GEN+AQ2-X2 | 2 | =GEN+AQ2/14.4 |
| | | | GY | | | |
| | | | BU | | | |
| =GEN+AQ2-X1 | PE | =GEN+AQ2/14.3 | GNYE | =GEN+AQ2-X2 | PE | =GEN+AQ2/14.4 |
| CABLE NAME: =GEN+AQ1-WCAQ2 | | CABLE TYPE: CONTROL 18x0,5 mm ² PART NO.: 718-3702-0010 | | COMMENT: | | |
| =GEN+AQ2-X10 | 31 | =GEN+AQ2/16.2 | BU | =GEN+AQ1-X10 | 31 | =GEN+AQ2/16.0 |
| | | | RD | | | |
| =GEN+AQ2-X10 | 42 | =GEN+AQ2/16.2 | GN | =GEN+AQ1-X10 | 42 | =GEN+AQ2/16.0 |

previous:
24next:
26

| SOURCE (FROM) | CONNECTION | PAGE REFERENCE | WIRE | TARGET (TO) | CONNECTION | PAGE REFERENCE |
|----------------------------|------------|---|----------------|-------------------|------------|----------------|
| CABLE NAME: =GEN+AQ1-WCAQ2 | | CABLE TYPE: CONTROL 18x0,5 mm ² PART NO.: 718-3702-0010 | | COMMENT: | | |
| =GEN+AQ2-X10 | 70 | =GEN+AQ2/16.2 | YE | =GEN+AQ1-X10 | 70 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 62 | =GEN+AQ2/16.2 | WH | =GEN+AQ1-X10 | 62 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 61 | =GEN+AQ2/16.2 | BK | =GEN+AQ1-X10 | 61 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 69 | =GEN+AQ2/16.2 | BN | =GEN+AQ1-X10 | 69 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 71 | =GEN+AQ2/16.2 | VT | =GEN+AQ1-X10 | 71 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 72 | =GEN+AQ2/16.2 | OG | =GEN+AQ1-X10 | 72 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 73 | =GEN+AQ2/16.2 | PK | =GEN+AQ1-X10 | 73 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 74 | =GEN+AQ2/16.2 | CY | =GEN+AQ1-X10 | 74 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 75 | =GEN+AQ2/16.2 | GY | =GEN+AQ1-X10 | 75 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 76 | =GEN+AQ2/16.2 | RD/BU | =GEN+AQ1-X10 | 76 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 77 | =GEN+AQ2/16.2 | GN/RD | =GEN+AQ1-X10 | 77 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 78 | =GEN+AQ2/16.2 | YE/RD | =GEN+AQ1-X10 | 78 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 79 | =GEN+AQ2/16.2 | WH/RD | =GEN+AQ1-X10 | 79 | =GEN+AQ2/16.0 |
| =GEN+AQ2-X10 | 80 | =GEN+AQ2/16.2 | RD/BK | =GEN+AQ1-X10 | 80 | =GEN+AQ2/16.0 |
| | | | RD/BN | | | |
| CABLE NAME: =GEN+AQ1-WPAQ2 | | CABLE TYPE: ÖLFLEX CLASSIC 100 G 5x4 mm ² PART NO.: 718-3701-0031 | | COMMENT: | | |
| =GEN+AQ2-X1 | 1 | =GEN+AQ2/14.1 | BN | =GEN+AQ1-X1 | 1 | =GEN+AQ2/14.1 |
| =GEN+AQ2-X1 | 2 | =GEN+AQ2/14.1 | BK | =GEN+AQ1-X1 | 2 | =GEN+AQ2/14.1 |
| =GEN+AQ2-X1 | 3 | =GEN+AQ2/14.1 | GY | =GEN+AQ1-X1 | 3 | =GEN+AQ2/14.1 |
| =GEN+AQ2-X1 | N | =GEN+AQ2/14.1 | BU | =GEN+AQ1-X1 | N | =GEN+AQ2/14.1 |
| =GEN+AQ2-X1 | PE | =GEN+AQ2/14.1 | GNYE | =GEN+AQ1-X1 | PE | =GEN+AQ2/14.1 |
| CABLE NAME: =GEN+AV1-WBAQ2 | | CABLE TYPE: CAN 2x2x1,5 mm ² PART NO.: 718-3702-Y1815PVC | | COMMENT: | | |
| | | | RD | | | |
| | | | WH | | | |
| | | | SH | | | |
| | | | BU | | | |
| | | | BK | | | |
| =GEN+AQ2-KD1 | -X50 | =GEN+SOV/7.1 | XX,WH,SH,BU,BK | =GEN+AV1-XB1 | CAN | =GEN+SOV/7.1 |
| | | | | | | |
| CABLE NAME: =GEN+AV1-WEAQ2 | | CABLE TYPE: ETHERNET 2x2x0,22 mm ² PART NO.: 718-3702-F5P2PUR | | COMMENT: | | |
| =GEN+AQ2-KE1 | RJ45 | =GEN+SOV/8.3 | | =GEN+AV1-KE1 | RJ45 | =GEN+SOV/8.1 |
| | | | SH | | | |
| CABLE NAME: =MON1+AQ2-BM1 | | CABLE TYPE: PART NO.: | | COMMENT: OPTIONAL | | |
| =MON1+AQ2-XRM1 | 32 | =GEN+AQ2/19.6 | | =MON1+AQ2-BM1 | 1 | =GEN+AQ2/19.4 |
| =MON1+AQ2-XRM1 | 31 | =GEN+AQ2/19.6 | | =MON1+AQ2-BM1 | 2 | =GEN+AQ2/19.4 |
| =MON1+AQ2-XRM1 | 52 | =GEN+AQ2/19.6 | | =MON1+AQ2-BM1 | 3 | =GEN+AQ2/19.4 |
| CABLE NAME: =MON1+AQ2-SB1 | | CABLE TYPE: PART NO.: | | COMMENT: OPTIONAL | | |
| =MON1+AQ2-XRM1 | 51 | =GEN+AQ2/19.5 | | =MON1+AQ2-SB1 | YE | =GEN+AQ2/19.6 |

previous:
25next:
27

| SOURCE (FROM) | CONNECTION | PAGE REFERENCE | WIRE | TARGET (TO) | CONNECTION | PAGE REFERENCE |
|-----------------------------|------------|--|------|-------------------|------------|----------------|
| CABLE NAME: =MON1+AQ2-SB1 | | CABLE TYPE: PART NO.: | | COMMENT: OPTIONAL | | |
| =MON1+AQ2-XRM1 | 32 | =GEN+AQ2/19.6 | | =MON1+AQ2-SB1 | WH | =GEN+AQ2/19.6 |
| =MON1+AQ2-XRM1 | 31 | =GEN+AQ2/19.6 | | =MON1+AQ2-SB1 | GY | =GEN+AQ2/19.6 |
| =MON1+AQ2-XRM1 | 52 | =GEN+AQ2/19.6 | | =MON1+AQ2-SB1 | BN | =GEN+AQ2/19.6 |
| CABLE NAME: =MON2+AQ2-BM2 | | CABLE TYPE: PART NO.: | | COMMENT: OPTIONAL | | |
| =MON2+AQ2-XRM2 | 32 | =GEN+AQ2/19.8 | | =MON2+AQ2-BM2 | 1 | =GEN+AQ2/19.7 |
| =MON2+AQ2-XRM2 | 31 | =GEN+AQ2/19.8 | | =MON2+AQ2-BM2 | 2 | =GEN+AQ2/19.7 |
| =MON2+AQ2-XRM2 | 52 | =GEN+AQ2/19.9 | | =MON2+AQ2-BM2 | 3 | =GEN+AQ2/19.7 |
| CABLE NAME: =MON2+AQ2-SB2 | | CABLE TYPE: PART NO.: | | COMMENT: OPTIONAL | | |
| =MON2+AQ2-XRM2 | 51 | =GEN+AQ2/19.8 | | =MON2+AQ2-SB2 | YE | =GEN+AQ2/19.8 |
| =MON2+AQ2-XRM2 | 32 | =GEN+AQ2/19.8 | | =MON2+AQ2-SB2 | WH | =GEN+AQ2/19.8 |
| =MON2+AQ2-XRM2 | 31 | =GEN+AQ2/19.8 | | =MON2+AQ2-SB2 | GY | =GEN+AQ2/19.8 |
| =MON2+AQ2-XRM2 | 52 | =GEN+AQ2/19.9 | | =MON2+AQ2-SB2 | BN | =GEN+AQ2/19.8 |
| CABLE NAME: =INF+AQ2-WMM1 | | CABLE TYPE: MOTOR 4+2x1/0,5 mm ² PART NO.: 718-3701-0042 | | COMMENT: | | |
| =GEN+AQ2-TF1 | U | =GEN+AQ2/15.1 | 1 | =INF+AQ2-M1 | U | =GEN+AQ2/15.0 |
| =GEN+AQ2-TF1 | V | =GEN+AQ2/15.1 | 2 | =INF+AQ2-M1 | V | =GEN+AQ2/15.0 |
| =GEN+AQ2-TF1 | W | =GEN+AQ2/15.1 | 3 | =INF+AQ2-M1 | W | =GEN+AQ2/15.0 |
| =GEN+AQ2-TF1 | PE | =GEN+AQ2/15.1 | PE | =INF+AQ2-M1 | PE | =GEN+AQ2/15.0 |
| =GEN+AQ2-TF1 | T1 | =GEN+AQ2/15.1 | WH | =INF+AQ2-M1 | A | =GEN+AQ2/15.0 |
| =GEN+AQ2-TF1 | T2 | =GEN+AQ2/15.1 | BN | =INF+AQ2-M1 | B | =GEN+AQ2/15.0 |
| | | | SH | | | |
| CABLE NAME: =TAW+AQ2-WMM2 | | CABLE TYPE: MOTOR 4+2x1/0,5 mm ² PART NO.: 718-3701-0042 | | COMMENT: | | |
| =GEN+AQ2-TF2 | U | =GEN+AQ2/15.3 | 1 | =TAW+AQ2-M2 | U | =GEN+AQ2/15.2 |
| =GEN+AQ2-TF2 | V | =GEN+AQ2/15.3 | 2 | =TAW+AQ2-M2 | V | =GEN+AQ2/15.2 |
| =GEN+AQ2-TF2 | W | =GEN+AQ2/15.3 | 3 | =TAW+AQ2-M2 | W | =GEN+AQ2/15.2 |
| =GEN+AQ2-TF2 | PE | =GEN+AQ2/15.3 | PE | =TAW+AQ2-M2 | PE | =GEN+AQ2/15.2 |
| =GEN+AQ2-TF2 | T1 | =GEN+AQ2/15.3 | WH | =TAW+AQ2-M2 | A | =GEN+AQ2/15.2 |
| =GEN+AQ2-TF2 | T2 | =GEN+AQ2/15.3 | BN | =TAW+AQ2-M2 | B | =GEN+AQ2/15.2 |
| | | | SH | | | |
| CABLE NAME: =CBELT+AC1-BP1 | | CABLE TYPE: PART NO.: | | COMMENT: | | |
| =CBELT+AC1-XAC1 | 32 | =GEN+AQ2/19.1 | | =CBELT+AC1-BP1 | 1 | =GEN+AQ2/19.0 |
| =CBELT+AC1-XAC1 | 31 | =GEN+AQ2/19.1 | | =CBELT+AC1-BP1 | 2 | =GEN+AQ2/19.0 |
| =CBELT+AC1-XAC1 | 32 | =GEN+AQ2/19.1 | | =CBELT+AC1-BP1 | 2 | =GEN+AQ2/19.1 |
| =CBELT+AC1-XAC1 | 31 | =GEN+AQ2/19.1 | | =CBELT+AC1-BP1 | 3 | =GEN+AQ2/19.1 |
| =CBELT+AC1-XAC1 | 51 | =GEN+AQ2/19.1 | | =CBELT+AC1-BP1 | 4 | =GEN+AQ2/19.1 |
| CABLE NAME: =CBELT+AQ2-WMM3 | | CABLE TYPE: MOTOR 4+2x1/0,5 mm ² PART NO.: 718-3701-0042 | | COMMENT: | | |
| =GEN+AQ2-TF3 | U | =GEN+AQ2/15.4 | 1 | =CBELT+AQ2-M3 | U | =GEN+AQ2/15.4 |
| =GEN+AQ2-TF3 | V | =GEN+AQ2/15.4 | 2 | =CBELT+AQ2-M3 | V | =GEN+AQ2/15.4 |
| =GEN+AQ2-TF3 | W | =GEN+AQ2/15.4 | 3 | =CBELT+AQ2-M3 | W | =GEN+AQ2/15.4 |

previous:
26next:
28

THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL 2014 ALL RIGHTS RESERVED WORLDWIDE.

www.marel.com

PROJ. TYPE: 2012-101
CUSTOMER: STANDARD
COUNTRY: -

PAGE DESCRI.: CABLE LIST
=REP REPORTS

LAST EDIT DATE:
2017.02.22

PAGE REV.
PROJ. REV.

SCALE: PAGE:
1:1

27

REVISED ON:
CREATED ON: 2014.09.30

BY:
BY: KRUN

DWG. NO. 2012-101-00002-02

SHEET / TOTAL : (/ 32)

| SOURCE (FROM) | CONNECTION | PAGE REFERENCE | WIRE | TARGET (TO) | CONNECTION | PAGE REFERENCE |
|-------------------------------|------------|--|------|---------------|------------|----------------|
| CABLE NAME: =CBELT+AQ2-WMM3 | | CABLE TYPE: MOTOR 4+2x1/0,5 mm ² PART NO.: 718-3701-0042 | | COMMENT: | | |
| =GEN+AQ2-TF3 | PE | =GEN+AQ2/15.4 | PE | =CBELT+AQ2-M3 | PE | =GEN+AQ2/15.4 |
| =GEN+AQ2-TF3 | T1 | =GEN+AQ2/15.4 | WH | =CBELT+AQ2-M3 | A | =GEN+AQ2/15.4 |
| =GEN+AQ2-TF3 | T2 | =GEN+AQ2/15.4 | BN | =CBELT+AQ2-M3 | B | =GEN+AQ2/15.4 |
| | | | SH | | | |
| CABLE NAME: =CBELT+AQ2-WMM3.1 | | CABLE TYPE: CONTROL 4x0,22 mm ² PART NO.: 718-3702-0006 | | COMMENT: | | |
| | | | BU | | | |
| | | | RD | | | |
| =GEN+AQ2-XTF3 | DI1 | =GEN+AQ2/18.5 | GN | =CBELT+AQ2-M3 | | =GEN+AQ2/18.5 |
| =GEN+AQ2-XTF3 | 32 | =GEN+AQ2/18.6 | YE | =CBELT+AQ2-M3 | | =GEN+AQ2/18.5 |
| =GEN+AQ2-XTF3 | 31 | =GEN+AQ2/18.5 | BN | =CBELT+AQ2-M3 | | =GEN+AQ2/18.5 |
| =GEN+AQ2-XTF3 | DI2 | =GEN+AQ2/18.5 | WH | =CBELT+AQ2-M3 | | =GEN+AQ2/18.5 |
| CABLE NAME: =REW+AQ2-BP2 | | CABLE TYPE: PART NO.: | | COMMENT: | | |
| =GEN+AQ2-KD1 | -X12 | =GEN+AQ2/19.3 | | =REW+AQ2-BP2 | 1 | =GEN+AQ2/19.2 |
| =GEN+AQ2-KD1 | -X12 | =GEN+AQ2/19.3 | | =REW+AQ2-BP2 | 2 | =GEN+AQ2/19.2 |
| =GEN+AQ2-KD1 | -X12 | =GEN+AQ2/19.3 | | =REW+AQ2-BP2 | 2 | =GEN+AQ2/19.3 |
| =GEN+AQ2-KD1 | -X12 | =GEN+AQ2/19.3 | | =REW+AQ2-BP2 | 3 | =GEN+AQ2/19.3 |
| =GEN+AQ2-KD1 | -X12:12 | =GEN+AQ2/19.3 | | =REW+AQ2-BP2 | 4 | =GEN+AQ2/19.3 |
| CABLE NAME: =REW+AQ2-WMM4 | | CABLE TYPE: MOTOR 4+2x1/0,5 mm ² PART NO.: 718-3701-0042 | | COMMENT: | | |
| =GEN+AQ2-TF4 | U | =GEN+AQ2/15.6 | 1 | =REW+AQ2-M4 | U | =GEN+AQ2/15.6 |
| =GEN+AQ2-TF4 | V | =GEN+AQ2/15.6 | 2 | =REW+AQ2-M4 | V | =GEN+AQ2/15.6 |
| =GEN+AQ2-TF4 | W | =GEN+AQ2/15.6 | 3 | =REW+AQ2-M4 | W | =GEN+AQ2/15.6 |
| =GEN+AQ2-TF4 | PE | =GEN+AQ2/15.6 | PE | =REW+AQ2-M4 | PE | =GEN+AQ2/15.6 |
| =GEN+AQ2-TF4 | T1 | =GEN+AQ2/15.6 | WH | =REW+AQ2-M4 | A | =GEN+AQ2/15.6 |
| =GEN+AQ2-TF4 | T2 | =GEN+AQ2/15.6 | BN | =REW+AQ2-M4 | B | =GEN+AQ2/15.6 |
| | | | SH | | | |
| CABLE NAME: =REW+AQ2-WMM4.1 | | CABLE TYPE: CONTROL 4x0,22 mm ² PART NO.: 718-3702-0006 | | COMMENT: | | |
| | | | BU | | | |
| | | | RD | | | |
| =GEN+AQ2-XTF4 | DI1 | =GEN+AQ2/18.7 | GN | =REW+AQ2-M4 | | =GEN+AQ2/18.7 |
| =GEN+AQ2-XTF4 | 32 | =GEN+AQ2/18.7 | YE | =REW+AQ2-M4 | | =GEN+AQ2/18.7 |
| =GEN+AQ2-XTF4 | 31 | =GEN+AQ2/18.6 | BN | =REW+AQ2-M4 | | =GEN+AQ2/18.7 |
| =GEN+AQ2-XTF4 | DI2 | =GEN+AQ2/18.7 | WH | =REW+AQ2-M4 | | =GEN+AQ2/18.7 |
| CABLE NAME: =DEL+AQ2-WMM5 | | CABLE TYPE: MOTOR 4+2x1/0,5 mm ² PART NO.: 718-3701-0042 | | COMMENT: | | |
| =GEN+AQ2-TF5 | U | =GEN+AQ2/15.8 | 1 | =DEL+AQ2-M5 | U | =GEN+AQ2/15.8 |
| =GEN+AQ2-TF5 | V | =GEN+AQ2/15.8 | 2 | =DEL+AQ2-M5 | V | =GEN+AQ2/15.8 |
| =GEN+AQ2-TF5 | W | =GEN+AQ2/15.8 | 3 | =DEL+AQ2-M5 | W | =GEN+AQ2/15.8 |
| =GEN+AQ2-TF5 | PE | =GEN+AQ2/15.8 | PE | =DEL+AQ2-M5 | PE | =GEN+AQ2/15.8 |
| =GEN+AQ2-TF5 | T1 | =GEN+AQ2/15.8 | WH | =DEL+AQ2-M5 | A | =GEN+AQ2/15.8 |

previous:

27

next:

29



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL 2014 ALL RIGHTS RESERVED WORLDWIDE.

www.marel.com

PROJ. TYPE: 2012-101
CUSTOMER: STANDARD
COUNTRY: -

PAGE DESCRI.: CABLE LIST
=REP REPORTS

LAST EDIT DATE:
2017.02.22

PAGE REV.
PROJ. REV.

SCALE: PAGE:
1:1

28

DWG. NO. 2012-101-00002-02

SHEET / TOTAL : (/ 32)

| SOURCE (FROM) | CONNECTION | PAGE REFERENCE | WIRE | TARGET (TO) | CONNECTION | PAGE REFERENCE |
|---------------------------|------------|--|------|-------------|------------|----------------|
| CABLE NAME: =DEL+AQ2-WMM5 | | CABLE TYPE: MOTOR 4+2x1/0,5 mm ² PART NO.: 718-3701-0042 | | COMMENT: | | |
| =GEN+AQ2-TF5 | T2 | =GEN+AQ2/15.8 | BN | =DEL+AQ2-M5 | B | =GEN+AQ2/15.8 |
| | | | SH | | | |

previous:

28

next:

30



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

© MAREL 2014 ALL RIGHTS RESERVED WORLDWIDE.

www.marel.com

PROJ. TYPE: 2012-101
CUSTOMER: STANDARD
COUNTRY: -

PAGE DESCRI.: CABLE LIST
=REP REPORTS

LAST EDIT DATE:
2017.02.22

PAGE REV.
PROJ. REV.

SCALE: PAGE:
1:1

29

REVISED ON:
CREATED ON: 2014.09.30

BY:
BY: KRUN

DWG. NO. 2012-101-00002-02
SHEET / TOTAL : (/ 32)

| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|---------|---------------|---------------------|---|--------------------|---------------------|------|------------|---------------------|---------------------|
| POS.NO. | DEVICE TAG | MAREL NUMBER (IS) | DESCRIPTION | MANUFACTURER | TYPE NUMBER | QTY. | LENGTH | ENCL. ITEM NO. | PAGE REFERENCE |
| 1 | =GEN+AQ2-1 | 055-0010-0 | Mounting rail EN 50 022 (35x15) | | TS 35_15 | 1 | 602,705 mm | =GEN+AQ2 (+AQ2 COM) | |
| 2 | =GEN+AQ2-2 | 721-4904-1030491 | Cable duct 60x40 | HAGER | TEBA7 60040 | 1 | 478,002 mm | =GEN+AQ2 (+AQ2 COM) | |
| 3 | =GEN+AQ2-3 | 721-4904-1030491 | Cable duct 60x40 | HAGER | TEBA7 60040 | 1 | 134,1 m3 | =GEN+AQ2 (+AQ2 COM) | |
| 4 | =GEN+AQ2-4 | 721-4904-1030491 | Cable duct 60x40 | HAGER | TEBA7 60040 | 1 | 546,702 mm | =GEN+AQ2 (+AQ2 COM) | |
| 5 | =GEN+AQ2-5 | 721-4904-1030491 | Cable duct 60x40 | HAGER | TEBA7 60040 | 1 | 134,1 m5 | =GEN+AQ2 (+AQ2 COM) | |
| 6 | =GEN+AQ2-6 | 055-0010-0 | Mounting rail EN 50 022 (35x15) | | TS 35_15 | 1 | 397,9 mm6 | =GEN+AQ2 (+AQ2 COM) | |
| 7 | =GEN+AQ2-7 | 055-0010-0 | Mounting rail EN 50 022 (35x15) | | TS 35_15 | 1 | 124,739 mm | =GEN+AQ2 (+AQ2 COM) | |
| 8 | =GEN+AQ2-8 | 721-4904-1030490 | Cable duct 60x25 | HAGER | TEBA7 60025 | 1 | 552,363 mm | =GEN+AQ2 (+AQ2 INV) | |
| 9 | =GEN+AQ2-9 | 721-4904-1030490 | Cable duct 60x25 | HAGER | TEBA7 60025 | 1 | 397,457 mm | =GEN+AQ2 (+AQ2 INV) | |
| 10 | =GEN+AQ2-10 | 721-4904-1030490 | Cable duct 60x25 | HAGER | TEBA7 60025 | 1 | 353,452 mm | =GEN+AQ2 (+AQ2 INV) | |
| 11 | =GEN+AQ2-11 | 721-4904-1030490 | Cable duct 60x25 | HAGER | TEBA7 60025 | 1 | 487,293 mm | =GEN+AQ2 (+AQ2 INV) | |
| 12 | =GEN+AQ2-12 | 055-0010-0 | Mounting rail EN 50 022 (35x15) | | TS 35_15 | 1 | 491,79 mm5 | =GEN+AQ2 (+AQ2 INV) | |
| 13 | =GEN+AQ2-. | 715-3303-1954000000 | END SUPPORT ZEW | WEIDMULLER | ZEW | 13 | | 12 | =GEN+AQ2 (+AQ2 COM) |
| 14 | =GEN+AQ2-EL1 | ELM-EVIS-BL1 | LIGHT LED 24V | MAREL | ELM-EVIS-BL1 | 1 | | | =GEN+AQ2/20.3 |
| 15 | =GEN+AQ2-EL2 | ELM-EVIS-BL1 | LIGHT LED 24V | MAREL | ELM-EVIS-BL1 | 1 | | | =GEN+AQ2/20.8 |
| 16 | =GEN+AQ2-FC1 | 717-4403-1051573 | CIRCUIT BREAKER 2P 10A | ABB | SU202M-C10 | 1 | | 27 | =GEN+AQ2/15.0 |
| 17 | =GEN+AQ2-FC1a | 717-4403-1051573 | CIRCUIT BREAKER 2P 10A | ABB | SU202M-C10 | 1 | | 35 | =GEN+AQ2/14.5 |
| 18 | =GEN+AQ2-FC1b | 717-4403-1051571 | CIRCUIT BREAKER 1P 10A | ABB | SU201M-C10 | 1 | | 34 | =GEN+AQ2/14.6 |
| 19 | =GEN+AQ2-FC2 | 717-4403-1051573 | CIRCUIT BREAKER 2P 10A | ABB | SU202M-C10 | 1 | | 28 | =GEN+AQ2/15.2 |
| 20 | =GEN+AQ2-FC3 | 717-4403-1051573 | CIRCUIT BREAKER 2P 10A | ABB | SU202M-C10 | 1 | | 29 | =GEN+AQ2/15.4 |
| 21 | =GEN+AQ2-FC4 | 717-4403-1051573 | CIRCUIT BREAKER 2P 10A | ABB | SU202M-C10 | 1 | | 30 | =GEN+AQ2/15.6 |
| 22 | =GEN+AQ2-FC5 | 717-4403-1051573 | CIRCUIT BREAKER 2P 10A | ABB | SU202M-C10 | 1 | | 31 | =GEN+AQ2/15.8 |
| 23 | =GEN+AQ2-KD1 | ELM-ECAN-MCS816 | MODULE, I/O MCS816 | MAREL | MCS816 | 1 | | 17 | =GEN+SOV/7.0 |
| 24 | =GEN+AQ2-KD4 | 001-0012-0037 | MODULE, I/O MCV8S8 | MAREL | MCV8S8 | 1 | | 18 | =GEN+SOV/7.1 |
| 25 | =GEN+AQ2-KE1 | elm-enet-es5 | ETHERNET SWITCH, 5-PORTS, 24VDC | MAREL | ES5 | 1 | | 33 | =GEN+SOV/8.3 |
| 26 | =GEN+AQ2-KR1 | 717-3406-1LC1D183BL | CONTACTOR 3P/18A 24VDC | SCHNEIDER ELECTRIC | LC1D183BL | 1 | | | =GEN+AQ2/17.3 |
| 27 | =GEN+AQ2-KR1 | | CONTACTOR TeSys LC1-D - 3P - AC-3 440V 18 A | SCHNEIDER ELECTRIC | LC1D18BD | 1 | | 17 | =GEN+AQ2 (+AQ2 INV) |
| 28 | =GEN+AQ2-KR2 | 717-3406-1012307 | RELAY 24VAC/DC 1XCO 6A | WEIDMULLER | TRZ 24VUC 1CO | 1 | | | =GEN+AQ2/19.7 |
| 29 | =GEN+AQ2-KV1 | 750-1020-1020594 | VALVE SV20 BLOCK X2 (2 VALVES) | SMC | 750-1020-1020594 | 1 | | 19 | =GEN+AQ2/19.3 |
| 30 | =GEN+AQ2-KV2 | 750-SV20-21005FU | VALVE SOLENOID | SMC | SV2100-5FU | 1 | | | =GEN+AQ2/19.4 |
| 31 | =GEN+AQ2-KV2 | 750-SV20-503AC6 | VALVE SV20 BASE | SMC | SV2000-50-3A-C6 | 1 | | | =GEN+AQ2/19.4 |
| 32 | =GEN+AQ2-R2 | | RESISTOR 120 OHM 0,25 W | AZCON | MF207/120 | 1 | | | =GEN+SOV/7.2 |
| 33 | =GEN+AQ2-R3 | 711-2000-32205 | RESISTOR 2,2 KOHM 0,25 W | IHLUTIR | 711-2000-32205 | 1 | | | =GEN+AQ2/18.6 |
| 34 | =GEN+AQ2-R4 | 711-2000-32205 | RESISTOR 2,2 KOHM 0,25 W | IHLUTIR | 711-2000-32205 | 1 | | | =GEN+AQ2/18.5 |
| 35 | =GEN+AQ2-R5 | 711-2000-32205 | RESISTOR 2,2 KOHM 0,25 W | IHLUTIR | 711-2000-32205 | 1 | | | =GEN+AQ2/18.7 |
| 36 | =GEN+AQ2-R6 | 711-2000-32205 | RESISTOR 2,2 KOHM 0,25 W | IHLUTIR | 711-2000-32205 | 1 | | | =GEN+AQ2/18.7 |
| 37 | =GEN+AQ2-SB1 | 717-3400-1029180 | PUSH BUTTON PIEZO 22MM BLUE/WHITE 3M CABLE | BARAN | 13102058-01_907-526 | 1 | | | =GEN+AQ2/20.1 |
| 38 | =GEN+AQ2-SB2 | 717-3400-1029180 | PUSH BUTTON PIEZO 22MM BLUE/WHITE 3M CABLE | BARAN | 13102058-01_907-526 | 1 | | | =GEN+AQ2/20.6 |
| 39 | =GEN+AQ2-TF1 | 725-8400-1020401 | INVERTER 1-PH 0,37 KW | LENZE | E84AVSCE3712SX0 | 1 | | 18 | =GEN+AQ2/15.1 |
| 40 | =GEN+AQ2-TF2 | 725-8400-1020401 | INVERTER 1-PH 0,37 KW | LENZE | E84AVSCE3712SX0 | 1 | | 19 | =GEN+AQ2/15.3 |
| 41 | =GEN+AQ2-TF3 | 725-8400-1020401 | INVERTER 1-PH 0,37 KW | LENZE | E84AVSCE3712SX0 | 1 | | 20 | =GEN+AQ2/15.4 |
| 42 | =GEN+AQ2-TF4 | 725-8400-1020401 | INVERTER 1-PH 0,37 KW | LENZE | E84AVSCE3712SX0 | 1 | | 21 | =GEN+AQ2/15.6 |

previous:
29next:
31

| | | | | | | | |
|--|---|----------------------|---------------------------------|-----------------------------------|--|-------------------|-----------------------------------|
|  <p>© MAREL 2014 ALL RIGHTS RESERVED WORLDWIDE. www.marel.com</p> | <p>THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.</p> | PROJ. TYPE: 2012-101 | PAGE DESCRI.: PARTS LIST | LAST EDIT DATE: 2017.03.02 | PAGE REV. | SCALE: 1:1 | PAGE: 30 |
| | | CUSTOMER: STANDARD | =REP | REPORTS | PROJ. REV. | | DWG. NO. 2012-101-00002-02 |
| | | COUNTRY: - | | | REVISED ON: BY: CREATED ON: 2014.09.30 BY: KRUN | | SHEET / TOTAL : (/ 32) |

previous
30



THIS DRAWING REMAINS PROPERTY OF MAREL ENTITY, SPECIFIED ON PAGE 1 AND MAY NOT BE COPIED OR REPRODUCED IN WHATEVER FORM WITHOUT PRIOR WRITTEN CONSENT OF MAREL. FURTHER THIS DRAWING MAY NOT BE DISCLOSED OR GIVEN TO ANY OTHER PARTY FOR INFORMATION OR USE WITHOUT PRIOR WRITTEN CONSENT OF MAREL.

MAREL

DE www.marel.com

PROJ. TYPE: 2012-101
CUSTOMER: STANDARD
COUNTRY: -

GE DESCRIPTIVE PARTS LIST
REP REPORTS

EDIT DATE:
17.03.02

PAGE REV.

PAGE: 1

31

| | |
|---------------------|------------|
| 17.03.02 | PROJ. REV. |
| ISED ON: | BY: |
| ATED ON: 2014-09-20 | PY: KRUN |

WG. NO. 2012-101-00002-02
EFT / TOTAL : (1 / 32)

Appendix

Regulations and licenses

SensorX X-ray Inspection unit uses low-energy X-rays to scan the product. During the design and construction of SensorX X-ray Inspection unit great care has been taken to ensure safe operation. Radiation regulations guiding the design and the construction of the equipment include:

Denmark:

Sundhedsstyrelsens bekendtgørelse nr. 307 af 24. maj 1984 om industrielle røntgenanlæg m.v.

Germany:

DIN 54 113, Teil 1, 1992 Strahlenschutzregeln f. die technische Anwendung von Röntgeneinrichtungen bis 500 kV.

DIN 54 113, Teil 2, 1992 Strahlenschutzregeln f. die technische Anwendung von Röntgeneinrichtungen bis 500 kV.

DIN 54113-3, 1995 Strahlenschutzregeln f. die technische Anwendung von Röntgeneinrichtungen bis 500 kV.

Iceland:

Law nr. 44/2002 on radiological protection.

USA:

PART 1020 -- PERFORMANCE STANDARDS FOR IONIZING RADIATION EMITTING PRODUCTS
Sec. 1020.40 Cabinet X-ray systems.

REMARK



Generally, a license is needed from the local authorities for the operation of an X-ray machine. In some countries a license is granted from a federal institution but sometimes by a local institution, for example from the county or state. This institution can also provide information regarding X-ray radiation, if needed.

Your local Marel representative can help you locate the appropriate institution.

Glossary of Terms

Emergency Stop Button

When activated, the button immediately stops SensorX25. Located on the front panel.

Front Panel

An operator panel with indicators to start/stop SensorX

Hz

Hertz, frequency measure unit.

kV

Kilovolts, thousands of volts.

kW

Kilowatts.

l/min

Capacity measure—liters per minute.

mA

Milliampere, one thousand of an Ampere.

Safety Circuit

The safety circuit is an electronic circuit that prevents the operation of the machine if the machine is in an unsafe state.

SensorX main display

A computer with a display unit that controls Marel equipment.

Index

A

Accessibility 7
Acidity 67
Adjusting
 cylinder speed 59
 light beam 60
 product sensor 60
Air 7
 cylinders 58
Air cylinders 11
Alarms 27, 44
Alarms, button 26
Assembling after sanitizing 71

B

Belt
 maintenance procedures 62
 quality 63
 speed 4
 tension 56, 62-63
Browse, button 26

C

Check list, installation 12
Chlorine 65
Chlorine, strength 68, 71
Cleaning
 assembling after sanitizing 71
 daily 67
 electrical cabinet 72
 final inspection 71
 foaming 70
 M3000 display 72
 materials used 65
 preparation 69
 procedures 68
 sanitizing 71
 training staff 68
 washing 71
 water temperature 66
Cleaning personnel
 training 68

Controls 23
Conveyor belts, cleaning 72
Conveyor ends 13
Cooling fans 17
Cross-contamination, prevent 70

D

Daily cleaning 67
Detergents
 choosing 67
 pH value 67
 use of 65
Disinfectants 67
Display
 cleaning 72

E

Electrical 13
 supply 10
Electrical cabinet, cleaning 72
Electricity 7
Elevating conveyor 3
Emergency stop 18, 22, 56, 64
Equipment, verification 7
Exit, button 27

F

Fans, cooling 17
Final inspection, cleaning 71
Floor, location 7
Foaming, cleaning 70

H

Hardware Monitor
 screen 35

I

Infeed conveyor 3
Information, button 26
Installation
 check list 12

L

Labels, warning 15
Light beam 60

M

M3000 display, cleaning 72
Main screen 26
Mains breaker 72
Maintenance
procedures 57
Maintenance procedures
product sensor 60
Maintenance schedule 56
Materials, cleaning 65
Metals, cleaning 65
Micro-organisms, count 71
Motors 63

N

Noise level 5

O

Overflow 3

P

PH value, detergents 67
Plastics, cleaning 65
Pneumatic
installations 11
Pneumatic installations 11
Preparation, cleaning 69
Pressure, water 65, 70
Procedures, cleaning 68
Procedures, maintenance 57
Product sensors 60

Q

Quaternary ammonium compounds (QACs) 67-68

R

Radiation 14, 17
Replacing air cylinders 59
Requirements, site 7
Return conveyor 3
Rework station 3
Rework terminal 3, 42

S

Safety
circuits 18
covers 14
system 17
Sanitizing 71
Schedule, maintenance 56
Sensors, product 60
Shock absorber 59
Site requirements 7
Speed adjustment, cylinders 59
Start/Stop, button 27
Status, indicator 26

T

Technical data 4
Temperature 7, 52
Temperature, water 66
Tension of belts 63
Training staff, cleaning 68

U

User interface, description 26

V

Verification of equipment 7
Voltage 4

W

Warning labels 15
Washing 71
Washing screen 31
Water
temperature 70
Water pressure 65, 70
Water, temperature 66, 70
Weight 5, 41, 53
Work stations
cleaning 69

X

X-ray 5, 14, 17-18, 23, 26, 32, 50, 52-53
radiation, leakage 17